





User Guide

Table of Contents

Chapter 1	Preface	4
Purp	ose	4
Orga	inization	4
Conv	ventions	4
Chapter 2	NCT192 User Interface	6
∎ Usor	Interface Mode	6
Acce	ess via the Console Port	6
Acce	ass using the Telnet Session	
/1000	Session Logout	
	Telnet Timeout	8
Man	aging the Session Login Account	8
Com	mand Syntax and Operating Regulation	10
	Syntax Notation Conventions	10
	Structure of a CLI Command	10
	Command Syntax and Context Sensitive Help	11
	Command History and Editing Features	11
	Ending a Session	12
Chapter 3	Initialing the NE	14
Port	Interface Indication	
Cons	structing the NE Objects	
	Planning the System Card Type	
	Verifying Current Software and Hardware Versions	19
	Configuring the System Information	20
Conf	iguring the SNMP Manager	21
	Configuring the SNMP Community	22
	Configuring the IP Address of SNMP Trap Station	23
Conf	iguring the Management Interface	23
	Setting the Management Ethernet (NME) Interface IP Address	
	Setting the in-band Interface (UGE) IP Address	
	Configuring the Default Gateway	
Main	toining the CE Network Interface	۲ ــــــــــــــــــــــــــــــــــــ
Mair	Configuring the UCE Negotiation Mode	∠0 28
	Checking the SEP module information	20 20
Main	taining the NF	29 30
Main	Storing the Active System Configuration	
	Backup and Restore the Active System Configuration	
	File System Management	
	Managing the Boot Section	34
	NE Firmware Upgrade	
	NE Firmware Upgrade in Cascade mode	
	SHDSL Firmware Upgrade	37
Conf	iguring the System Date and Time	
Conf	iguring the Internet Time Server	
Conf	iguring the DNS Server	
Amb	ient lemperature	
Chapter 4	Managing the System Profiles	44
Conf	iguring the xDSL Profile	45
	Contiguring the ADSL Connection Profile	
	Contiguring the ADSL Performance Alarm Profile	
	Configuring the Traffic Policing Profile	
	Configuring the SHDSL Connection Profile	
	Configuring the Shost Performance Alarm Profile	60

Co	onfiguring the VLAN Profile	62
	Configuring the IP Traffic Profile	62
	Configuring the Multicast Service Related Profile	64
Chapter 4	5 Managing the Subscriber Interface	68
Onapter		
Co	onfiguring the ADSL Line Port	68
Mo	phitoring the ADSL Connection Status	70
Co	onfiguring the SHDSL Line Port	
MC	Ditoring the SHDSL Connection Status	
	spining the Line Card Operation Mode	12 73
De		
Chapter (6 Managing the Network Interface	78
Co	onfiguring the RSTP	78
	Configuring RSTP Bridge Parameters	79
-	Configuring RSTP Port GE1/Port GE2 parameters	81
Co	onfiguring the Link Aggregation	
Co	onfiguring the CoS Traffic Mapping	
	Mapping the 802.1p value to the priority queue of GE port	88
No	Mapping the 802.1p value to the DSCP value	88
	etwork Interface Administrating	90
De	sining the NC Gald Operation Mode	
CC	priguring the Cascading	
		4.00
Chapter	Managing the Connection Services	102
VC	C-to-VLAN Connection Management	102
	Configuring a VC-to-VLAN Connection for the VC of RFC2684 Bridged Mode	
	Configuring a VC-to-VLAN Connection for the VC of RFC2684 Routed Mode	
	Monitoring the VC-to-VLAN Connection Status	
MU	Jiticast Service Management	
	Configuring Multicast Channel.	109 111
	Monitoring the ICMP Spoony/Proxy Information	
Ma	anaging the Subscriber Access Services	
Co	onfiguring the Access Control List	118
00	Source MAC Access Control List	118
	Filtering the NetBIOS and NetBEUI	
Co	onfiguring the System Services	
	DHCP Broadcast Control	120
	DHCP Relay Setting	121
	DHCP Relay Option 82 Setting	123
	Configuring the PPPoE Suboption	123
	Configuring the VLAN MAC Limitation	124
	Configuring MAC Aging for Bridged Services	125
	Monitoring the VLAN Member Set	
	Configuring Static MAC	
	Filtering the Upstream Traffic of Spoofed MAC	
		130
Chapter 8	8 Managing the System Operations	136
Sy	stem Administrating	
	Reset the Line Card and Port	
	Reboot the System	
Ala	arm Definition and Relay Setting	
	Configuring the Alarm Definition	
	Configuring the System Relay-In Alarm	
_	Configuring the System Relay-Out AidIII	
Chapter 9	9 Diagnosis and Performance Monitoring	144

Performance Monitoring on System and Network Interface	144
Performance Monitoring on ADSL Subscriber Interface	145
Performance Monitoring on SHDSL Subscriber Interface	146
Monitoring System Alarms	147
OAM and Loop Diagnostic Test on Subscriber Interface	150
ATM OAM F5 VC Diagnosis	150
ADSL Loop Diagnosis (DELT <dual-ended line="" test="">)</dual-ended>	151
ADSL Link Monitoring	
Loop SELT Test (Single End Loop Test)	158
Network Ping Test	159
Monitoring the System Environment	159
Monitoring the System Performance	161
Appendix A Abbreviations and Acronyms	A-1
Appendix B Alarm Definition	B-1
Appendix C Legal and Regulatory Information	В-3

Chapter 1 Preface

This preface describes the "NCT192 IP-DSLAM System Configuration Guide" about how it is organized, and its document conventions. It contains the following topics:

- Purpose
- Organization
- Conventions

Purpose

The purpose of this guide is to provide detailed information and description of NCT192 IP-DSLAM, which includes software configuration and other specific features. This document is intended to help system operator to operate the software and understand the NCT192 IP-DSLAM system configurations as quickly as possible.

Organization

This guide contains the following chapters:

- Preface
- NCT192 User Interface
- Initialing the NE
- Managing the System Profiles
- Managing the Subscriber Interface
- Managing the Network Interface
- Managing the Connection Services
- Managing the System Functions
- Diagnosis and Performance Monitoring
- Appendix

Conventions

This section describes the conventions used in this guide.

The NCT192 IP-DSLAM is the Next-Generation xDSL Broadband Access Network comprises a Gigabit Ethernet and a number of ATU-Rs, STU-Rs, and POTS splitter to construct a broadband access network between central office and customer premises. The NCT192 IP-DSLAM uses statistically multiplexing and ATM over xDSL technologies to provide the broadband data communication services, such as high speed Internet access and multimedia services, across existing twisted pair telephone line.

NCT192 IP-DSLAM (Digital Subscriber Line Access Multiplexer) represents NCT192.

All statement in this document applies to the NCT192 IP-DSLAM. However it is noted that the valid range of port and slot are different for each model. The following table lists the valid range of slot and port.

Model Name	Valid range of Network Card	Valid range of Line Card	Range of ADSL/SHDSL port
NCT192	1	1~4	1~48

NE/NEs hereinafter referred as NCT192 medium capacity IP-DSLAM, unless specifically indicated.

ADSL mention in this document covers ADSL, ADSL2, and ADSL2+, unless specifically indicated.

xDSL hereinafter referred as ADSL, unless specifically indicated.

The **xDSL** specified in this document compliance with ITU-T Rec. G.992.1, G.992.2, G.992.3 and G.992.5 for ADSL.

CLI Ex – The command line management with a local console or Telnet through in-band or out-of-band IP interface for CIT (Craft Interface Terminal) connection.

NCT192 LCT – NCT192 Local Craft Terminal (LCT), a stand-along host with SNMP base EMS (Element Management System) provides GUI operation under single section through in-band or out-of-band IP management interface.



This sign indicates the **NOTICE**. A note contains helpful suggestions or reference relay on the topical subjects.



This sign indicates the **TIP**. Performing the information described in the paragraph will help you solve a problem. The tip information might not be troubleshooting or even an action, but could be useful information.



This sign indicates the **CAUTION**. In this situation, you might do something that could result in equipment damage or loss of data.



This sign indicates the DANGER. You are in situation that could cause bodily injury. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.

Chapter 2 NCT192 User Interface

This chapter describes the NCT192 user interface, the instructions describe how to using the command-line interface, and also describes the command editing and command history features that enable you to recall previous command entries and edit previously entered commands.

- User Interface Mode
- Access via the Console Port
- Access using the Telnet Session
- Managing the Session Login Account
- Command Syntax and Operating Regulation

User Interface Mode

The NCT192 provides the CLI Ex mode to access the device in either one of the following ways:

- Remote Telnet via in-band port
- Remote Telnet via out-band port
- Local RS232 Console

Access via the Console Port

The NCT192 provides RS232 port for the operator to perform configuration operations via a directly connected VT-100 compatible terminal.

Follow the following procedure to enter the CLI Ex mode via a direct VT100-compatible terminal, for example, the hyper terminal in Microsoft Windows environment.

Step 1 Set the communication parameters of a VT100-compatible terminal shown in Table 2-1.

Table 2-1 NCT192 Console Management Setting

Parameter	Setting
Baud rate	9600
Data bits	8
Parity	None
Start bits	1
Stop bits	1
Flow control	None

- **Step 2** Connect the VT100-compatible terminal to the Console Port on the NCT192 front panel.
- Step 3 Press <Enter> a number of times until the "Login:" is displayed on the screen.
- **Step 4** Enter the username and password. The default administration username and password are listed below (case sensitive):

Login: **admin** Password: **admin**



See the Section "Managing the Session Login Account" of Chapter 2 for detail information.

Access using the Telnet Session

Enter the CLI Ex mode by establishing a Telnet session between the local host and NCT192 though either the in-band (UGE) or out-band (M-ETH) port.

Follow the following procedure to enter the CLI Ex mode:

- Step 1 Open the MS-DOS prompt window in Microsoft Windows environment.
- **Step 2** Type the "telnet xx.xx.xx (IP address)" in the MS-DOS prompt window to establish a telnet connection to the target NCT192.
- **Step 3** Enter the username and password. The default administration username and password are listed below (case sensitive):

User Name: admin Password: admin

If the IP address of NCT192 is changed during configuration, the Telnet session will be broken. The operator needs to build a new Telnet session to continue the configuration process.

If the assigned IP has been changed and forgotten, locally access NCT192 via Console port with the command shown in Example 1 to retrieve the IP address assigned to the system.



The IP address assigned must be unique in use with the device on the network segment. Refer to the Section "Configuring the Management Interface" of Chapter 3 for more information.

Example 1 Display the system management IP addresses

CLI # config ip show UGE	
IP address subnet mask MAC address UGE VLAN ID	: 172.17.192.1 : 255.255.0.0 : 00:60:64:dc:7a:17 : 4092
NME IP address subnet mask	: 192.168.192.1 : 255.255.255.0
Gateway IP address	: 172.17.192.254



The single NE supports up to 12 concurrent telnet sessions. Only one concurrent telnet session is allowed to enter by admin account user at a time (Console access included), the default "**admin**" account user is with administrator privilege level, see the Section "Managing the Session Login Account" of Chapter 2 for detail information.

Session Logout

The following command is to terminate the Telnet session or quit the console session from CLI Ex mode.

To logout the sessions using the "logout" command at the prompt for CLI#.

Table 2-2 Session Logout Command

The following command is to logout the session (Telnet or Console).	
	_

CLI# logout

If you are using Telnet access for the CLI Ex mode, the command "**logout**" will terminate the current Telnet session, and the CLI Ex will return to the login prompt if using Console access.

Telnet Timeout

The following command is to set the Telnet session time-out timer from CLI Ex mode. Telnet session will terminate when the telnet time-out times ends, and the CLI Ex will return to the login prompt if using Console access.

Table 2-3 Telnet	Session	Timeout	Command
------------------	---------	---------	---------

Use this command to set the telnet time-out of the system.				
CLI(config mgt)# telnet-time	CLI(config mgt)# telnet-timeout set <min></min>			
Use this command to view the telnet time-out of the system.				
CLI(config mgt)# telnet-timeout show				
Parameters	Task			
<min></min>	This specifies the telnet time out of the system			
Type: Mandatory				
Valid values: 1~1440 minutes.				
	Default values: 2 minutes			

Example 2 Display the telnet time-out of the system

CLI(config mgt)# telnet-timeout set 5 OK CLI(config mgt)# telnet-timeout show Telnet time-out : 5 min (5 min)

Managing the Session Login Account

For security reason, the CLI Ex mode provides two groups of user account privileges, "**admin**" group and "**guest**" group. Admin group has read/write access privileges while guest group has only the read privileges.

Table 2-4 shows the system default login account and session information.

Table 2-4	NCT192 Default I	Login Account Index
-----------	------------------	---------------------

Group	Default Account	Login Mode	Session	Session Timeout
-------	-----------------	------------	---------	-----------------

Admin	Username: admin Password: admin	Console, Telnet	Single session occupying on either Console access or Telnet access.	Console: limitless Telnet: 120 Seconds
Guest	Username: guest Password: guest	Console, Telnet	1 session for Console access, up to 12 sessions for Telnet access.	Console: limitless Telnet: 120 Seconds

The user account management performs how to create, delete and change the user password. Enter to the "**config mgt user**" sub-group directory. Table 2-5 shows the commands to perform user account management. Example 3 presents how to generate a new account user and join to the admin group; Example 4 and Example 5 show how to change the user password and delete a user account respectively.

CLI# config mgt user CLI(config mgt user)#

Table 2-5 User Account Management

The following command is to create the account user and its group privileges of console or telnet, while valid user name was defined, the password prompt will appear.

CLI(config mgt user)# add <name> [<user-group>]

The following command is to delete a user login of console or telnet.

CLI(config mgt user)# del <name>

CLI(config mgt user)# show

The following command is to change the user password.

CLI(config mgt user)# set password <name>

The following command is to change the user group privileges.

CLI(config mgt user)# set group <name> [<user-group >]

The following command is to display information of all the users. Password information is not included.

······································	
Parameters	Task
<name></name>	This specifies the user name and password to be created.
	Type: Mandatory
	Valid values: String of up to 16 characters ('A' - 'Z', 'a' - 'z', '0' - '9', '-', '_, ', '@')
<user-group></user-group>	This specifies group privilege of the name user.
	Type: Option
	Default value: guest
	Valid values: admin, guest

Example 3 Create a new user account

```
CLI(config mgt user)# add abc
Enter password (up to 16 characters):
Confirm password:
OK
CLI(config mgt user)# set group abc admin
OK
CLI(config mgt user)# show
management VLAN : 4092
user : guest (guest)
```

user : admin (admin) user : abc (admin)

Example 4 Change the user password

CLI(config mgt user)**# password abc**

Enter new password: Confirm new password:

OK

Example 5 Delete a user account

CLI(config mgt user)# **del abc**

OK

CLI(config mgt user)# **show**

management	VLAN	:	100	
	user	:	guest	(guest)
	user	:	admin	(admin)

Command Syntax and Operating Regulation

This section describes the syntax notation, structure, context-sensitive, command history features, and command syntax help.

Syntax Notation Conventions

CLI Ex command syntax using different bracket form to display syntax notation, Table below lists the notation information.

Table 2-6 Syntax Notation of CLI Ex

Notation	Descriptions
Keyword	Keywords in a command that you must enter exactly as shown.
<parameter></parameter>	Parameter values must be specified.
[<parameter>]</parameter>	Parameter values are optional.
[Parameter 1 Parameter 2 Parameter n]	Parameter values are enclosed in "[] " when you optional use one of the values specified.
{ <i>Parameter 1 Parameter 2 Parameter n</i> }	Parameter values are enclosed in "{ }" when you must use one of the values specified.

Structure of a CLI Command

The CLI Ex commands conform to the following structure in group base. Each group contains sub-group directory or action command that can be used directly with proper syntax.

CLI# {[<Group-A> | <Action-A>] | [<Group-B> | <Action-B>] | [<Group-C> | <Action-C>] | <Action-D>}

or

CLI# [<Group-A> | <Action-A>]

CLI(Group-A)#	[<group-b></group-b>	<pre> <action-b>]</action-b></pre>
CLI(Group-B)#	[<group-c></group-c>	<pre> <action-c>]</action-c></pre>
CLI(Group-C)#	<action-d></action-d>	

The command structure can complete in a single sentence or access into specific group directories.

Table 2-7 Structure of CLI Ex Mode

Keyword	Descriptions
<group-#></group-#>	This is the group directory of a CLI Ex command which contains relative keywords. It indicates the type of group to be performed. " config " is an example of the group directory.
<action-#></action-#>	This is the keyword of a CLI Ex command. It indicates the type of operation to be performed. " ping " is an example of this action keyword.
Command	Descriptions
exit	Jump to the upper group directory.
exit all	Jump to the root directory CLI#
clear	Clear the screen.
Press Enter / Return	Execute the command.

Command Syntax and Context Sensitive Help

Fully utilize the "?" command to assist your task; this command can be used to browse command and to be assisted on the command keywords or arguments.

To get help specific to a command, a keyword, or argument, performs one of these tasks:

Table 2-8 CLI Ex Syntax Help

Command	Task
?	To list all commands available of CLI Ex mode.
Command ?	To list the associated keywords and arguments for a command.
Abbreviated-command-entry <tab></tab>	Complete a partial command or group directory name.

To list the command keywords, enter a question mark "?" to complete the command keywords and arguments. Include a space before the ?. This form of help is called command syntax help.

The CLI Ex mode provides an error announce that appears in which you have entered an incorrect or incomplete command, syntax, keyword, or argument.

If you have entered the correct command but invalid syntax or a wrong keyword parameters, the CLI Ex will automatically prompt the error messages and reprint the commands with cursor indexed on wrong syntax.

Command History and Editing Features

By default, the system records ten command lines in its history buffer. To recall commands from the history buffer, perform one of these commands:

Table 2-9 Command History and Editing

Command	Task
Press the Up arrow key	To recall commands in the history buffer. Beginning with the most recent commands. Repeat the key sequence to recall the older commands.
Press the Down arrow key	To return to more recent commands in the history buffer. Repeat the key sequence to recall the more recent commands.
Press the left arrow key	To move the cursor back one character.
Press the right arrow key	To move the cursor forward one character.
Press Backspace	To erase the character to the left of the cursor.

This CLI Ex mode includes an editing feature. You can move cursor around on the command line to insert or delete the character.



The arrow keys function only on ANSI-compatible terminals such as VT100s.

Ending a Session

If you access using the Telnet session, you can type "**logout**" command to terminate the Telnet session instantly.



Console port will stay in life until you close the terminal session.

This page is leave in blank for note or memo use

Chapter 3 Initialing the NE

This chapter describes how to configure the NCT192 IP-DSLAMs initially, and contains the following sections:

- Port Interface Indication
- Constructing the NE Objects
- Configuring the SNMP Manager
- Configuring the Management Interface
- Maintaining the GE Network Interface
- Maintaining the NE
- Configuring the System Date and Time
- Configuring the Internet Time Server
- Configuring the DNS Server
- Ambient Temperature

Port Interface Indication

The NCT192 IP-DSLAM slot structure is described as follows:

• NCT192: single shelf and five slots, 1 for NC (Network Card) and 4 for xDSL LC (Line Card), each xDSL LC contains 48 ADSL ports or 48 SHDSL ports. Figure 3-1 shows the shelf, slot, and port addressing outward on NCT192.

Figure 3-1 NCT192 Port Addressing Diagram



The CLI described in all chapters applies to the NCT192 IP-DSLAM. The following table lists the valid range of slot and port.

Model Name	Valid range of Network Card	Valid range of Line Card	Range of ADSL/SHDSL port
NCT192	NC1	1~4	1~48

Table 3-1 shows the commands to perform the port interface indication format.

Parameters	Descriptions
<slot-id></slot-id>	Format: slot_#
	Valid values: $\operatorname{slot}_{\#}(1 \sim 4)$
	Default value: slot _# (1)
<port-id></port-id>	Format: [slot_#] . port_#
	Valid values: $slot_{#}(1 \sim 4)$, $port_{#}(1 \sim 48)$
	Default value: slot_# (1)
<slot-range></slot-range>	<pre>Format (Continuously): slot_# - slot_#</pre>
	Format (Individually): slot_#
	Valid values: $\operatorname{slot}_{\#}(1 \sim 4)$
	Default value: slot _# (1)
<port-range></port-range>	Format (Continuously): [slot_#] . port_# - port_#
	Format (Individually): [slot_#] . port_#
	Valid values: slot_# (1 ~ 4), port_# (1 ~ 48)
	Default value: slot_# (1)

Port Interface Indication Format Table 3-1

Through the document, the notations *<slot-id>*, *<port-id>*, *<slot-range>*, and *<port-range>* are used to identify the particular slot/port interface or range of slot/port inside the CLI Ex mode. The <*slot-range>* and *<port-range>* parameters use "-" notation to identify the continuously range.

The form of "slot_#" is for the slot-based CLI command. Example 6 shows the usage of "slot_#" to indicate a specific slot in a slot-based CLI command.

: ADSL

: up

: LLC : tagged-only

: SHDSL

: NCT1901-V3 : 6.5.7_2.4.0

: untagged-only

: disabled

: NCT1901-8169S009034

: 4day / 19hr / 48min / 26sec

Example 6 The usage of "slot_#" to indicate a specific slot in a slot-based CLI command.

CLI# status

CLI(status)# Ic show 4

LC4

current card type planned card type hardware version software version serial number oper status system up time RFC2684 encapsulation tagged mode (configured) tagged mode (run-time) tagged mode (run-time) VLAN tag pass through (configured) : enabled through (configured) : disabled VLAN tag pass through (run-time)

CLI# status

CLI(status)# Ic show 3-4

LC3

current card type	· 4051
	. ////
planned card type	: ADSL
hardware version	: NCT1901-V3
software version	: 6.5.7_2.4.0
serial number	: NCT1901-8169S009033
oper status	: up
system up time	: 4day / 20hr / 6min / 32sec
RFC2684 encapsulation	: LLC
tagged mode (configured)	: untagged-only

tagged mode (run-time) VLAN tag pass through (configured) VLAN tag pass through (run-time)	: untagged-only : disabled : disabled
LC4	
current card type	: ADSL
planned card type	: SHDSL
hardware version	: NCT1901-V3
software version	: 6.5.7_2.4.0
serial number	: NCT1901-8169S009034
oper status	: up
system up time	: 4day / 20hr / 6min / 55sec
RFC2684 encapsulation	: LLC
tagged mode (configured)	: tagged-only
tagged mode (run-time)	: untagged-only
VLAN tag pass through (configured)	: enabled
VLAN tag pass through (run-time)	: disabled

The form of "**slot_#. port_#**" is for the port-based CLI command. If **slot_#** is not specified, CLI_Ex will apply the default value (slot 1) automatically to the syntax. Example 7shows the usage of "**slot_#. port_#**" to indicate a specific port in a port-based CLI command. It is noted that Example 7 also depicts the CLI commands with different forms of port index which indicates the same port (slot 1, port 6).

Example 7 CLI commands to show the physical status of (slot 1 . port6)

CLI # status port show 6			
Port: 1.6	onablod		
oper status	un		
power state	10		
line standard	· C 00	12 5 Ann	ov A
	. 0.93	2.J AIII	en A
[physical status]			
item	US	DS	
attainable rate	1343	30644	kbps
attenuation	0.0	0.0	dB
SNR margin	6.5	8.5	dB
output power	12.1	12.6	dBm
[chappa] status]			
[Channer Status] item	US	DS	
Tx rate	1342	29204	kbps
interleave delay	0	0	ms
CRC block length	39	255	ms
INP symbol time	0.00	0.00	DMT symbol
CLI# status port show 1.6			
Port: 1.6	anablad		
admini status .			
power state	up LO		
ling standard	· c 00	12 5 Ann	ox A
Time Stanuaru	. 0.99	2.5 ANN	ex A
[physical status]			
item	US	DS	
attainable rate	1343	30649	kbps
attenuation	0.0	0.0	dB
SNR margin	6.6	8.5	dB
output power	12.1	12.6	dBm
[channel_status]			
item	US	DS	

	Tx rate	1342	29204	khns
	interleave delay	0	0	me
	CDC block longth	20	255	mo
	UND symbol time	0.00	200	IIIS DMT sumbal
	INP SYMDOI TIME	0.00	0.00	DMI SYMDOI
CLI(stat	us)# port show 1.0	6-25		
Port · 1	6			
admi	n status ·	anablad		
aum	in Status .	un		
oper	status .	up LO		
powe	standard .		2 E Ann	ov 1
11116	stanuaru	. 0.99	2.0 AIII	ex A
[phy	sical status] item	US	DS	
	attainable rate	1343	30644	kbps
	attenuation	0.0	0.0	dB
	SNR margin	6.5	8.5	dB
	output power	12.1	12.6	dBm
[cha	innel status]			
	item	US	DS	
		1040	20204	lub a s
	IX rate	1342	29204	KDDS
	Interleave delay	0	0	ms
	CRC block length	39	255	ms
	INP symbol time	0.00	0.00	DMT symbol
Dorte 1	01			
P011: 1.		anahlad		
admi	n status :	enabied		
oper	status :	down		
Port: 1.	23			
admi	n status :	enabled		
oper	status ·	un		
nowe	er state :	10		
line	standard	· G. 99	2.5 Ann	ex A
1110	o o tandar a		2.0 /	
[phy	'sical status]			
	item	US	DS	
	attainable rate	1343	30649	kbps
	attenuation	0.0	0.0	dB
	SNR margin	6.4	8.5	dB
	output power	12.1	12.6	dBm
	The period			
[cha	innel status]			
	item	US	DS	
	Tx rate	1351	29204	kbps
	interleave delay	0	0	ms
	CRC block length	39	255	ms
	INP symbol time	0.00	0.00	DMT symbol

Constructing the NE Objects

The NCT192 IP-DSLAM provides the flexibility to be equipped with various card modules such as ADSL-LC and SHDSL-LC. Constructing the NE board type of card module is the first task you need to perform.

Once the equipped card modules to the NCT192 IP-DSLAM are determined, you need to set the

planned type according to their correspondent slot to secure the system operation. For any reason (removed or type error); if the planned type is not the same as the online type detected from the system, the board mismatch alarm message will be reported.

Planning the System Card Type

Enter to the "config nc" sub-group directory to plan the NC (Network Control) card.

CLI**# config nc** CLI(config nc)#

Enter to the "config lc" sub-group directory to plan the LC (Line Card) card.

CLI# config lc CLI(config lc)#

Table 3-2 shows the CLI commands to configure the planned-type of LC/NC in the NE. Example 8~ Example 9 shows the usage of these commands as well as their related parameters.

Table 3-2 Planning the system card type

The following command is to modify the planning NC card type.

CLI(config nc)# set planned-type *<nc-id>* {*none | cpu*}

The following command is to modify the planning LC card type.

CLI(config lc)# set planned-type < *lc-range*> <card-*type*>

Parameters	Task
<nc-id></nc-id>	Identify the slot range of the NC card Type: Mandatory Valid values: 1 ~ 2 (value = 2 does not apply to NCT192)
{none / cpu}	Identify the NC type.
<lc-range></lc-range>	Identify the slot range of the Line card. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<card-type></card-type>	Identify the line card type Valid values: none, adsl, shdsl

Example 8 CLI commands to modify the planning NC card type

```
CLI# config nc
CLI(config nc)# set planned-type 1 cpu
0K
CLI(config nc)# show
NC:
  planned-type current-type tagged-mode
         CPU
                  CPU untagged-only
UGE:
  UGE oper-status admin-status auto negotiation use-mode
   -----
      1
           down enabled enabled uplink
           down disabled enabled uplink
    2
Subtend VLAN ID:
```

n/a

Example 9 CLI commands shows how to modify the planning LC card type

CLI# config Ic CLI(config Ic)# set planned-type 1.1 ads1

LC 1. 1: OK

CLI(config Ic)# show

	planned	current	rfc2684	vlan-tag	service	configured
LC	type	type	encap	pass	type	tagged-mode
1	ADSL	ADSL	LLC	disabled	disabled	untagged-only
2	SHDSL	n/p	LLC	disabled	disabled	untagged-only
3	SHDSL	ADSL	LLC	disabled	disabled	untagged-only
4	SHDSL	n/p	LLC	enabled	disabled	tagged-only

```
CLI(config 1c)# set planned-type 3-4 ads1
LC 1. 3: OK
LC 1. 4: OK
```

CLI(config Ic)# **show**

LC	planned type	current type	rfc2684 encap	vlan-tag pass	service type	configured tagged-mode
1	ADSL	ADSL	LLC	disabled	disabled	untagged-only
2	SHDSL	n/p	LLC	disabled	disabled	untagged-only
3	ADSL	ADSL	LLC	disabled	disabled	untagged-only
4	ADSL	n/p	LLC	enabled	disabled	tagged-only

Verifying Current Software and Hardware Versions

Follow the commands to display the inventory information of NE software/ hardware version, card serial number, card type etc.

Use the "**nc show**" or "**lc show**" command under the "**status**" group directory to display the system H/W and S/W version of each plug-in card module and slot planning type.

Enter to the "status" group directory to verify the software and hardware versions.

CLI**# status** CLI(status)#

Table 3-3 shows the commands to retrieve the NC board-level information. Example 10 shows the usage of these commands.

Table 3-3 Retrieve the software and hardware information of NC card

The following command is to display the version and plugging status of NC card.

CLI(status)# nc show

Example 10 Monitoring the NC board-level information

CLI(status)# nc show

NC

current card type	: CPU Module
planned card type	: CPU Module
role	: active
hardware version	: NCT1902-V5
software version	: 1.0v2.0.2@R134
serial number	: NCT1902-8169S008952

oper status : up system up time : 2day / Ohr / 23min / 14sec tagged mode : untagged-only

Table 3-4 shows the commands to retrieve the LC board-level information. 0 shows the usage of these commands.

Table 3-4 Software and Firmware Verify of LC on-board card

The following command is to display the LC card version and plugging status.			
CLI(status)# lc show [<lc-range>]</lc-range>			
Parameters	Task		
<lc-range></lc-range>	Identify the slot range of the Line card. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.		

Example 11 Monitoring the LC board-level information

CLI(status)# ic show

LC1

current card type	: ADSL
planned card type	: SHDSL
hardware version	: NCT1901-V3
software version	: 6.5.7_2.4.0
serial number	: NCT1901-8169S009031
oper status	: up
system up time	: Oday / 16hr / 5min / 44sec
RFC2684 encapsulation	: LLC
tagged mode (configured)	: untagged-only
tagged mode (run-time)	: untagged-only
VLAN tag pass through (configured)	: disabled
VLAN tag pass through (configured)	: disabled
VLAN tag pass through (run-time)	: disabled



NC tagged mode = Tagged LC tagged mode Run-Time Status = Tagged LC VTP Run-Time Status = Enabled

NOTE

NOTE

The tagged mode (run-time) indicates the operational status of tagged mode. Tagged-only: LC (or NC) only forwards the tagged Ethernet frame and drops the untagged Ethernet frame.

Untagged-only: LC (or NC) only forwards the untagged Ethernet frame and drops the tagged Ethernet frame.

It is noted that the value of configured Tagged mode and its Run-Time Status may be different. Please refer to Table 6-9 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.

Configuring the System Information

The system information contains system name, location, and person contact information as defined in RFC1213.

Enter to the "config sys-info" sub-group directory to configure the system information.

CLI# config sys-info CLI(config sys-info)#

Table 3-5 shows the commands to perform the configuration of system information. Example 12

•

shows the usage of these commands as well as their related parameters.

Table 3-5 System Information Configuration

Use this command to modify the system location.

CLI(config sys-info)# set location <string>

Use this command to modify the system contact information.

CLI(config sys-info)# set contact <string>

Use this command to modify the system name.

CLI config (sys-info)# set name <string>

• • • • • •

Use this command to monitor the system information.

CLI(config sys-info)# snow	
Parameters	Task
<string></string>	This specifies the textual identification of the information on the given field
0	Type: Mandatory
	Valid values: String of up to 255 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '.', '@').

Example 12 Modifying the name of system information

```
CLI(config sys-info)# set location Sydney
OK
CLI(config sys-info)# set contact NetCommLimited@02-94242000
OK
CLI(config sys-info)# set name NCT192_IP_DSLAM
OK
CLI(config sys-info)# show
System Name : NCT192_IP_DSLAM
System Contact : NetCommLimited@02-94242000
System Description : IP-DSLAM
```

: 2 min (2 min)

System Location : Sydney

Configuring the SNMP Manager

Telnet time-out

SNMP (Simple Network Management Protocol) is an application-layer protocol designed to facilitate the exchange of management information between network devices. By using SNMP, network administrators can more easily manage network performance, find and solve network problems, and plan for network growth.

In NCT192 IP-DSLAM, we use SNMP to exchange management information between a NE and LCT (or NCT192 server). SNMP enables the administrators to manage the NE by the LCT (or NCT192 server). In the term of SNMP, the NE plays the role of SNMP agent and the LCT (or NCT192 server) serves as the SNMP server. This section describes how to configure the SNMP on the NE.



Beware of the SNMP community setting, this will affect the communication between the NCT192 LCT (or NCT192 server) and NE, you must re-login the NCT192 LCT if the SNMP community has been modified.

Configuring the SNMP Community

The SNMP community is a string representing the password to access the MIB of NE with the associated privilege. The NE supports two levels of privilege (Permission) as follows:

- Read / Write / Create Allow the SNMP server to read and write all objects in the MIB, as well as the community strings.
- Read-only Only allow the SNMP server to read all objects in the MIB except the community strings.

NOTE

The community string definitions on your NCT192 LCT (or NCT192 Server) must match at least one of those community string definitions on the NE. Otherwise, the LCT (or NCT192 Server) is not allowed to access the NE.

The SNMP Community setting allows you to assign the community privilege levels. Two privilege levels are supported, read-only and read-write.

Enter to the "config mgt snmp" sub-group directory to configure the SNMP community.

CLI**# config mgt snmp** CLI(config mgt snmp)**#**

Table 3-6 shows the commands to perform the setting of SNMP community. Example 13 shows the usage of these commands as well as their related parameters.

Table 3-6 SNMP Community Setting

The following command is to create new SNMP community information. It is noted that the system supports at most 8 community settings.

CLI(config mgt snmp)# add community <*community-name*> {*rw* / *ro*}

The following command is to delete the SNMP community information.

CLI(config mgt snmp)# del community <community-name>

The following command is to monitor the status of SNMP community sets (Community Table).

CLI(config mgt snmp)# show community <option>

Parameters	Task
< community-name >	This specifies the community name Type: Mandatory Valid values: String of up to 20 characters ('0'~'9', 'A'~'Z', 'a'~'Z', 'a'~'Z', '.', '@').
<option></option>	This specifies the community types Type: Mandatory Valid values: community trapstation
{ <i>rw</i> / <i>ro</i> }	This specifies the access permissions given by managers with this community name. 'ro' implies read only permission and 'rw' implies read-write permission. Type: Mandatory

Example 13 Add a new SNMP community to the system

CLI(config mgt snmp)**# add community xxx ro** OK

CLI(config mgt snmp)# show

Community Table: Community Permission

> "public" read-only "netman" read-write

"xxx" read-only

Trap Station Table: No entry

Configuring the IP Address of SNMP Trap Station

SNMP Trap Manager records the hosts (any SNMP server, like LCT, NCT192 Server, and so on) to be notified whenever the NE encounters abnormalities. When a trap condition happens, the NE sends the corresponding SNMP trap message to the hosts (SNMP server).

Enter to the "config mgt snmp" sub-group directory to configure the Trap station.

CLI# config mgt snmp CLI(config mgt snmp)#

Table 3-7 shows the commands to perform the setting of SNMP Trap Station. Example 14 shows the usage of these commands as well as their related parameters.

Table 3-7 SNMP Trap Station Setting

The following command is to create a new trap station, system allows of 8 trap stations in maximum.

CLI(config mgt snmp)# add trapstation <ip-addr> <community-name>

The following command is to delete the trap station information.

CLI(config mgt snmp)# del trapstation <ip-addr>

The following command is to monitor the status of trap stations (Trap Station Table).

CLI(config mgt snmp)# show <option></option>
--

Parameters	Task
<ip-addr></ip-addr>	This indicates the IP address (Server / Host IP) of SNMP Manager. Type: Mandatory
<community-name></community-name>	This specifies the SNMP trap community of NE (Send Trap). Type: Mandatory
<option></option>	This specifies the community types Type: Mandatory Valid values: community trapstation

Example 14 Add a new Trap station

CLI(config mgt snmp)# add trapstation 192.168.1.1 public $\ensuremath{\mathsf{OK}}$

CLI(config mgt snmp)#	show trapstation	า
Trap Station Table:	A	
IP Address	Community	Version
192.168.1.1	"public"	v2c

Configuring the Management Interface

NCT192 provides 2 kinds of management interfaces on the NC (Network Control) card:

• Network management Ethernet interface (nme) The nme is an out-of-band management Ethernet port on the NC card. Packets received on this interface will never reach the switching fabric. Instead, packets are transported between the CPU and the nme port directly.

• Uplink network interface (uge)

The uge, an in-band management interface connects to the switching fabric, presents the uplink gigabit Ethernet port that has ability to join the VLAN membership. Packets received on this interface are transported to the CPU via switching fabric and vice versa.

This section depicts the CLI commands to configure the IP address of nme and uge ports.

Enter to the "config ip" sub-group directory to configure the management interface IP address.

CLI**# config ip** CLI(config ip)#

Enter to the "**config mgt**" sub-group directory to configure the VLAN-ID associated with the uge in-band interface.

CLI# config mgt CLI(config mgt)#

Table 3-8 shows the commands to perform the management interface setting of IP address. Example 15 and Example 16 shows the usage of these commands as well as their related parameters.

Table 3-8 Management Interface IP Address Setting

The following command is to assign the IP address and subnet mask for management Ethernet interface (nme).

CLI(config ip)# set nme <ip-addr> <netmask> <gatewayip>

The following command is to assign the IP address and subnet mask for uplink Network interface (uge).

CLI(config ip)# set uge <*ip-addr*> <*netmask*> <*gatewayip*>

The following command is to assign the default gateway. The NCT192 IP-DSLAM sends all off-network IP traffic to the default gateway.

CLI(config ip)# set gateway <ip-addr>

The following command is to monitor the management interface information.

CLI(config ip)# show

The following command is to identify the VLAN ID for in-band management traffic.

CLI(config mgt)# vlan-id set <vid>

The following command is to view the VLAN ID for in-band management traffic.

CLI(config mgt)# vlan-id show

Parameters	Task
<ip-addr></ip-addr>	This specifies the network IP address for nme and uge interface, this IP address is only for system management. Type: Mandatory Valid values: Any valid class A/B/C address Default value: None
<gatewayip></gatewayip>	This specifies the gateway IP address for system, this gateway IP address is only for system management. Type: Mandatory Valid values: Any valid class A/B/C address
<netmask></netmask>	This specifies the subnet mask configured for the interface. Type: Mandatory Valid values: 255.0.0.0 ~ 255.255.255.255
<vid></vid>	Assign the in-band interface to the proper VLAN (Making sure the VLAN will be associated with the network to which the IP address belongs). Type: Mandatory Valid values: 1 ~ 4094

Example 15 Assign the IP address and subnet mask for nme

```
CLI(config ip)# set nme 192.168.192.1 255.255.0.0 100.168.1.254
OK
```

Example 16 Assign the IP address and subnet mask for uge

CL OK	l(config ip)#	set uge	100. 168. 1. 31	255.255.0.0	100. 168. 1. 254
CL	l(config ip)#	show			
UG	E IP address subnet mask MAC address UGE VLAN ID	: 100 : 255 : 00 : 409	D. 168.1.31 5.255.0.0 :60:64:dc:7a: 92	17	
NM	E IP address subnet mask MAC address	: 192 : 255 : 001	2.168.192.1 5.255.0.0 :60:64:dc:7a:	16	
Ga	teway IP address	: 100). 168. 1. 254		

Setting the Management Ethernet (NME) Interface IP Address

Before accessing telnet session to the NCT192 IP-DSLAM or SNMP, you must assign an IP address to either the in-band (uge) interface or the management Ethernet (nme) interface.

You can specify the subnet mask (netmask) in dotted decimal format.

To set the management Ethernet (nme) interface IP address, perform these procedures in CLI Ex mode:

Step 1 Assign an IP address and subnet mask to the management Ethernet (nme) interface.

Step 2 Verify the default gateway, if necessary.

Example 17 depicts the CLI commands with how to assign an IP address and subnet mask to the management Ethernet (nme) interface and how to verify the interface configuration.

Example 17 Setup the out-of-band management interface

```
CLI(config ip)# set nme 172.16.1.1 255.255.0.0 172.16.1.254
OK
CLI(config ip)# show
UGE
   IP address
                : 100.168.3.97
   subnet mask : 255.255.0.0
   MAC address : 00:60:64:dc:7a:17
   UGE VLAN ID : 4092
NME
   IP address
                : 172.16.1.1
   subnet mask : 255.255.0.0
   MAC address : 00:60:64:dc:7a:16
Gateway
   IP address
                : 172.16.1.254
```

Setting the in-band Interface (UGE) IP Address

Before accessing telnet session to the NCT192 IP-DSLAM or SNMP, you must assign an IP address to either the in-band (uge) interface or the management Ethernet (nme) interface.

You can specify the subnet mask (netmask) in dotted decimal format.

To set the IP address and VLAN membership of the in-band (uge) management interface, you can perform the following procedures in CLI Ex mode:

- **Step 1** Assign an IP address and subnet mask to the in-band (uge) management interface.
- **Step 2** Verify the default gateway, if necessary.

Step 3 Assign the in-band interface to the proper VLAN.

The Example 18 and Example 19 depict the CLI commands with how to assign an IP address, specify the subnet mask, and assign the VLAN for the in-band (uge) interface.

Example 18 Setup the in-band management interface

CLI(config ip)# set uge 192.168.100.1 255.255.255.0 192.168.100.254 OK CLI(config ip)# show UGE IP address : 192.168.100.1 : 255.255.255.0 subnet mask MAC address : 00:60:64:dc:7a:17 : 4092 UGE VLAN ID NME IP address : 192.168.192.1 : 255.255.248.0 subnet mask MAC address : 00:60:64:dc:7a:16 Gateway IP address : 192.168.100.254 CLI(config ip)# exit

Example 19 Assign the in-band interface to the proper VLAN

CLI# config mgt CLI(mgt)# set vlan 10 OK CLI(mgt)# show management VLAN : 10 user : guest (guest) user : admin (admin) user : abc (admin)

Configuring the Default Gateway

A gateway is a node that serves as an entrance to another network, and vice-versa. Gateways are most commonly used to transfer data between private networks and the Internet.

The NCT192 IP-DSLAM sends IP packets destined for other IP subnets to the default gateway (typically a router interface in the same network or subnet as the switch IP address). The NCT192 IP-DSLAM does not use the IP routing table to forward traffic from connected devices, IP traffic only generated by the NCT192 IP-DSLAM itself (for example: Telnet, TFTP, and ping).

The switch sends all off-network IP traffic to the primary default gateway. Both the in-band (uge) and management Ethernet (nme) interfaces are specified with common default gateway, the system forward traffic automatically determines through which interface of the default gateway can be reached.

Configuring the Secured Host

The security host mechanism protects the NCT192 IP-DSLAM against unauthorized access from untrustful host. This feature allows you to specify up to 10 sections of IPs of trusted hosts and authorized services (e.g. SNMP, TELNET, and FTP)

Enter to the "config secure" sub-group directory to configure the secured host IP address.

CLI# config secure CLI(config secure)#

Enter the "enable" CLI command in sub-group directory to enable the secured host.

CLI(config secure)# enable

OK

Table 3-9 shows the commands to perform the configuration of secured host. Example 20 and Example 21 shows the usage of these commands as well as their related parameters.

Table 3-9 Secured Host Configuration

The following command is to specify the secured host with all permission services.

CLI(config secure)# allow <index> all

The following command is to specify the secured host without any permission service.

CLI(config secure)# allow <index> none

The following command is to specify the secured host in a specifics service.

CLI(config secure)# allow <index> <snmp,telnet,ftp,tftp>

The following command is to enable the secured host feature.

CLI(config secure)# enable

The following command is to disable the secured host feature.

CLI(config secure)# disable

The following command is to specify the secured host IP range.

CLI(config secure)# set <index> <from-ip> [<to-ip>]

The following command is to display the information of secured host.

CLI(config secure)# show [<index>]

Parameters	Task
<index></index>	This specifies the entry number of secured host list. Valid values: $1 \sim 10$
<snmp,telnet,ftp,tftp></snmp,telnet,ftp,tftp>	This indicates the services (any combination of SNMP, TELNET, FTP and TFTP) the specified secured hosts are allowed. Valid values: snmp, telnet, ftp, tftp
<from-ip></from-ip>	This indicates the beginning of the IP address range of the secured hosts. Valid values: $0.0.0.0 \sim 255.255.255.255$
<to-ip></to-ip>	This indicates the end of the IP address range of the secured hosts. Valid values: $0.0.0.0 \sim 255.255.255.255$

Example 20 Set the secured host IP range

CLI(config secure)**# set 2 192.168.192.1 192.168.192.255** OK

CLI(config secure)# **show**

Secured host configuration:

Admin Status: enabled index from IP

to IP	allowed type

ТΡ
one
one
one
all
one

Example 21 Allow the secured host with the permission services

CLI(config secure)**# allow 2 all** OK

CLI(config secure)# **show**

Secured host configuration: Admin Status: enabled

		is: enabled	in Stati
allowed type	to IP	from IP	index
SNMP + telnet + FTP	255.255.255.255	0.0.0.0	1
all	192.168.192.255	192.168.192.1	2
none	0.0.0.0	0.0.0.0	3
none	0.0.0.0	0.0.0.0	4
all	0.0.0.0	0.0.0.0	5
none	0.0.0.0	0.0.0.0	6
none	0.0.0.0	0.0.0.0	7
none	0.0.0.0	0.0.0.0	8
none	0.0.0.0	0.0.0.0	9
none	0.0.0.0	0.0.0.0	10

Maintaining the GE Network Interface

Configuring the UGE Negotiation Mode

The NE supports auto-negotiable uge Ethernet port. Enter to the "**config nc**" sub-group directory to configure the UGE Negotiation Mode.

CLI**# config nc** CLI(config nc)**#**

Table 3-10 shows the commands to perform the configuration of the UGE Negotiation Mode. Example 22 shows the usage of these commands as well as its related parameters.

Table 3-10 Configuring the UGE Negotiation Mode

The following command is to mourly the OOL negotiation mode.			
CLI(config nc)# set autoneg <uge-id> {off / on}</uge-id>			
Parameters	Task		
$\{off \mid on\}$	Identify the auto negotiation mode of specified UGE port. Type: Mandatory Valid values: off on		
<uge-id></uge-id>	Identify the slot range of the UGE port Type: Mandatory Valid values: 1 ~ 2		

The following command is to modify the UGE negotiation mode.

Example 22 The modification of the UGE negotiation mode

```
CLI(config nc)# set autoneg 1 enabled
OK
CLI(config nc)# show
NC:
   planned-type current-type tagged-mode
                         -----
            CPU
                         CPU untagged-only
UGE:
   UGE oper-status admin-status auto negotiation use-mode
     1
               down
                          enabled
                                           enabled
                                                   uplink
     2
               down
                        disabled
                                           enabled uplink
Subtend VLAN ID:
   n/a
```

Checking the SFP module information

NCT192 IP-DSLAM supports 2 SFP (Small Form Pluggable) Mini-GBIC modules on the NC.

Enter to the "status" group directory to verify the SFP module information.

Use the "gbic show" command under the "status" group directory to display the SFP information.

CLI**# status** CLI(status)#

Table 3-11 shows the commands to perform the check of the SFP module information. Example 23 shows the usage of these commands as well as its related parameters.

Table 3-11 Checking the SFP module information

Using this command to display the system plugged SFP mini GBIC module.		
CLI(status)# gbic show <uge-id></uge-id>		
Parameters	Task	
<uge-id></uge-id>	This specifies the index of UGE.	
-	Type: Mandatory	
	Valid values: 1 2	

Example 23 Display the system plugged SFP mini GBIC module

CLI(status)# gbic show 2

identifier	:	SFP
connector	:	LC
SONET compliance codes	:	
ethernet compliance codes	:	1000BASE-LX
fiber channel link length	:	long distance (L)
fiber channel transmitter tech	:	longwave laser (LC)
fiber channel transmitter media	:	single mode (SM)
fiber channel speed	:	100 MBytes/Sec
encoding	:	8B10B
BR,nominal - 100Mbps	:	13
length(9um) - km	:	10
length(9um) - 100m	:	100
length(50um) - 10m	:	55
length(62.5um)- 10m	:	55
length(Copper)- 1m	:	0
vendor name	:	
vendor OUI	:	00:00:00
vendor PN	:	SFP-LX
vendor SN	:	3119980079
laser wave length	:	1310 nm

Maintaining the NE

The NE supports the storing, backup/restore configuration and firmware upgrade functions as described in the following sub-sections.

- Storing the Active System Configuration
- Backup and Restore the Active System Configuration
- File System Management
- Managing the Boot Section
- NE Firmware Upgrade
- NE Firmware Upgrade in Cascade mode
- SHDSL Firmware Upgrade

Storing the Active System Configuration

The modified configuration will be lost due to the rebooting of hardware without saving (storing). Use "**save**" command under "**config file**" sub-group directory to save your active configuration in system flash, NCT192 IP-DSLAM will load the saved configurations and execute them whenever the system reboots.

Enter to the "config file" sub-group directory to operate.

CLI**# config file** CLI(config file)#

Table 3-12 Store the Active System Configuration

The following command is to save current configuration and backup old configuration.
CLI(config file)# save

The following command is to remove all saved configuration files.

CLI(config file)# erase

The following command is to show configuration information.

CLI(config file)# ls

Saving system configurations takes about 15 seconds to finish.

Example 24 Save the system configuration

CLI(config file)# save OK CLI(config file)# is Listing directory [cfg:] Nov 19 2007 18:14 37 mac.cfg Oct 10 2000 12:58 146150 default.cfg Nov 30 2007 20:43 32 default.md5 Oct 11 2000 13:38 146993 config.cfg Oct 11 2000 13:38 32 config.md5

Backup and Restore the Active System Configuration

NE provides the backup and restore related CLI commands to backup or restore the NE configuration via FTP. The backup procedures are as following:

- Step 1 Open the DOS prompt window (or environment) on personal computer (PC).
- Step 2 Go to the directory where the backup file is saved and then login the NCT192 by FTP
- **Step 3** Get the configuration file from NE to the target partition via FTP by following commands:
 - ftp> cd cfg: ftp> get default.cfg or ftp> put default.cfg



It is noted that login device via FTP must be used the read-write authorization. The default username/password is **admin/admin**.



It is noted that the NE configuration is saved in "default.cfg" on the NE. The operator can backup the "default.cfg" and save it with a different filename on the local host. However, the operator has to restore (by the ftp "put" command) the NE configuration with filename of "default.cfg".

Example 25 and Example 26 show the process to backup the configurations and restore the configurations, respectively.

Example 25 Backup the configurations from the NE via FTP.

1. 2. D:\>ftp 192.168.192.1 3. Connected to 192.168.192.1. 4. 220------5. 220-Welcome to the IP-DSLAM FTP Server 6. 220-7. 220- CAUTION: It's your responsibility to use the FTP service correctly -8. 220- , please put the right files into the right file system. -10. User (192.168.192.1:(none)): admin 11. 331 Password required 12. Password: 13. 230 User logged in 14. ftp> cd cfg: 15. 250 Changed directory to "cfg:/" 16. ftp> get default.cfg D:\DSLAM-TPE-4.txt 17. 200 Port set okay 18. 150 Opening BINARY mode data connection 19. 226 Transfer complete ftp: 152231 bytes received in 0.45Seconds 335.31Kbytes/sec. 20. 21. ftp> **bye** 22. 221 Bye...see you later 23. D:\> 24. Restore the configurations to the NE via FTP. 25. 26. D:\>ftp 192.168.192.1 27. Connected to 192.168.192.1. 28. 29. 220-Welcome to the IP-DSLAM FTP Server 30. 220-31. 220- CAUTION: It's your responsibility to use the FTP service correctly -32. 220- , please put the right files into the right file system. -33. 220 ------

```
34. User (192.168.192.1:(none)): admin
```

- 35. 331 Password required
- 36. Password:
- 37. 230 User logged in
- 38. ftp> cd cfg:
- 39. 250 Changed directory to "cfg:/"
- 40. ftp> put DSLAM-TPE-4.cfg default.cfg
- 41. 200 Port set okay
- 42. 150 Opening BINARY mode data connection
- 43. 226- CAUTION: Please wait for 120 seconds -
- 44. 226 Transfer complete
- 45. ftp: 152231 bytes sent in 0.80Seconds 191.01Kbytes/sec.
- 46. ftp> **bye**
- 47. 221 Bye...see you later

File System Management

This section depicts the CLI commands for the maintenance of file system in the on-board flash.

Enter the "filesystem" in sub-group directory to operate.

CLI**# filesystem** CLI(filesystem)#

Example 26

The following command is to de	lete a file.
CLI(filesystem)# del { <i>opC</i>	odeA opCodeB cfg} <filename></filename>
The following command is to lis	t files inside file system partition.
CLI(filesystem)# ls [opCod	$leA \mid opCodeB \mid cfg]$
Parameters	Task
$\{opCodeA \mid opCodeB \mid cfg\}$	This specifies the partition of NC on-board flash. <i>opCodeA/opCodeB</i> : the partition to store the NE firmware and LC firmware. <i>cfg</i> : the partition to store the configuration file.
<filename></filename>	This specifies the file name of file to be stored in the partition of NC on-board flash. Type: Mandatory Valid values: nct192. enc nct1901fw. enc nct1901br. enc config. cfg config. md5

Table 3-13 File System Configuration

Example 27 Configuration of file system in NE

CLI# filesystem ls Listing directory [opCo	deA:]		
D D D	ec 18 2007 10:23 ec 18 2007 15:55 ec 18 2007 15:55	2679217 457808 32892	nct192.enc nct1901fw.enc nct1901br.enc
Listing directory [opCo D D D	deB:] ec 15 2007 10:21 ec 15 2007 13:25 ec 15 2007 13:25	2679217 457808 32892	nct192.enc nct1901fw.enc nct1901br.enc
Listing directory [cfg: N N N O O O] iov 19 2007 18:14 iov 30 2007 20:43 iov 30 2007 20:43 iot 15 2000 09:30 iot 15 2000 09:30	37 146150 32 146689 32	mac.cfg default.cfg default.md5 config.cfg config.md5

CLI# filesystem del cfg default.cfg

ERROR: Can't delete default configuration file.



It is noted that the follwing files can not be deleted via CLI/LCT. default.cfg default.md5 mac.cfg

Two kinds of .cfg files, config.cfg and default.cfg, are kept in the NE for the NE to boot up with a set of deterministic configuration parameters. In order to guarantee these .cfg files are not corrupted, the NE also protect them by MD5 encryption.
Whenever the NE boots up, it executes the following procedure.
1. The NE first reads and checks config.cfg and try to rebuild the previous configuration accordingly.
2. If the config.cfg is absent or is corrupted, the NE will read and check default.cfg and try to rebuild the default configuration accordingly.
3. If the default.cfg is absent or is corrupted, the NE will use its internal setting to rebuild the factory-default configuration accordingly

Managing the Boot Section

The NE supports two boot sections 'opCodeA' and 'opCodeB', each contains the necessary firmware for the system. With 2 boot sections, the original NE firmware can be kept as it is. As a result, the operator is able to recover the NE whenever it fails to upgrade NE firmware due to any reason (ex. the upgraded firmware is corrupted due to network failure.)

To this end, it is recommened the operator to upload the new firmware to the 'opCodeA' if the current boot partition is 'opCodeB'.

Please refer to Section "NE Firmware Upgrade" of Chapter 3 for the example of their usage.

Use the command "boot-device" to manage the boot section of the system.

CLI# boot-device

Table 3-14 Managing the Boot Section

The following command is to identify the startup boot section.

CLI# boot-device set {opCodeA | opCodeB}

The following command is to display the current boot device and firmware file.

CLI# boot-device show

NE Firmware Upgrade

NE provides NC/ADSL LC Firmware Upgrade related commands to load the new firmware to the NC on-board flash (non-violent memory) by FTP. The firmware upgrade procedures are as follows.

Step 1 Check the current boot partition via the CLI command:.

CLI# boot-device show current boot device : opCodeB:xxxxx.enc next boot device : opCodeB:xxxxx.enc

- **Step 2** Open the DOS prompt window (or environment) on personal computer (PC).
- Step 3 Go to the directory where the new firmware is saved, and then login the NCT192 by FTP
- **Step 4** Upload the new firmware to the target partition via FTP by the following commands. Example 28 shows an example of uploading firmware to NE.

ftp> cd opCodeB: (or ftp> cd opCodeA:) ftp> bin ftp> put xxxxx.enc

Step 5 Change the next boot partition to let the NE be rebooted by executing the new image (Refers to Table 3-14 Managing the Boot Section)

CLI# boot-device set opCodeA CLI# boot-device show current boot device : opCodeB:xxxxx.enc next boot device : opCodeA:xxxxx.enc



It is noted that login device via FTP must be used the read-write authorization. The default username/password is **admin/admin**.

Example 28 Upload NC/ADSL LC Firmware to Flash Memory of NC through FTP

Upgrade nct192.enc (image file of NC)

root@redhat9:/tmp> ftp 192.168.192.1 Connected to 192.168.192.1 (192.168.192.1).

Name (192.168.192.1:axdsl): admin 331 Password required Password: 230 User logged in ftp> cd opCodeA: 250 Changed directory to "opCodeA:" ftp> bin 200 Type set to I, binary mode ftp> put nct192.enc 200 Port set okay 150 Opening BINARY mode data connection 226- CAUTION: Please wait for 120 seconds or check the Flash LED -226 Transfer complete ftp: 3126797 bytes sent in 6.91Seconds 452.70Kbytes/sec. ftp> bye 221 Bye...see you later Upgrade nct1901fw.enc (DSP code of LC)

root@redhat9:/tmp> ftp 192.168.192.1 Connected to 192.168.192.1 (192.168.192.1).

Name (192.168.192.1:axdsl): admin 331 Password required Password: 230 User logged in ftp> cd opCodeA: 250 Changed directory to "opCodeA:" ftp> bin 200 Type set to I, binary mode $f\,tp>$ put nct1901fw.enc 200 Port set okay 150 Opening BINARY mode data connection 226- CAUTION:Please wait for 120 seconds or check the Flash LED -226 Transfer complete ftp: 457808 bytes sent in 1.03Seconds 444.04Kbytes/sec ftp> **bye** 221 Bye...see you later Upgrade nct1901br.enc (Booter of LC)

root@redhat9:/tmp> ftp 192.168.192.1 Connected to 192.168.192.1 (192.168.192.1).

Name (192.168.192.1:axdsl): admin 331 Password required Password: 230 User logged in ftp> cd opCodeA: 250 Changed directory to "opCodeA:" ftp> bin 200 Type set to I, binary mode ftp> put nct1901br.enc 200 Port set okay 150 Opening BINARY mode data connection 226- CAUTION:Please wait for 120 seconds or check the Flash LED -226 Transfer complete ftp: 32892 bytes sent in 0.11Seconds 299.02Kbytes/sec ftp> bye 221 Bye...see you later


Make sure the source image file that you select is accordant to the NE model; else the NE may not run well with the upgraded firmware image after rebooting.

NE Firmware Upgrade in Cascade mode

NE provides NC/ADSL LC Firmware Upgrade related commands to load the new firmware to the NC on-board flash (non-violent memory) by FTP. The Remote-NE firmware upgrade procedures are as follows.

Step 1 "Clogin" to check the current boot partition of Remote-NE via the CLI command:.

```
CLI# clogin 1
           CLI#
                  Please type "@.<cr>" to locally close connection
           Login:admin
           Password:
           CLI# boot-device show
           current boot device
                                 : opCodeB:xxxxx.enc
           next boot device
                                  : opCodeB:xxxxx.enc
Step 2
           Open the DOS prompt window (or environment) on personal computer (PC).
           Go to the directory where the new firmware is saved, and then login the NCT192 by
Step 3
           FTP
Step 4
           Upload the new firmware to the target partition via FTP by the following commands.
           Example 29 shows an example of uploading firmware to Remote-NE.
           ftp> bin
           ftp> put xxxxx.enc (Client filename) \\1 (Remote ID) \ opCodeB:\xxxxx.enc (Remote filename)
Step 5
          Change the next boot partition to let the Remote-NE be rebooted by executing the
           new image (Refers to Table 3-14 Managing the Boot Section)
           CLI# boot-device set opCodeA
           CLI# boot-device show
           current boot device
                                  : opCodeB:xxxxx.enc
           next boot device
                                  : opCodeA:xxxxx.enc
```



It is noted that login device via FTP must be used the read-write authorization. The default username/password is **admin/admin**.

Example 29 Upload NC/ADSL LC Firmware to Flash Memory of a Remote-NE through FTP

Upgrade nct192.enc (image file of NC)

root@redhat9:/tmp> ftp 192.168.192.1 Connected to 192.168.192.1 (192.168.192.1).

Name (192.168.192.1:axds1): admin 331 Password required Password: 230 User logged in ftp> bin 200 Type set to I, binary mode ftp> put nct192.enc \\1\opCodeA:\nct192.enc 200 Port set okay 150 Opening BINARY mode data connection 226- CAUTION:Please wait for 120 seconds or check the Flash LED -226 Transfer complete ftp: 3126797 bytes sent in 6.91Seconds 452.70Kbytes/sec. ftp> **bye** 221 Bye...see you later

Upgrade nct1901fw.enc (DSP code of LC)

root@redhat9:/tmp> ftp 192.168.192.1 Connected to 192.168.192.1 (192.168.192.1).

Name (192.168.192.1:axds1): admin 331 Password required Password: 230 User logged in ftp> bin 200 Type set to I, binary mode ftp> put nct1901fw.enc \\1\opCodeA:\nct1901fw.enc 200 Port set okay 150 Opening BINARY mode data connection 226- CAUTION:Please wait for 120 seconds or check the Flash LED -226 Transfer complete ftp: 457808 bytes sent in 1.03Seconds 444.04Kbytes/sec ftp> bye 221 Bye...see you later Upgrade nct1901br.enc (Booter of LC)

root@redhat9:/tmp> ftp 192.168.192.1 Connected to 192.168.192.1 (192.168.192.1).

Name (192.168.192.1:axds1): admin 331 Password required Password: 230 User logged in ftp> bin 200 Type set to I, binary mode ftp> put nct1901br.enc \\1\opCodeA:\nct1901br.enc 200 Port set okay 150 Opening BINARY mode data connection 226- CAUTION:Please wait for 120 seconds or check the Flash LED -226 Transfer complete ftp: 32892 bytes sent in 0.11Seconds 299.02Kbytes/sec ftp> bye 221 Bye...see you later



Make sure the source image file that you select is accordant to the Remote-NE model; else the NE may not run well with the upgraded firmware image after rebooting.

SHDSL Firmware Upgrade

This section depicts the procedures to upgrade the firmware version of the SHDSL line card; the higher version will bring new features and functions of the SHDSL line card.

CLI employs a NE SHDSL Firmware Upgrade utility to transfer the new code files to the memory of NC card by FTP (File Transfer Protocol), and then upgrades this new version from memory to SHDSL line card. You can follow the procedures below to update your SHDSL line card if necessary.

- **Step 1** Open the DOS prompt window and go to the directory where the new firmware is.
- Step 2 Upload the new SHDSL firmware to the flash memory of NC through FTP. Example 30 shows an example of uploading SHDSL firmware from local host to the flash memory of NC.

Step 3 Use the commands described in Table 3-15 to upgrade the new firmware to SHDSL line card and wait for the state of upgrade to be finished. Example 31 shows an example of uploading SHDSL firmware from NC to NE.

Example 30 Upload SHDSL Firmware to Flash Memory of NC through FTP

D:\image\SHDSL Firmware>ftp 192.168.192.1 Connected to 192.168.192.1. 220------220-Welcome to the IP-DSLAM FTP Server 220-220- CAUTION: It's your responsibility to use the FTP service correctly -220- , please put the right files into the right file system. -User (192.168.192.1:(none)): admin 331 Password required Password: 230 User logged in ftp> ftp> cd shdsl: 250 Changed directory to "shdsl:/" ftp> put TEImage.bin.gz 200 Port set okay 150 Opening BINARY mode data connection 226- CAUTION:Please wait for 120 seconds or check the Flash LED -226 Transfer complete ftp: 1834196 bytes sent in 1.30Seconds 1414.18Kbytes/sec. ftp> ftp> bye 221 Bye...see you later

Table 3-15 SHDSL Firmware Upgrade

The following command is to upgrade SHDSL firmware from flash memory to SHDSL line card.

CLI#	shdsl-fw	-upgrade	start	<lc-range></lc-range>
------	----------	----------	-------	-----------------------

The following command is to show the upgrade status.		
CLI# shdsl-fw-upgrade show		
Parameters	Task	
<lc-range></lc-range>	This specifies the slot index of target SHDSL line card. Type: Mandatory	

Valid values: 1 ~ 4

Example 31 Upload SHDSL Firmware from NC to SHDSL Line Card

```
CLI# shdsl-fw-upgrade start 4
```

OK: Please reset LC after "finished" state

CLI# shdsl-fw-upgrade show

SHDSL firmware upgrade state

LC	type	state	
1	ADSL		n/a
2	ADSL		n/a
3	ADSL		n/a
4	SHDSL	transmission of firmware	image

Configuring the System Date and Time

You can set the date and time parameters as part of the initial system configuration and set the system date and time by using the "**datetime**" command at the prompt of CLI#.



The date and time will be reset due to reboot system. However, the NE will synchronize its date and time with the configured time server's.

(Please refer to Section "Configuring the Internet Time Server" for the setting of time server.

Table 3-16 shows the CLI commands to perform the configuration of system data and time. Example 32 shows the usage of these commands as well as its related parameters.

Table 3-16 System Date and Time Configuration

The following command is to set the system date time.

CLI# datetime set <date> <time>

The following command is to set the GMT time zone for system.

CLI# datetime timezone <zone>

The following command is to monitor the current system time.

CLI# datetime show

Parameters	Task	
<date></date>	Identify the year, month, and date. Type: Mandatory Valid values: yyyy-mm-dd	
<time></time>	Identify the time in hour, minute, and second. Type: Mandatory Valid values: hh:mm:ss	
{zone}	Identify the GMT time zone. Type: Mandatory Valid values: -12 ~ +13	

Example 32 Configure the system date and time

```
CLI# datetime set 2005-03-10 10:38:00
OK
CLI# datetime timezone +8
OK
CLI# datetime show
datetime: 2005-03-10 10:38:11 GMT+8
```

Configuring the Internet Time Server

A time server is a server that reads the actual time from a reference clock and distributes this information to its clients using a computer network. The NE supports to synchronize its date and time with the configured time server's via the Simple Network Time Protocol (SNTP)

We use the following steps to configure the time sever of NCT192 IP-DSLAM:

- **Step 1:** Set the time server to let the clock of NCT192 IP-DSLAM be synchronized with an Internet time server's.
- **Step 2:** Enter the "**config time-service**" sub-group directory to configure the Internet time server.

CLI# config time-service CLI(config time-service)#

Table 3-17 shows the CLI commands to perform the Internet Time Server setting. Example 33 shows the usage of these commands as well as their related parameters.

Table 3-17 Internet Time Server Setting

The following command is to enable the time server IP address or domain name.

CLI(config time-service)# servers set <server1 | server2 | server3> <address>

The following command is to disable the time server.

CLI(config time-service)# servers delete <server1 | server2 | server3>

The following command is to define the synchronization protocol.

CLI(config time-service)# set protocol <none | sntp>

The following command is to define the synchronization time period.

CLI(config time-service)# set timezone <zone-value>

The following command is to define the synchronization time period.

CLI(config time-service)# set period <time>

The following command is to display the time server configuration information.

CLI(config time-service)# show

The following command is to manually synchronize with time server.

CLI(config time-service)# update

Parameters	Task	
<address></address>	This specifies the network IP address or domain name for Internet time server.	
	Valid values: Any valid class A/B/C IP address or domain name	
<zone-value></zone-value>	Identify the GMT time zone. Type: Mandatory Valid values: -12 ~ +13	
<time></time>	This specifies the automatic synchronizing time period Type: Mandatory Valid values: 1 ~ 1440 Minutes	

Example 33 Set the time server IP address or domain name

```
CLI(config time-service)# servers set server1 220.130.158.52
OK
CLI(config time-service)# set protocol sntp
OK
CLI(config time-service)# set timezone +12
OK
CLI(config time-service)# update
OK
CLI(config time-service)# show
Time protocol: SNTP
Update period: 12 hr 0 min
Time servers:
   [server1]
     internet address: 220.130.158.52
               status: backup mode
   [server2]
      internet address:
               status: not set
   [server3]
      internet address:
               status: not set
```

[time zone] GMT+12

Configuring the DNS Server

The DNS (Domain Name System) server is used for the resolution of domain name. For example, a query for www.cisco.com will receive a reply with the IP address of the web server of Cisco. Therefore the DNS Server is designed for the resolution of domain name. In other words, the DNS replies the corresponding IP address to the URL like the given example.

Enter to the "config dns" sub-group directory to configure the DNS server.

CLI**# config dns** CLI(config dns)#

Table 3-18 shows the CLI commands to perform the DNS server setting. Example 34 shows the usage of these commands as well as its related parameters.

Table 3-18 DNS Server Setting

The following command is to define the DNS server IP address.

CLI(config dns)# set {dns1 | dns2 | dns3} <ip-addr>

The following command is to delete the DNS server.

CLI(config dns)# del {dns1 | dns2 | dns3}

The following command is to display the DNS server.

CLI(config dns)# show

Parameters	Task
<ip-addr></ip-addr>	This specifies the DNS server IP address.
	Type: Mandatory

Example 34 Add a new DNS server to the system

CLI(config Set OK.	dns)#	set dns1	168.95.1.1	
CLI(config Set OK.	dns)#	set dns2	168.95.1.88	
CLI(config DNS server	dns)# IP	show		
	dns	1	dns2	dns3
	95.1.	168	3.95.1.88	0.0.0.0

Ambient Temperature

Ambient temperature is a common term to denote a certain temperature within enclosed space in which the NCT192 IP-DSLAM is accustomed.

Enter the "**config hw-sensor**" sub-group directory to set the temperature threshold of hardware sensor of NCT192 IP-DSLAM.

CLI**# config hw-sensor** CLI(config hw-sensor)# Table 3-19 shows the CLI commands to perform the configuration of ambient temperature. Example 35 shows the usage of these commands as well as its related parameters.

Table 3-19 Configuring Ambient Temperature

The following command is to set the temperature threshold of the system.

CLI(config hw-sensor)# **set temp** <*temp-high*> <*temp-low*>

The following command is to show the current setting.

CLI(config hw-sensor)# show			
Parameters	Task		
<temp-high></temp-high>	This specifies the high temperature threshold. Whenever the ambient temperature is higher than < <i>temp-high></i> , the NE sends alarm traps to the configured trap hosts (NCT192 LCT or NCT192 server) Type: Mandatory Valid values: -20 ~ 100 (degrees centigrade)		
<temp-low></temp-low>	This specifies the low temperature threshold. Whenever the ambient temperature is lower than < <i>temp-low</i> >, the NE sends alarm traps to the configured trap hosts (NCT192 LCT or NCT192 server) server) Type: Mandatory Valid values: -20 ~ 100 (degrees centigrade)		

Example 35 Set the temperature threshold of the system

CLI(config hw-sensor)**# set temp 70 -10** OK

CLI(config hw-sensor)# **show**

sensor temperature thresholds: high low

70 -10

Chapter 4 Managing the System Profiles

A profile is a named list of configuration parameters with a value assigned to each parameter. By using a profile, the operator can configure the NE without keying in a lot of configuration parameters. However, when the operator modifies a profile, the modification will affect all ports using that profile.

This chapter describes the management of two kinds of profiles, data transport related profiles and alarm definition profile. The alarm definition profile defines the attributes of the report (alarm) of abnormality launched by the NE.

As to the data transport related profiles, they are

- xDSL Profile
- VLAN Profile

The xDSL Profile indicates the ADSL Profile and SHDSL Profile. It defines the attributes of the connection established via the xDSL subscriber loop. As to the VLAN Profile, it defines the attributes of services/applications applied to the xDSL subscriber.

Figure 4-1 and Table 4-1 help you to understand each profile and their interrelationship.

As shown in Figure 4-1, NE forwards traffic on 2 kinds of connections, unicast connection and multicast connection, on the Data Level. For the unicast connection, it carries all traffic (unicast and broadcast) except multicast traffic. The attributes of unicast connection are specified by the IP Traffic Profile. As for the multicast connection, its attributes are specified by the Multicast Channel Profile. Moreover, the NE also supports to restrict the subscriber to receive a set of specific Multicast Channels. Multicast Service Profile records the set of specific Multicast Channels.

Figure 4-1 Interrelationship of Data Transport Related Profiles



Profile		Capacity	Level	Category	Description
	Line Profile	60 sets	Link	Loop	Define the attributes of xDSL loop connection.
xDSL Profile	PM Threshold Profile	60 sets	Link	Loop	Report the message if loop connection error across the threshold.
	Traffic Policing Profile (ADSL LC only)	60 sets	Data	User Data	Define the rule of traffic policing for user data.
VLAN Profile	IP Traffic Profile	60 sets	Data	Unicast	Define the traffic bandwidth of Unicast connection.
	Multicast Service Profile	60 sets	Data	Multicast	A set of service selected from menu list.
	Multicast Channel Profile	800 sets	Data	Multicast	A menu list of multicast channel, it also defines the traffic bandwidth of Multicast connection.

Table 4-1 Data Transport Related Profiles



To make Traffic Policing Profile take effect, it needs to set IP Traffic Profile properly. Please refer to the NOTE under "Configuring the Traffic Policing Profile".



To make an xDSL line work normally, the IP Traffic Profile is essential. As to the Traffic Policing Profile, it is optional and is only applicable to ADSL LC.

A profile is a named list of configuration parameters with a value assigned to each parameter. When you delete a profile you will affect the change on all port or connection using that profile. If you want to change a single port or a subset of ports, you can create another profile with desired parameters, and then assign the new profile to the desired port.

This chapter contains the following sections:

- Configuring the xDSL Profile
 - Configuring the ADSL Connection Profile
 - Configuring the ADSL Performance Alarm Profile
 - Configuring the Traffic Policing Profile
 - Configuring the SHDSL Connection Profile
 - Configuring the SHDSL Performance Alarm Profile
- Configuring the VLAN Profile
 - VLAN Profile contains 2 categories of profiles.
- Configuring the IP Traffic Profile
- Configuring the Multicast Service Related Profile

Configuring the xDSL Profile

The xDSL profiles enable you to simplify the process to configure the different xDSL loops with the same loop/data connection attributes. For example, you may classify the subscribers to several categories like category of residential customers, category of small office customers, category of enterprise customers and so on. Each category of subscribers is with the same loop/data connection attributes. Different categories are with their specific attributes like the line speed and performance parameters to secure their particular service quality. Once the profiles are created, you can easily assign the xDSL subscriber with the request xDSL loop attributes.

This section depicts the supported xDSL profiles.

- Configuring the ADSL Connection Profile
- Configuring the ADSL Performance Alarm Profile
- Configuring the Traffic Policing Profile
- Configuring the SHDSL Connection Profile
- Configuring the SHDSL Performance Alarm Profile

Configuring the ADSL Connection Profile

The ADSL connection profile indicates the expected overall physical parameters of the ADSL line port. This profile describes the communication at the ADSL layer. A number of parameters will be specified such as fast/interleaved, rate adaptation mode, noise margin, power spectrum density, and transmit rate.

Enter to the "config profile adsl-conf" sub-group directory to manage the ADSL connection profile.

CLI**# config profile adsl-conf** CLI(config profile adsl-conf)**#**

Table 4-2 shows the connection profile configuration of the ADSL line. Example 36 shows the usage of these commands as well as its related parameters

Table 4-2 ADSL Connection Profile Configuration

The following command is to generate a new ADSL connection profile.

CLI(config profile adsl-conf)# add <profile-name>

The following command is to remove the specific ADSL connection profile.

CLI(config profile adsl-conf)# del <profile-name>

The following command is to activate the specific ADSL connection profile.

CLI(config profile adsl-conf)# enable <profile-name>

The following command is to deactivate the specific ADSL connection profile.

CLI(config profile adsl-conf)# disable <profile-name>

The following command is to modify the profile rate mode to adaptive with desired parameters.

CLI(config profile adsl-conf)# set adaptive-rate <profile-name> <us-min-rate> <us-max-rate>

<ds-min-rate> <ds-max-rate>

Table 4-2 ADSL Connection Profile Configuration (continued)

The following command is to modify the profile rate mode to dynamic with desired parameters.

CLI(config profile adsl-conf)# set dynamic-rate <profile-name> <us-min-rate> <us-max-rate> <ds-min-rate> <ds-max-rate> <us-down-shift>

<us-up-shift> <ds-down-shift> <ds-up-shift>

The following command is to modify the profile rate mode to fix with desired parameters.

CLI(config profile adsl-conf)# set fixed-rate <profile-name> <us-rate> <ds-rate>

The following command is to modify the profile line mode to interleaved path with latency.

CLI(config profile adsl-conf)# set line-mode <profile-name> interleave <max-us-latency>

<max-ds-latency> <min-us-inp>

<min-ds-inp>

The following command is to modify the profile line mode to fast path.

CLI(config profile adsl-conf)# set linemode <profile-name> fast

The following command is to modify the profile PSD (Power Spectrum Density) with desired parameters.

CLI(config profile adsl-conf)# set psd <profile-name> <us-psd> <ds-psd>

The following command is to modify the upstream or downstream shelf SNR margin due to dynamic rate mode.

 $\label{eq:cliconfig} \mbox{ config profile adsl-conf} \mbox{ set snr-margin } < \mbox{ profile-name} \ \mbox{ us } \mbox{ | } \mbox{ ds} \mbox{ } < \mbox{ target-snr} \mbox{ set snr-margin } \mbox$

<min-snr><max-snr>

The following command is to modify the upstream or downstream shelf SNR margin due to dynamic rate mode.

CLI(config profile adsl-conf)# set shift-snr <profile-name> {us | ds} <down-shift-snr>

<up-shift-snr>

The following command is to modify the ADSL2/ADSL2+ power automatic management for L2 state.

CLI(config profile adsl-conf)# set pwr-mgt <profile-name> l2 automatic <l2-min-rate> <l2-max-rate> <l2-low-time> <l0-time>

The following command is to modify the ADSL2/ADSL2+ power manual management for L2 state.

CLI(config profile adsl-conf)# set pwr-mgt <pro>cprofile-name> l2 manual <l2-min-rate> <l2-max-rate>

The following command is to modify the ADSL2/ADSL2+ power management for L3 state.

CLI(config profile adsl-conf)# set pwr-mgt <profile-name> 13 <denied | accepted>

The following command is to monitor the ADSL connection profile information.

CLI(config profile adsl-conf)# show [<profile-name>]

Parameters	Task
<profile-name></profile-name>	This specifies the ADSL connection profile name Type: Mandatory Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_, '', '@').
<us-min-rate></us-min-rate>	Defines upstream minimum transmit rate, this parameter is available for adaptive and dynamic rate mode. Type: Mandatory Valid values: 64 ~ 2976 (multiple of 32 kbps) Default value: 64 kbps (due to profile generated)
<us-max-rate></us-max-rate>	Defines upstream maximum transmit rate, this parameter is available for adaptive and dynamic rate mode. Type: Mandatory Valid values: 64 ~ 2976 (multiple of 32 kbps) Default value: 64 kbps (due to profile generated)
<ds-min-rate></ds-min-rate>	Defines downstream minimum transmit rate, this parameter is available for adaptive and dynamic rate mode. Type: Mandatory Valid values: 32 ~ 29984 (multiple of 32 kbps) Default value: 32 kbps (due to profile generated)
<ds-max-rate></ds-max-rate>	Defines downstream maximum transmit rate, this parameter is available for adaptive and dynamic rate mode. Type: Mandatory Valid values: 32 ~ 29984 (multiple of 32 kbps) Default value: 32 kbps (due to profile generated)
<us-rate></us-rate>	Defines upstream transmit rate, this parameter is available for fixed rate mode. Type: Mandatory Valid values: 64 ~ 2976 (multiple of 32 kbps) Default value: 64 kbps (due to profile generated)
<ds-rate></ds-rate>	Defines downstream transmit rate, this parameter is available for fixed rate mode. Type: Mandatory Valid values: 32 ~ 29984 (multiple of 32 kbps) Default value: 32 kbps (due to profile generated)
< us-down-shift >	Defines the minimum time interval during which the upstream noise margin should stay below the Downshift SNR before the ATU-R triggers the SRA process to decrease the line rate. Type: Mandatory Valid values: 0 ~ 16383 (seconds) Default value: 0 sec (due to profile generated)
< us-up-shift >	Defines the minimum time interval during which the upstream noise margin should stay above the Upshift SNR before the ATU-R triggers the SRA process to increase the line rate. Type: Mandatory Valid values: 0 ~ 16383 (seconds) Default value: 0 sec (due to profile generated)

 Table 4-2
 ADSL Connection Profile Configuration (continued)

Parameters

Task
Defines the minimum time interval during which the downstream noise margin should stay below the Downshift SNR before the ATU-C triggers the SRA process to decrease the line rate.
Type: Mandatory
Valid values: $0 \sim 16383$ (seconds)
Default value: 0 sec (due to profile generated)
Defines the minimum time interval during which the downstream noise margin should stay above the Upshift SNR before the ATU-C triggers the SRA process to increase the line rate.
Type: Mandatory

ADSL Connection Profile Configuratio Table 4-2

< ds-down-shift >	Defines the minimum time interval during which the downstream noise margin should stay below the Downshift SNR before the ATU-C triggers the SRA process to decrease the line rate.
	Type: Mandatory
	Valid values: $0 \sim 16383$ (seconds)
	Default value: 0 sec (due to profile generated)
< ds-up-shift >	Defines the minimum time interval during which the downstream noise margin should stay above the Upshift SNR before the ATU-C triggers the SRA process to increase the line rate.
	Type: Mandatory
	Valid values: $0 \sim 16383$ (seconds)
	Default value: 0 sec (due to profile generated)
< max-us-latency>	Defines the maximum upstream interleaved path latency.
	It applies only to the interleave channel and defines the mapping between subsequent input bytes at the inter-leaver input and their placement in the bit stream at the interleave output. Larger numbers provide greater separation between consecutive input bytes in the output bit stream, allowing for improved impulse noise immunity at the expense of payload latency.
	Type: Mandatory
	Valid values: 1 ~ 255 (milliseconds)
	Default value: 0 msec (due to profile generated)
< max- <i>ds-latency</i> >	Defines the maximum downstream interleaved path latency.
	It applies only to the interleave channel and defines the mapping between subsequent input bytes at the inter-leaver input and their placement in the bit stream at the interleave output. Larger numbers provide greater separation between consecutive input bytes in the output bit stream, allowing for improved impulse noise immunity at the expense of payload latency.
	Type: Mandatory
	Valid values: $1 \sim 255$ (milliseconds)
	Default value: 0 msec (due to profile generated)
<min-us-inp></min-us-inp>	Defines the minimum upstream INP (Impulse Noise Protect) capability. It indicates the multiple of INP symbol.
	Type: Mandatory
	Valid values: {0 1/2 1 2 4 8 16}
	Default value: 0 (due to profile generated)
<min-ds-inp></min-ds-inp>	Defines the minimum downstream INP (Impulse Noise Protect) capability. It indicates the multiple of INP symbol.
	Type: Mandatory
	Valid values: {0 1/2 1 2 4 8 16}
	Default value: 0 (due to profile generated)
<us-psd></us-psd>	Defines upstream power spectrum density level.
-	Type: Mandatory
	Valid values: $-40.0 \sim 4.0 \text{ (dB/Hz)}$
	Default value: 0 dB/Hz (due to profile generated)
<ds-psd></ds-psd>	Defines downstream power spectrum density level.
1	Type: Mandatory
	Valid values: $-40.0 \sim 4.0 \text{ (dB/Hz)}$
	Default value: 1.0 dB/Hz (due to profile generated)

Parameters	Task
<target-snr></target-snr>	Defines target SNR (Signal-to-Noise Ratio) margin for upstream or downstream signal. Type: Mandatory
	Valid values: $0.0 \sim 31.0$ (dBm) Default value: 6.0 dBm (due to profile generated)
<min sur<="" th=""><th>Defines minimum SNR margin for unstream or downstream signal</th></min>	Defines minimum SNR margin for unstream or downstream signal
	Type: Mandatory
	Valid values: 0.0 ~ 31.0 (dBm)
	Default value: 0 dBm (due to profile generated)
<max-snr></max-snr>	Defines maximum SNR margin for upstream or downstream signal. Type: Mandatory
	Valid values: $0.0 \sim 31.0 \text{ (dBm)}$
	Default value: 31.0 dBm (due to profile generated)
<down-shift-snr></down-shift-snr>	Defines down-shift SNR margin for upstream or downstream signal.
	Type: Mandatory
	Valid Values: $0.0 \sim 31.0 \text{ (dBm)}$
<un shift="" sur=""></un>	Defines up-shift SNR margin for unstream or downstream signal
<up-sngt-sn></up-sngt-sn>	Type: Mandatory
	Valid values: $0.0 \sim 31.0 \text{ (dBm)}$
	Default value: 0 dBm (due to profile generated)
<mode></mode>	Defines line power management L2 mode to be either 'automatic' or 'manual'. Automatic – This mode enables the ADSL line to automatically transfer from the L0 (full-on) state to the L2 (low power) state whenever the downstream net data rate is lower than expected. And it also enables the ADSL line to automatically transfer from the L2 state to the L0 state once the NE begins to drop the downstream data.
	Manual –This mode allows the operator to manually force the specific ADSL line to transfer from the L2 state to the L0 state, and vice versa.
	Type: Mandatory
	Default value: manual
<12-min-rate>	Defines minimum rate and low-bound to data rate for power management L2 state in 32 kbps steps.
	Type: Mandatory
	Default value: 52 ~ 29964 Köps
<12-max-rate>	Defines maximum rate to data rate for power management L2 state in 32 kbps steps.
	Type: Mandatory
	Valid values: 32 ~ 29984 kbps
<l2-low-rate-time></l2-low-rate-time>	It specifies the contiguous time interval for which the downstream mean net data rate is below the 'L2 State Min & Low Rate' on a ADSL line. (See the Note below)
	Type: Mandatory
	Valid values: $0 \sim 65535$ seconds
	Default value: 300 seconds
<l0-time></l0-time>	It specifies the minimum time (seconds) the ADSL line must stay at the L0 state. During this time interval, the ADSL line is not allowed to transfer to the L2 state. It is the so-called L0-TIME as defined in ITU-T G.997.1. (See the Note below)
	Type: Mandatory
	Default value: 900 seconds
<denied accepted="" =""></denied>	Defines the management L3 request. If it is, the ADSL lines applied this profile will accept request from CPE and transfer their power management state into L3 by the CPE request.
	Valid values: {denied accepted}
	Default value: accepted

Table 4-2 ADSL Connection Profile Configuration (continued)

Comparison of ADSL 'adaptive-rate mode' and 'dynamic-rate mode'.

- Adaptive-rate mode: When the ADSL loop is in the 'adaptive-rate mode', the NE will re-try to establish a new lower-rate connection with the ATU-R whenever the NE or ATU-R detects 10 consecutive SESs (Severely Error Seconds) in this mode.
- **Dynamic-rate** mode: When the ADSL loop is in the '**dynamic-rate** mode', the NE will trigger the SRA (Seamless Rate Adaptation) process to change the line rates without losing the connection with ATU-R whenever the physical loop environment varies in this mode.



The associated parameters of the **Dynamic-rate** mode are as follows.

`<up-shift-snr>`, `<down-shift-snr>`, `<us-up-shift>/< ds-up-shift>' and `<us-down-shift>/< ds-down-shift>' and `<us-down-shift>' and `<us-down-shift>/< ds-down-shift>' and `<us-down-shift>' and `



In the **Dynamic-rate** mode, the NE will lose the connection with ATU-R if it fails to complete the SRA process to change the line rates



The following relationship holds when setting their values.

 $< min-snr > \le < down-shift-snr > \le < target-snr > \le < up-shift-snr > \le < max-snr >$.



Comparison of ADSL 'interleave channel mode' and 'fast channel mode'

- **Interleave** channel mode: When the ADSL loop is in the '**Interleave** channel mode', it enhances the immunity to the impulse noise like lighting. However, its side effect is to introduce the transmission latency. Hence it is suitable for the time-insensitive data transmission, like file transfer.
- **Fast** channel mode: When the ADSL loop is in the '**fast** channel mode', the latency introduced by the ADSL link is shortest. Hence, it is suitable for the transmission of time-sensitive information such as audio.



The default upstream/downstream PSD spectrums in G.992.1 ADSL, G.992.3 ADSL2 and G.992.5 ADSL2+ are different. To simply the configuration effort, $\langle us-psd \rangle$ and $\langle ds-psd \rangle$ here indicate the deviation from the default upstream and downstream PSD spectrums in G.992.x, respectively. Hence, it is recommended to set $\langle us-psd \rangle$ and $\langle ds-psd \rangle$ as zero in normal case.



The relationship among *<us-psd>*, observed upstream SNR margin, observed ADSL line upstream rate and ADSL line reach.

- Higher <us-psd> results in either higher observed SNR margin or higher observed ADSL line rate or longer ADSL line reach.
- Higher *<us-psd>* also results in more severe Cross Talk.

Hence, for fixed ADSL reach, you will observe either high SNR margin or high ADSL line rate. When you do not need high SNR margin or high ADSL line rate, you can lower the $\langle us-psd \rangle$ to save power (save money).

The above description applies to the relationship among *<ds-psd>*, observed downstream SNR margin, observed ADSL line downstream rate and ADSL line reach.



In order to save power, G.992.3 and G.992.5 define the power management function. The operator can either configure the ADSL line Transmission (Tx) power be either manually or automatically managed.

The automatic power management function enables the ADSL line to automatically transfer from the L0 (full-on) state to the L2 (low power) state whenever the downstream net data rate is lower than expected. And it also enables the ADSL line to automatically transfer from the L2 state to the L0 state once the NE begins to drop the downstream data.

Concepts about the setting of automatic L0/L2 power management (l2 pwr-mgt)

- The default values are to let the ADSL line be always in the L0 state. If you want to save power, you can alter these values.
- Whenever the ADSL chip detects that the subscriber's data traffic is low on this ADSL line, and it meets the criterion constructed by the setting of <l2-min-rate>, <l2-max-rate>, <l2-low-time> and <l0-time>. The ADSL chip will let the ADSL line enter L2 state to save power. (The ADSL chip will lower the PSD Spectrum to achieve this purpose)



In order to let the ADSL line avoid going into and out of L2 too often, the following $L0 \leftrightarrow L2$ state transition criteria are adopted.

L0→L2:

- The ADSL line must stay at the L0 state for a period specified by 'L0 State Min Time to Start Monitoring' (i.e., the L0-TIME as defined in ITU-T G.997.1)
- After the L0-TIME, the NE begins to compute the mean net-data rate for a period of 'L2 State Low Rate Min Contiguous Time' on an ADSL line.
- The ADSL line transfers to the L2 state once the computed mean net-data rate is below the 'L2 State Min & Low Rate'.
- Once an ADSL line is at the L2 state, its downstream ADSL line rate is in the range from 'L2 State Min & Low Rate' to 'L2 State Max Rate'.

L2→L0:

• The ADSL line immediately transfers to the L0 state once the NE detects packet loss on the ADSL line in the down stream direction.

Example 36 Add a new ADSL connection profile with desired values

CLI(config profile adsl-conf)# **add bank** OK

CLI(config profile ads1-conf)**# set adaptive-rate bank 512 2048 1024 8192** OK

CLI(config profile ads1-conf)**# set line-mode bank interleave 10 10 1 1** OK

CLI(config profile ads1-conf)**# enable bank** OK

CLI(config profile ads1-conf)# show bank

profile [bank]

status	: enabled				
line mode	: interleave				
rate mode	: adaptive				
			up-stream	down-stream	
fast rate (n	nin/max)	:	512/2048	1024/8192	kbps
interleave m	ate (min/max)	:	512/2048	1024/8192	kbps
interleave m	nax delay	:	10	10	ms
interleave m	nin INP symbol t	time :	1	1	
target SNR n	nargin	:	6.0	6.0	dB
min./max. SM	NR margin	:	0.0/31.0	0.0/31.0	dB
down/up shit	t SNR margin	:	3.0/20.0	3.0/20.0	dB
down/up shit	t time	:	1000/1000	1000/1000	sec
PSD		:	0.0	0.0	dBm/Hz
power manage	ement setting:				
L2-mode	e L2-min-rate	L2-max-	rate CPE L3	3	
manua	al 32 kbps	29984	kbps accepte	 ed	



Attaching the ADSL connection profile to the proper ADSL line port can be tasked to the "**config port**" sub-group directory. It refers to the Section "Configuring the ADSL Line Port" of Chapter 5.

Once the ADSL connection profile is created, the operator can apply it to distinct ADSL line port by the CLI commands in the "**config port**" sub-group directory. Please refers to the Section "Configuring the ADSL Line Port" of Chapter 5. for the related command.

Configuring the ADSL Performance Alarm Profile

The PM threshold profile sets the threshold values for the performance parameters associated with the ADSL line. The NE will report the threshold-over trap (i.e. TCA, Threshold-Crossing Alarm) to the NCT192 LCT (or NCT192 Server) when the specified performance threshold is over.

During the accumulation cycle, if the current value of a performance parameter reaches or exceeds its corresponding threshold value, a threshold crossing alert (TCA) is generated by the system and sent to trap station. TCAs provide early detection of performance degradation. When a threshold is crossed, the ADSL line port continues to count the errors during a given accumulation period. If 0 is entered as the threshold value, the NE never sends the corresponding TCA.

The NE supports to define the Near-End and Far-End thresholds of ES (Errored Seconds), SES (Severely Errored Seconds), and UAS (Unavailable Seconds) conditions in 15 minutes and 1 day interval. The definition of ES, SES and UAS are as follows.

• ES (Error Second)

ES corresponds to "ES-L" defined in ITU-T G.997.1 (2003 Edition) ITU-T G.997.1 defines ES as a count of 1-second intervals with one or more CRC-8 anomalies summed over all received bearer channels, or one or more LOS defects, or one or more SEF defects, or one or more LPR defects.

- SES (Several Error Second) SES corresponds to the "SES-L" defined in ITU-T G.997.1 (2003 Edition). ITU-T G.997.1 defines ES as a count of 1-second intervals with 18 or more CRC-8 anomalies summed over all received bearer channels, or one or more LOS defects, or one or more SEF defects, or one or more LPR defects.
 - UAS (UnAvailable Second)
 UAS corresponds to the "UAS-L" defined in ITU-T G.997.1 (2003 Edition).
 ITU-T G.997.1 defines ES as a count of 1-second intervals for which the ADSL line is unavailable. The ADSL line becomes unavailable at the onset of 10 contiguous SES-Ls. The 10 SES-Ls are included in unavailable time. Once unavailable, the ADSL line becomes available at the onset of 10 contiguous seconds with no SES-Ls. The 10 seconds with no SES-Ls are excluded from unavailable time. Some parameter counts are inhibited during unavailability

Enter to the "**config profile adsl-alarm**" sub-group directory to manage the ADSL performance alarm profile.

CLI# config profile adsl-alarm CLI(config profile adsl-alarm)#

Table 4-3 shows the performance alarm profile configuration of the ADSL line. Example 37 shows the usage of these commands as well as its related parameters.

Table 4-3 ADSL Performance Alarm Profile Configuration

The following command is to generate a new ADSL performance alarm profile.

CLI(config profile adsl-alarm)# add <profile-name>

The following command is to remove the specific ADSL performance alarm profile.

CLI(config profile adsl-alarm)# del <profile-name>

The following command is to activate the specific ADSL performance alarm profile.

CLI(config profile adsl-alarm)# enable <profile-name>

The following command is to deactivate the specific ADSL performance alarm profile.

CLI(config profile adsl-alarm)# disable <profile-name>

The following command is to modify the performance ADSL alarm profile parameters at Near-End and Far-End.

CLI(config profile adsl-alarm) # set < profile-name > <15 min-es > <15 min-ses > <15 min-uas > <1 day-es > <15 min-uas > <10 day-es > <10 min-uas > <10 day-es > <10 min-uas > <10 min-ua

<1day-ses> <1day-uas> [near / far]

The following command is to monitor the ADSL performance alarm profile information.

CLI(config profile adsl-alarm)# show [<profile-name>]

Parameters	Task
<profile-name></profile-name>	This specifies the performance alarm profile name Type: Mandatory Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '@').
<15min-es>	 When the keyword "<i>near</i>" is set, This field indicates the threshold of Errored Seconds (ES) on the CO (Central Office) side during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. When the keyword "<i>far</i>" is set, This field indicates the threshold of Errored Seconds (ES) on the RT side (CPE) during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. Type: Mandatory
	Valid values: 0 ~ 900 Default value: 0 (due to profile generated)
<15min-ses>	 When the keyword "<i>near</i>" is set, This field indicates the threshold of Severely Errored Seconds (SES) on the CO (Central Office) side during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. When the keyword "<i>far</i>" is set, This field indicates the threshold of Severely Errored Seconds (SES) on the RT side (CPE) during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. Type: Mandatory Valid values: 0 ~ 900
	Default value: 0 (due to profile generated)

Parameters	Task
<15min-uas>	When the keyword " <i>near</i> " is set, This field indicates the threshold of Unavailable Seconds (UAS) on the CO (Central Office) side during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. When the keyword " <i>far</i> " is set.
	This field indicates the threshold of Unavailable Seconds (UAS) on the RT side (CPE) during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. Type: Mandatory Valid values: $0 \approx 900$
	Default value: 0 (due to profile generated)
<1day-es>	When the keyword " <i>near</i> " is set, This field indicates the threshold of Errored Seconds (ES) on the CO (Central Office) side during the last 1 day. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day. When the keyword " <i>far</i> " is set, This field indicates the threshold of Errored Seconds (ES) on the BT side (CDE)
	 Inis field indicates the threshold of Errored Seconds (ES) on the RT side (CPE) during the last 1 day. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day. Type: Mandatory Valid values: 0 ~ 86400 Default value: 0 (due to profile generated)
<1day-ses>	When the keyword " <i>near</i> " is set, This field indicates the threshold of Errored Seconds (SES) on the CO (Central Office) side during the last 1 day. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day. When the keyword " <i>far</i> " is set, This field indicates the threshold of Severely Errored Seconds (SES) on the RT side (CPE) during the last 1 day. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day. Type: Mandatory Valid values: $0 \sim 86400$ Default value: 0 (due to profile generated)
<1day-uas>	When the keyword " <i>near</i> " is set, This field indicates the threshold of Unavailable Seconds (UAS) on the CO (Central Office) side during the last 1 day. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day. When the keyword " <i>far</i> " is set, This field indicates the threshold of Unavailable Seconds (UAS) on the RT side (CPE) during the last 1 day. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day. Type: Mandatory Valid values: 0 ~ 86400 Default value: 0 (due to profile generated)
[near / far]	Identify the given performance parameter value in Near-End or Far-End side, CLI Ex will apply the same performance parameter value for Near-End and Far-End if not specify. Type: Optional Valid values: near, far

 Table 4-3
 ADSL Performance Alarm Profile Configuration (continued)

Example 37 Add a new performance alarm profile with correspond performance parameter values

CLI(config profile adsl-alarm)**# add bank_pm** OK

CLI(config profile adsl-alarm)**# set bank_pm 10 15 20 30 40 50** OK

CLI(config profile adsl-alarm)# enable bank_pm

1day-uas

40

50

50

15

10



0K

Once the performance alarm profile is created, the operator can apply it to distinct ADSL line port by the CLI commands in the "**config port**" sub-group directory.

30

Please refer to the Section "Configuring the ADSL Line Port" of Chapter 5 for the related command.

20

Configuring the Traffic Policing Profile

far end

Traffic policing is to monitor network traffic for conformity with the Service Level Agreement (SLA) between subscribers and ISP (or NSP).

According to the SLA, the edge network equipment (NE) either drops or marks subscriber's out-of-profile traffic with designated DSCP values to enforce compliance with that SLA. The traffic policing profile serves to keep the rules per the SLA.

Once the traffic policing profile is created, the operator can apply it to distinct ADSL line port by the CLI commands in the "**config port**" sub-group directory. Please refer to the Section "Configuring the ADSL Line Port" of Chapter 5 for the related command.

One example of application of traffic policing is as follows.

Suppose that the SLA defines that the subscriber can send upstream traffic at the rate up to 1.5Mbps. However, the NSP has the right to remark the DSCP value of traffic higher than 1Mbps when the network is in congestion. To accomplish this SLA, the operator can set the CIR to be 1Mbps, and set the out-of-profile action to remark the DSCP value to BE.

To verify the aforementioned setting, you can send 1.5Mega bit in one second in the upstream direction, then set the SmartBit (which connects to GE port to receive the upstream traffic) to capture the upstream traffic. And you will see that the DSCP of IP packet about 0.5Mbit is the value what you set "out-of-profile action"

Enter to the "config profile metering" sub-group directory to manage the traffic policing profile.

CLI# config profile metering CLI(config profile metering)#

Table 4-4 shows the commands to perform the configuration of traffic policing profile.0 shows the usage of these commands as well as their related parameters.

Table 4-4 Traffic Policing Profile Configuration

The following command is to generate a new traffic policing profile.

CLI(config profile metering)# add <profile-name>

The following command is to remove the specific traffic policing profile.

CLI(config profile metering)# del <profile-name>

The following command is to modify the traffic policing profile and it desired parameters.

CLI(config profile metering)# set <profile-name> <cir> <action>

The following command is to monitor the traffic policing profile information.

CLI(config profile metering)# show [<profile-name>]

Parameters	Task	
<profile-name></profile-name>	This specifies the traffic policing profile name	
	Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_, '', '@').	
<cir></cir>	Defines the committed information rate of traffic policing profile.	
	Type: Mandatory	
	Valid values: $0 \sim 2 \text{ (mbps)}$	
<action></action>	This identifies which value will DSCP be replace, drop packets or do nothing when user's upstream traffic exceeds CIR.	
	Type: Mandatory	
	Valid values: no-action drop BE AF11 AF12 AF13 AF21 AF22 AF23 AF31 AF32 AF33 AF41 AF42 AF43 EF	

Example 38 Add a new traffic policing Profile with desired values

```
CLI(config profile metering)# add Adsl_tp
OK
CLI(config profile metering)# set Adsl_tp 100 AF32
OK
CLI(config profile metering)# show
Traffic Policing [Adsl_tp]
CIR (Mbps) action
100 DSCP-AF32
```



The "Service Type Control" should be enabled when Traffic Policing Profile is assigned to xDSL subscribers (refers to Section "Defining the Line Card Operation Mode" of Chapter 5 for the commands related to the setting of "Service Type Control").



Please refer to Figure 6-4 and accompany paragraphs for more details of Differentiated Service Code Point.

Configuring the SHDSL Connection Profile

A profile corresponds to a particular set of parameters, and can be referenced to by separated SHDSL line port.

Enter to the "**config profile shdsl-conf**" sub-group directory to manage the SHDSL connection profile.

CLI# config profile shdsl-conf

CLI(config profile shdsl-conf)#

Table 4-5 shows the connection profile configuration of the SHDSL line. Example 36 shows the usage of these commands as well as its related parameters.

Table 4-5 SHDSL Connection Profile Configuration

The following command is to generate a new SHDSL connection profile.

CLI(config profile shdsl-conf)# add <name>

The following command is to remove the specific SHDSL connection profile.

CLI(config profile shdsl-conf)# del <name>

The following command is to activate the specific SHDSL connection profile.

CLI(config profile shdsl-conf)# enable <name>

The following command is to deactivate the specific SHDSL connection profile.

CLI(config profile shdsl-conf)# disable <name>

The following command is to set the line probe state before training with STU-R.

CLI(config profile shdsl-conf)# set line-probe <name> <enabled-state>

The following command is to set the PSD mask of the SHDSL connection profile.

CLI(config profile shdsl-conf)# set psd <name> <psd-value>

The following command is to set the single-pair minimum/maxmum rate of the SHDSL connection profile.

CLI(config profile shdsl-conf)# set rate <name> <min-rate> <max-rate>

The following command is to set the SNR margin of the SHDSL connection profile.

CLI(config profile shdsl-conf)# set snr-margin <name> <down-current-snr> <down-worst-snr> <up-cur rent-snr> <up-worst-snr>

The following command is to set the transmission mode of the SHDSL connection profile.

CLI(config profile shdsl-conf)# set transmission <name> <transmission-mode>

The following command is to set the used SNR margins of the SHDSL connection profile.

CLI(config profile shdsl-conf)# set used-snr <name><used-snr-list>

The following command is to monitor the SHDSL connection profile information.

CLI(config profile shdsl-conf)# show [<name>]

Parameters	Task
<name></name>	It specifies the the SHDSL connection profile name
	Type: Mandatory
	Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '_', '@').
<min-rate></min-rate>	It specifies the minimum transmit rate, this parameter is available for adaptive. rate mode.
	Type: Mandatory
	Valid values: 72 ~ 2312 (multiple of 64 kbps)
	Default value: 72 kbps (due to profile generated)
<max-rate></max-rate>	It specifies the maximum transmit rate, this parameter is available for adaptive . rate mode.
	Type: Mandatory
	Valid values: 72 ~ 2312 (multiple of 64 kbps)
	Default value: 72 kbps (due to profile generated)
<psd-value></psd-value>	It specifies the setting of PSD Mask to be symmetric or asymmetric.
1	Type: Mandatory
	Valid values: 1 = symmetric, 2 = asymmetric
	Default value: 1

<transmission-mode></transmission-mode>	It specifies the e transmission mode, Annex A, Annex B, or both.
	Type: Mandatory
	Valid values: 1:Annex.A or 2:Annex.B or 3:Both.
	Default value: 3
<down-current-snr></down-current-snr>	It specifies the downstream current target SNR margin.
	Type: Mandatory
	Valid values: $-10 \sim 21 \text{ (dBm)}$
	Default value: 6 dBm (due to profile generated)
<down-worst-snr></down-worst-snr>	It specifies the downstream worst target SNR margin
	Type: Mandatory
	Valid values: $-10 \sim 21 \text{ (dBm)}$
	Default value: 6 dBm (due to profile generated)
<up-current-snr></up-current-snr>	It specifies the upstream current target SNR margin.
1	Type: Mandatory
	Valid values: $-10 \sim 21 \text{ (dBm)}$
	Default value: 6 dBm (due to profile generated)
<up-worst-snr></up-worst-snr>	It specifies the upstream worst target SNR margin
1	Type: Mandatory
	Valid values: $-10 \sim 21 \text{ (dBm)}$
	Default value: 6 dBm (due to profile generated)
<used-snr-list></used-snr-list>	It specifies that it uses SNR bit-map, 0:down-current, 1:down-worst, 2:up-current,
	3:up-worst
	Type: Mandatory
	Valid values: 0, 1, 2, 3
<enabled-state></enabled-state>	It specifies to enable or disable the line probe state before training with STU-R.
	Enable: To make the 'line rate limit' up to 2312Kbps.
	Disable: To make the 'line rate limit' up to 1.5Mbps.
	Type: Mandatory
	Valid values: 1 =enable, 2= disable.

Table 4-5 SHDSL Connection Profile Configuration (continued)



In the case that *<minrate>* is equal to *<maxrate>*, the SHDSL line is to be in the 'fixed-rate mode'.

In the case that *<minrate>* is not equal to *<maxrate>*, the SHDSL line is to be in the 'adaptive-rate mode'.

Example 39 Add a new SHDSL Connection Profile with desired values

```
CLI(config profile shds1-conf)# add shds1_conf
OK
CLI(config profile shds1-conf)# set line-probe shds1_conf 1
OK
CLI(config profile shds1-conf)# set psd shds1_conf 1
OK
CLI(config profile shds1-conf)# set rate shds1_conf 300 2312
OK
CLI(config profile shds1-conf)# set snr-margin shds1_conf 6 6 6 6
OK
CLI(config profile shds1-conf)# set transmission shds1_conf 1
OK
CLI(config profile shds1-conf)# set transmission shds1_conf 1
OK
```

profile [shdsl_conf]		
status single-pair minimum/maxmum rate PSD mask transmission mode line probe support	: disabled : 264K/2312K : symmetric : region1-Annex.A : enabled	
SNR margin: current down worst down	current up worst up	used SNR
6 6	6 6	DC

CLI(config profile shdsl-conf)# **show**

Configuring the SHDSL Performance Alarm Profile

The PM threshold profile sets the threshold values for the performance parameters associated with the SHDSL line. The NE will report the threshold-over trap (i.e. TCA, Threshold-Crossing Alarm) to the NCT192 LCT (or NCT192 Server) when the specified performance threshold is over.

During the accumulation cycle, if the current value of a performance parameter reaches or exceeds its corresponding threshold value, a threshold crossing alert (TCA) is generated by the system and sent to trap station. TCAs provide early detection of performance degradation. When a threshold is crossed, the SHDSL line port continues to count the errors during a given accumulation period. If 0 is entered as the threshold value, the NE never sends the corresponding TCA.

The NE supports to define the Near-End and Far-End thresholds of ES (Errored Seconds), SES (Severely Errored Seconds), and UAS (Unavailable Seconds) conditions in 15 minutes interval. The definition of ES, SES and UAS are as follows.

• ES (Error Second)

ES corresponds to "ES-L" defined in ITU-T G.997.1 (2003 Edition) ITU-T G.997.1 defines ES as a count of 1-second intervals with one or more CRC-8 anomalies summed over all received bearer channels, or one or more LOS defects, or one or more SEF defects, or one or more LPR defects.

- SES (Several Error Second)
 SES corresponds to the "SES-L" defined in ITU-T G.997.1 (2003 Edition).
 ITU-T G.997.1 defines ES as a count of 1-second intervals with 18 or more CRC-8 anomalies summed over all received bearer channels, or one or more LOS defects, or one or more SEF defects, or one or more LPR defects.
- UAS (UnAvailable Second)

UAS corresponds to the "UAS-L" defined in ITU-T G.997.1 (2003 Edition). ITU-T G.997.1 defines ES as a count of 1-second intervals for which the ADSL line is unavailable. The ADSL line becomes unavailable at the onset of 10 contiguous SES-Ls. The 10 SES-Ls are included in unavailable time. Once unavailable, the ADSL line becomes available at the onset of 10 contiguous seconds with no SES-Ls. The 10 seconds with no SES-Ls are excluded from unavailable time. Some parameter counts are inhibited during unavailability

Enter to the "**config profile shdsl-alarm**" sub-group directory to manage the SHDSL performance alarm profile.

CLI**# config profile shdsl-alarm** CLI(config profile shdsl-alarm)#

Table 4-6 shows the performance alarm profile configuration of the SHDSL line. Example 40 shows the usage of these commands as well as its related parameters

Table 4-6 SHDSL Performance Alarm Profile Configuration

The following command is to generate a new SHDSL performance alarm profile.

CLI(config profile shdsl-alarm)# add <name>

The following command is to remove the specific SHDSL performance alarm profile.

CLI(config profile shdsl-alarm # del <name>

The following command is to activate the specific SHDSL performance alarm profile.

CLI(config profile shdsl-alarm # enable <name>

The following command is to deactivate the specific SHDSL performance alarm profile.

CLI(config profile shdsl-alarm)# disable <name>

The following command is to modify the SHDSL performance alarm profile parameters at Near-End.

CLI(config profile shdsl-alarm)# set <name> [atte <atte> snr <snr> es <es> ses <ses> crc <crc> losws <losws>uas <uas>]

The following command is to monitor the SHDSL performance alarm profile information.

CLI(config profile shdsl-alarm)# show <name> **Parameters** Task This specifies the performance alarm profile name <name> **Type:** Mandatory Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_, '@'). This identifies the attenuation threshold. <atte> Type: Mandatory Valid values: 1 ~ 127 This field indicates the threshold of Errored Seconds (ES) on the CO (Central Office) side during $\langle es \rangle$ the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. Type: Mandatory Valid values: 0 ~ 900 **Default value:** 0 (due to profile generated) This field indicates the threshold of Errored Seconds (SES) on the CO (Central Office) side < ses >during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. **Type:** Mandatory Valid values: 0 ~ 900 Default value: 0 (due to profile generated) This identifies the CRC error threshold. < crc >Type: Mandatory **Valid values:** 0 ~ 44100 This identifies the LOSWS error threshold. <losws> Type: Mandatory Valid values: 0 ~ 900 This identifies the LOSWS error threshold < uas >Type: Mandatory Valid values: 0 ~ 900 This field indicates the threshold of Unavailable Seconds (UAS) on the CO (Central Office) side <usa> during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes. Type: Mandatory Valid values: 0 ~ 900 Default value: 0 (due to profile generated)

Example 40 Add a new SHDSL port alarm profile with desired values

CLI(config profile shdsl-alarm)**# add shdsl_ex** OK CLI(config profile shdsl-alarm)# set shdsl_ex atte 127 snr 10 ses 100 crc 12800 losws 100 uas 100 OK

CLI(config profile shdsl-alarm)**# enable shdsl_ex** OK

CLI(config profile shdsl-alarm)# **show**

Profile [shd	sl_ex]			
Status	: enable	ed		
Attenuati	on : 127			
SNR margi	n :10			
ES	SES	CRC	LOSWS	UAS
0	100	12800	100	100

Configuring the VLAN Profile

VLAN Profile contains 2 categories of profiles which are described in the following 2 sub-section.

- Configuring the IP Traffic Profile
- Configuring the Multicast Service

As shown in Figure 4-1, NE forwards traffic on 2 kinds of connections, unicast connection and multicast connection, on the Data Level. For the unicast connection, it carries all traffic (unicast and broadcast) except multicast traffic. The attributes of unicast connection are specified by the IP Traffic Profile. As for the multicast connection, its attributes are specified by the Multicast Channel Profile. Moreover, the NE also supports to restrict the subscriber to receive a set of specific Multicast Channels. Multicast Service Profile records the set of specific Multicast Channels.

Configuring the IP Traffic Profile

Similar to the traffic policing profile, the IP traffic profile serves to keep the rules to enforce compliance with that SLA. (Please refer to Section "Configuring the Traffic Policing Profile" of Chapter 4 for the description of traffic policing)

However, it is noted that the scope of traffic policing profile is to police the traffic on a whole ADSL line. As to the IP traffic profile, its scope of is to police the traffic on a PVC in an ADSL line.

The operator can create the IP Traffic Profile according to the SLA and apply it to the corresponding VC-to-VLAN on demand.

By configures IP Traffic Profile, the following traffic attributions of a PVC is specified.

- The maximum upstream/downstream net-data rate limit.
- The system drops upstream/downstream packets whenever it exceeds the corresponding specified rate
- The downstream priority of the PVC

The system forwards the downstream packets in a differentiated manner. That is, the system only forwards the traffic on PVC of lower priority whenever either one of the following conditions happened:

- There is no traffic on PVC of higher priority to be forwarded.
- The volume of traffic on PVC of higher priority exceeds the specified downstream net-data rate in a unit time.
- The filtering of the downstream broadcasts traffic

Enter to the "config profile ip-traffic" sub-group directory to manage the IP traffic profile.

CLI# config profile ip-traffic CLI(config profile ip-traffic)#

Table 4-7 shows the commands to perform the configuration of IP traffic profile. Example 41 shows the usage of these commands as well as their related parameters.

Table 4-7 IP Traffic Profile Configuration

The following command is to generate a new IP traffic profile.

CLI(config profile ip-traffic)# add <name>

The following command is to remove a new IP traffic profile.

CLI(config profile ip-traffic)# del <name>

The following command is to configure the rate limit of specific IP traffic profile.

CLI(config profile ip-traffic)# set <name> <us-rate> <ds-rate> <vc-priority> <bcast-filter>

The following command is to display the IP traffic profile information.

CLI(config profile ip-traffic)# show

Parameters	Task
<name></name>	This specifies the IP traffic profile name Type: Mandatory Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', ', ', ', ', ', ', ', ', ', ', ', ', '
<us-rate></us-rate>	This specifies the upstream rate limit for subscriber IP traffic. Type: Mandatory Valid values: nolimit 32k 64k 128k 256k 384k 512k 768k
<ds-rate></ds-rate>	This specifies the downstream rate limit for subscriber IP traffic. Type: Mandatory Valid values: 32 ~ 29984 kbps (multiple of 32 kbps)
< vc-priority >	This defines the downstream priority, the lower the priority, the higher the chance to get drop due to traffic congestion. Type: Mandatory Valid values: low medium high highest
<bcast-filter></bcast-filter>	This defines the downstream broadcast filter of ip-traffic profile. Available on the VLAN ID in which PVC used this ip-traffic. Type: Mandatory Valid values: drop forward

Example 41 Add a new IP traffic profile with desired values

CLI(config profile ip-traffic)# add Adsl_iptraffic

ΟK

CLI(config profile ip-traffic)# set Adsl_iptraffic no-limit 128 low forward

ΟK

CLI(config profile ip-traffic)# show

profile [Adsl_iptraffic] index : 1 US rate : no Limit DS rate : 128 (kbps) VC priority : low broadcast filter : forward

Configuring the Multicast Service Related Profile

The NE supports to prevent the subscriber to receive un-booked TV channel (multicast channel) by checking the received "IGMP join" packet with a preconfigured Multicast Service Profile. Here, a Multicast Service Profile represents a set of Multicast (TV) Channel Profiles. Each Multicast (TV) Channel Profile describes the attributes of a multicast stream (TV channel). In other words, the subscriber is restriced to receive the TV channels described recorded in the Multicast Service Profile.

This section depicts the concept and configuration of Multicast Service Profileand Multicast Channel Profile.

Multicast Channel Profile Setting

The multicast channel profile sets value of multicast group IP and the associated downstream bandwidth resource, it is a menu list of the Multicast Channel (multicast group; i.e. a TV channel) provided by the Content Service Provider (CSP) or Application Service Provider (ASP).

Enter to the "config profile mcast" sub-group directory to manage the multicast channel profile.

CLI# config profile mcast CLI(config profile mcast)#

Table 4-8 shows the commands to perform the configuration of multicast channel profile.Example 42 shows the usage of these commands as well as their related parameters.

Table 4-8 Multicast Channel Profile Configuration

The following command is to generate a new multicast group profile.

CLI(config profile mcast)# add <profile-name>

The following command is to remove the specific multicast group profile.

CLI(config profile mcast)# del <profile-name>

The following command is to activate the specific multicast group profile.

CLI(config profile mcast)# enable <profile-name>

The following command is to deactivate the specific multicast group profile.

CLI(config profile mcast)# disable <profile-name>

The following command is to modify the profile multicast group member and it desired parameters.

CLI(config profile mcast)# set <profile-name> <proup-ip> <rate> {low | medium | high | highest}

The following command is to monitor the multicast group profile information.

CLI(config profile mcast)# show [<profile-name>]

Parameters	Task
<profile-name></profile-name>	This specifies the multicast channel profile name
1 5	Type: Mandatory
	Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '@').
<group-ip></group-ip>	Defines class D IP addressing for multicast channel.
0 1 1	Type: Mandatory
	Valid values: 224.0.1.0 ~ 239.255.255.255
	Default value: 0.0.0.0 (due to profile generated)
<rate></rate>	Defines the downstream transmission limit rate of multicast channel.
	Type: Mandatory
	Valid values: 32~29984 +32 kbps
	Default value: 32 kbps (due to profile generated)
{low medium high highest}	Defines the downstream forwarding priority of the associated multicast channel
	Type: Mandatory
	Valid values: low, medium, high, highest
	Default value: low (due to profile generated)

Example 42

CLI(config profile mcast)**# add AdsI_ms** OK CLI(config profile mcast)**# set AdsI_ms 224.0.1.1 1024 high** OK

CLI(config profile mcast)**# enable Adsl_ms** OK

CLI(config profile mcast)# **show**

profile [Adsl_ms]			
grouip-ip	rate(kbps)	priority	status
224.0.1.1	1024	high	enabled

Multicast Service Profile Setting

The multicast service profile is a set of Multicast Channel profiles. Once the Multicast Channel profiles are created, you can generate the multicast service profile to bind suitable Multicast Channel profiles. Each multicast service profile is viewed as a service package for the subscriber to book. The operator then applies the booked multicast service profile to the distinct VC-to-VLAN associated with the subscriber. Please refer to the Section "Configuring a VC-to-VLAN Connection for the VC of RFC2684 Bridged Mode" and Section "Configuring a VC-to-VLAN Connection for the VC of RFC2684 Routed Mode" of Chapter 7 for the related command.

Add a new multicast service Profile with desired values

Whenever the subscriber clicks his remote controller to watch a TV channel transmitted via the ADSL line, the set-top-box sends the corresponding IGMP report packet. The NE will forward IGMP packet if its multicast IP hits the associated multicast service profile. Otherwise, the NE drops the IGMP packet. As a result, the subscriber is restricted to watch the TV progrNCT192 that he booked.

Attaching the multicast profile to the proper ADSL line port can be tasked at "**config profile mservice**" sub-group directory, refers to Section "Multicast Service Management" of Chapter 7.

Enter to the "**config profile mservice**" sub-group directory to manage the multicast service profile.

CLI# config profile mservice CLI(config profile mservice)#

Table 4-9 shows the commands to perform the configuration of multicast service profile. Example 43 and Example 44 show the usage of these commands as well as their related parameters.

Table 4-9 Multicast Service Profile Configuration

The following command is to generate a new multicast service profile.

CLI(config profile mservice)# add <service-name>

The following command is to remove the specific multicast service profile.

CLI(config profile mservice)# del <service-name>

The following command is to add the multicast channel profile into specific multicast service profile.

CLI(config profile mservice)# subscribe <service-name> <profile-list>

The following command is to remove the multicast channel profile from specific multicast service profile.

CLI(config profile mservice)# cancel <service-name> <profile-list>

The following command is to monitor the multicast service profile information.

CLI(config profile mservice)# show

Parameters	Task
<service-name></service-name>	This specifies the multicast service profile name
	Type: Mandatory
	Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '@').
<profile-list></profile-list>	This specifies the multicast group profile name.
	Type: Mandatory
	Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_, '.', '@').
	Format: xxx or xxx xxx xxx (xxx indicate as multicast group profile)

Example 43 Create a new multicast channel profile with desired values

CLI(config OK	profile	mcast)#	add	HBO		
CLI(config OK	profile	mcast)#	add	espn		
CLI(config OK	profile	mcast)#	add	CNN		
CLI(config OK	profile	mcast)#	set	HBO 224.1.	1.10 29984	high
CLI(config OK	profile	mcast)#	set	espn 224. 1	.1.11 2998	4 medium
CLI(config OK	profile	mcast)#	set	CNN 224.1.	1.12 29984	highest
CLI(config	profile 301	mcast)#	show			
groi	uip-ip	rate(kbps)	priority	status	
22	24. 1. 1. 10) 2	29984	high	disabled	
profile [E	SPN]					
groi	uip-ip	rate(kbps)	priority	status	
23	24. 1. 1. 11	1 2	29984	medium	disabled	
profile [Cl grow	NN] uip-ip	rate(kbps)	priority	status	
22	24. 1. 1. 12	2	29984	highest	disabled	

Example 44 Subscribe sets of multicast channel into service profile

```
CLI(config profile mservice)# add program-1
OK
CLI(config profile mservice)# subscribe program-1 HBO|ESPN
OK
CLI(config profile mservice)# add program-2
OK
CLI(config profile mservice)# subscribe program-2 HBO|ESPN|CNN
OK
CLI(config profile mservice)# show
Profile [program-1]
Mcast Profile: "HBO", "ESPN", Profile [program-2]
Mcast Profile: "HBO", "ESPN", "CNN",
```

Chapter 5 Managing the Subscriber Interface

This chapter describes the CLI commands to apply the relative profile to Subscriber interface in the following sections:

- Configuring the ADSL Line Port
- Monitoring the ADSL Connection Status
- Configuring the SHDSL Line Port
- Monitoring the SHDSL Connection Status
- Subscriber Interface Administrating

Configuring the ADSL Line Port

This section depcits the CLI commands to apply the following ADSL-related profiles to the ADSL line port in interest.

- ADSL Connection Profile
- ADSL Performance Alarm Profile
- Traffic Policing Profile

This section also depcits the CLI commands to manually perform the power management of the ADSL line port in interest.

On the other hand, the NE allows the operator to specify Agent Remote ID with an ASCII string of up to 63 characters. As to the Agent Circuit ID, it is not permitted to be modified. The format of Agent Circuit ID is as follows.

"NE-InbandIP-userSrcMAC atm slot-port:VPI.VCI" Here is one example Agent Circuit ID "IP_DSLAM-100.168.3.97-00:11:d8:80:93:23 atm 3-1:100.33", which represents NE's inband IP=100.168.3.97, MAC address of subscriber's personal computer (or the CPE)= 00:11:d8:80:93:23, slot = 3, port = 1, vpi = 100, vci = 33.



The xDSL Port Agent ID List keeps the Agent Circuit ID (intended for circuits terminated by the system hosting the Relay agent) and Agent Remote ID (intended to identify the remote host end of a circuit).



xDSL Port Agent ID is to be inserted into either all upstream DHCP messages sent by the client and all upstream PPPoE discovery stage packets

Enter to the "**config port**" sub-group directory to configure the relative profile on the ADSL line port.

CLI**# config port** CLI(config port)#

Table 4-9 shows the commands to perform the configuration of multicast service profile. Example 45 shows the usage of these commands as well as their related parameters.

Table

Table 5-1 ADSL Port Interface Configuration
The following command is to apply the PM alarm profile to specific ADSL line ports.
CLI(config port)# set adsl-alarm-profile <pre><pre>cprofile-name></pre></pre>
The following command is to apply connection profile to specific ADSL line ports.
CLI(config port)# set adsl-conf-profile <pre><pre>cprofile-name></pre></pre>
The following command is to force the ADSL2/ADSL2+ power management status. (manual manual manua
CLI(config port)# set adsl-pwr-mgt <pre>cport-range> <pwr-state></pwr-state></pre>
The following command is to apply the traffic policing profile to specific ADSL line ports.
CLI(config port)# set metering <prort-range> <profile-name></profile-name></prort-range>
The following command is to apply an "Agent Remote ID" to specific xDSL line port.
CLI(config port)# set remote-id <pre><pre>idstring></pre></pre>

The following command is to remove the remote ID from specific subscriber port.

CLI(config port)# clean remote-id <port-range>

The following command is to remove traffic policing profile from specific subscriber port.

CLI(config port)# clean metering port-range>

The following command is to remove the PM alarm profile from specific subscriber port.

The following command is to apply the PM alarm profile to specific SHDSL line port.

CLI(config port)# set shdsl-alarm-profile profile-name>

The following command is to apply connection profile to specific SHDSL line port.

CLI(config port)# set shdsl-conf-profile profile-name>

The following command is to view the configuration status of ADSL line port in interest.

CLI(config port)# show <port-range>

Parameters	Task
<pre><port-range></port-range></pre>	Identify the port range of the system to apply the relevance profile of line port. Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
<profile-name></profile-name>	Defines the profile name; connection profile, performance alarm profile or traffic policing profile.
	Type: Mandatory
	Valid values: The name of "connection profile", "performance alarm profile" or "traffic policing profile"
<pwr-state></pwr-state>	Defines the ADSL2/ADSL2+ power management operating status, switch between L0, L2 and L3 will only be available if ADSL power management is in "Manual" mode.
	Type: Mandatory
	Valid values: L0, L2,L3
<idstring></idstring>	Identify the remote ID information which is used for the DHCP option 82 tag and PPPoE tag.

NOTE

The "Service Type Control" should be enabled when Traffic Policing Profile is assigned to xDSL subscribers (refers to Section "Defining the Line Card Operation Mode" of Chapter 5 for the commands related to the setting of "Service Type Control").

Example 45 Apply the profile to the specify of ADSL line port

CLI(config port)# set adsI-conf-profile 1.6 ADSL_P1

de only)

```
ΟK
CLI(config port)# set adsI-alarm-profile 1.6 ADSL_PM
OK
CLI(config port)# set remote-id 1.6 1234
0K
CLI(config port)# set metering 1.6 ADSL_TRAF
OK: But LC1 STC is disabled. The traffic policing is not active until STC enabled.
CLI(config port)# show 1.6
Port: 1.6
    admin status
                              : enabled
    oper status
                            : up
    ADSL config profile : "ADSL_P1"
    ADSL alarm profile : "ADSL_PM"
SHDSL config profile : ""
    SHDSL contig profile : ""
SHDSL alarm profile : ""
-licing : "ADSL_TRAF"
    traffic policing : "ADSL_TRAF"
circuit ID : "IP_DSLAM-172.17.192.1-00:00:00:00:00:00 atm 1/6:0.0"
                            : "1234"
    remote ID
```

Monitoring the ADSL Connection Status

The NE supports to display the actual ADSL connection status as follows.

Enter to the "status" group directory to monitor the ADSL line Connection status.

CLI**# status** CLI(status)#

Table 5-2 shows the commands to monitor of ADSL connection status. Example 46 shows the usage of these commands as well as their related parameters.

Table 5-2 ADSL Connection Status Monitor

The following command is to view the ADSL line Connection status.			
CLI(status)# port show [<port-range>]</port-range>			
Parameters	Task		
<port-range></port-range>	Identify the port range of the system to view the status of line port.		
	Valid values: See the Section "Port Interface Indication" of Chapter 3.		

Example 46 Display the ADSL Connection Status

CLI(status)# port show 1.6

Port: 1.6				
admin status	:	enabled		
oper status	:	up		
power state	:	LO		
line standard	:	G.992.5	Annex A	
[physical status]				
item		US	DS	
attainable rat	e e	1343	30649	kbps
attenuatio	n	0.0	0.0	dB

SNR margin	6.4	8.4	dB
output power	12.1	12.6	dBm
[channel status]			
item	US	DS	
Tx rate	1342	29204	kbps
interleave delay	0	0	ms
CRC block length	39	255	ms
INP symbol time	0.00	0.00	DMT symbo

Configuring the SHDSL Line Port

This section depcits the CLI commands to apply the following SHDSL-related profiles to the SHDSL line port in interest.

- SHDSL Connection Profile
- SHDSL Performance Alarm Profile

Enter to the "**config port**" sub-group directory to configure the relative profile on the SHDSL line port.

CLI**# config port** CLI(config port)#

Table 5-3 shows the commands to configuration of SHDSL port interface.Example 47 shows the usage of these commands as well as their related parameters.

Table 5-3 SHDSL Port Interface Configuration

The following command is to apply the PM alarm profile to specific ADSL line port.

CLI(config port)# set adsl-alarm-profile profile-name >

The following command is to apply connection profile to specific ADSL line port.

CLI(config port)# set adsl-conf-profile profile-name

The following command is to apply the PM alarm profile to specific SHDSL line port.

CLI(config port)# set shdsl-alarm-profile cprofile-name>

The following command is to apply connection profile to specific SHDSL line port.

CLI(config port)# set shdsl-conf-profile profile-name>

The following command is to view the SDSL line port operation status.

CLI(config port)# show [<port-range>]

Parameters	Task
<port-range></port-range>	Identify the port range of the system wish to apply the relevance profile of line port. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<profile-name></profile-name>	Defines the profile name; connection profile or performance alarm profile. Type: Mandatory Valid values: The name of "connection profile" or "performance alarm profile"

Example 47 Display the Configuration of SHDSL Port Interface

CLI(config port)# **show 4.1** Port: 4.1 admin status : enabled oper status : down
```
: ""
ADSL config profile
ADSL alarm profile : ""
SHDSL config profile : "SHDSL "
SHDSL alarm profile : "SHDSL_PM "
'SHDSL_TAL'
traffic policing : "SHDSL_TRAF"
                         : "IP_DSLAM-172.17.192.1-00:00:00:00:00:00 atm 4/1:0.0"
circuit ID
                        : ""
remote ID
```

Monitoring the SHDSL Connection Status

The NE supports to display the actual SHDSL connection status as follows.

Enter to the "status port" group directory to monitoring the SHDSL line Connection status.

```
CLI# status port
CLI(status port)#
```

Table 5-4 shows the commands to monitor of SHDSL connection status. Example 48 shows the usage of these commands as well as their related parameters.

Table 5-4 SHDSL Connection Status Monitor

The following command is to view the ADSL line Connection status.

CLI(status port)# sho	w <port-range></port-range>
-----------------------	------------------------------------

Parameters	Task
<port-range></port-range>	Identify the port range of the system to view the status of line port.
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.

Display the SHDSL connection status Example 48

```
CLI(status port)# show 2.37
port: 2.37
   admin status
                   : enabled
   oper status
                    : up
```

Subscriber Interface Administrating

Enter to the "config port" sub-group directory to administrate (enable/disable) the ADSL line port or the SHDSL line port.

CLI# config port CLI(port)#

Table 5-5 shows the commands to perform the subscriber service administration. Example 49 shows the usage of these commands as well as their related parameters.

Table 5-5 Subscriber Interface Administration

The following command is to activate the subscriber service of ADSL line port or the SHDSL line port.

CLI(config port)# enable <po< th=""><th>rt-range></th></po<>	rt-range>
The following command is to deact	ivate the subscriber service of ADSL line port or the SHDSL line port.
CLI(config port)# disable <pre>per</pre>	ort-range>
Parameters	Task
<port-range></port-range>	Identify the port range of the system to enable or disable the connection of ADSL line port. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.

Example 49 Administrating the connection of ADSL line port

CLI(config port)# enable 1.6 OK CLI(config port)# show 1.6 Port: 1.6 admin status : enabled oper status : up : "ADSL_P1" ADSL config profile : "ADSL_PM" ADSL alarm profile SHDSL config profile : "" SHDSL alarm profile : "" traffic policing : "ADSL_TRAF" : "IP_DSLAM-172.17.192.1-00:00:00:00:00:00 atm 1/6:0.0" circuit ID : "" remote ID CRC block length 7 15 ms

Defining the Line Card Operation Mode

You are allowed to plan the expecting card type address in specific slot; there will have an alarm arise if the planned card type and the actual plug-in card type are mismatch.

The NCT192 support the following functions on a per LC basis.

- Planning the card type of a LC slot To ease the operator to plan the usage of each LC slot in advance, the NE support to configure the planned type of a LC slot. There will be an alarm arise if the planned card type and the actual plug-in card type are different.
- RFC 2684 encapsulation method for ADSL line card, either LLC or VCMUX.
- "Service Type Control" for ADSL line card. Operator can define the service which allow user to pass, they are "DHCP", "PPPoE" and "Static IP".
- VLAN tag pass-through function for ADSL line card Whenever the VLAN tag pass-through (VTP) is configured as enabled, the LC provides transparent transportation of the VLAN traffic from subscriber interface to network interface without any VLAN tag attachment. The LC will not attach any VLAN tag to the upstream subscriber traffic. In the mean time, the LC will also not replace the existing VLAN tag of the upstream subscriber traffic. On the other hand, in the case that the VTP function is configured as disabled, the LC will

attach a VLAN tag to all the traffic from subscriber interface to network interface. IEEE 802.10 VLAN forwarding function for ADSL line card

The operator can set the xDSL subscriber ports as well as the GE ports to only forward either tagged traffic or untagged traffic. This section depicts the commands to set the IEEE 802.1Q VLAN forwarding function on the xDSL subscriber ports. As to the setting on the GE ports, please refer to Section "Network Interface Administrating" of Chapter 6 for the

configuration of GE ports to either only forward either tagged traffic or untagged traffic.

NOTE

Please refer to Section "Verifying Current Software and Hardware Versions" of Chapter 3 for the run-time status of the tagged mode on NC and LC.

It is noted that the run-time status of Tagged mode and VTP on LC may be different to their corresponding configuration. In this case, the behavior of the NE is per the run-time status of NE instead of their configuration. Please refer to Table 6-9 for the expected NE behavior.



The ADSL LC needs to be reset to perform the expected system behavior as depicted in Table 6-9 whenever its run-time status changes.



It is noted that the NE will drop the tagged Ethernet frames of VLAN-ID not configured by the VC-to-VLAN setting (see Table 6-9) in the following case. NC tagged mode = Tagged LC tagged mode Run-Time Status = Tagged

LC VTP Run-Time Status = Enabled



The tagged mode (run-time) indicates the operational status of tagged mode. Tagged-only: LC (or NC) only forwards the tagged Ethernet frame and drops the untagged

Ethernet frame.

Untagged-only: LC (or NC) only forwards the untagged Ethernet frame and drops the tagged Ethernet frame.

It is noted that the value of configured Tagged mode and its Run-Time Status may be different. Please refer to Table 6-9 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.

Enter to the "config lc" sub-group directory to plan the line card slot.

CLI**# config lc** CLI(config lc)#

Table 5-6 shows the commands to perform the planning of the line card slot. Example 50 shows the usage of these commands as well as their related parameters.

Table 5-6 Plan the Line Card Slot

Use this command to plan the line card type address in specific slot.

CLI(config lc)# set planned-type <lc-range> <card-type>

Use this command to define the RFC 2684 encapsulation method for specific line card.

CLI(config lc)# set rfc2684-encap <lc-range> <encap-type>

Use this command to define the Service Type Control function for specific line card.

CLI(config lc)# set service-type <lc-range> <option>

Use this command to modify the VLAN tag pass-through (VTP) that configured as enables or not. (per LC setting).

CLI(config lc)# set vlan-tag-pass <lc-id> <option>

Use this command to define the tagged mode in specific slot.

CLI(config lc)# set tagged-mode <lc-id> <mode>

Use this command to monitor the line card plug-in and planned status.

CLI(config lc)# show

Parameters	Task
<lc-range></lc-range>	Specify the slot range of the system Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<lc-id></lc-id>	Specify the specific slot identifier of NE. Type: Mandatory Default values: 1
<card-type></card-type>	Specify the planning line card type Type: Mandatory Valid values: none, adsl, shdsl
<encap-type></encap-type>	Specify the RFC 2684 encapsulation method. Type: Mandatory Valid values: llc, vc-mux
<option></option>	Specify the VLAN tag pass-through status or Service Type Control, enable or disable. Type: Mandatory Valid values: enabled disabled
<mode></mode>	Specify the tagged mode is configured as either tagged or untagged mode. Type: Mandatory Valid values: tagged-only untagged-only

Example 50 Display the line card type status

CLI(config Ic)# set planned-type 1 ads1

LC 1. 1: OK

CLI(config Ic)# set rfc2684-encap 1 vc-mux

LC1 will be reset. Are you sure? (Y/N) Y OK

CLI(config Ic)# set vlan-tag-pass 1 enabled

OK

CLI(config Ic)**# set tagged-mode 1 tagged-only** LC1 will be reset. Are you sure? (Y/N) Y OK

CLI(config Ic)# **show**

	planned	current	rfc2684	vlan-tag	service	configured
LC	type	type	encap	pass	type	tagged-mode
1	ADSL	ADSL	VC-MUX	enabled	disabled	tagged-only
2	n/a	n/p	LLC	disabled	disabled	untagged-only
3	n/a	n/p	LLC	disabled	disabled	untagged-only
4	n∕a	n/p	LLC	disabled	disabled	untagged-only

This page is leave in blank for note or memo use

Chapter 6 Managing the Network Interface

There are two GE network interfaces, GE1 and GE2, for NCT192 IP-DSLAM. By default, GE1 is stated as the uplink GE port. GE2 is stated as the subtended GE port, and it connects to other equipment and forward traffics to GE1 if none of LACP or RSTP is enabled.

Figure 6-1shows the packet forwarding diagram. As can be seen, the so-called "Port Isolation" indicates that all xDSL users can not communicate with each other. That is, all traffic from the xDSL line interface is forwarded to the GE1 interface. In the mean time, once the GE2 is configured as a subtended port, all the ingress traffic of GE2 is restricted to be forwarded to GE1.





This chapter contains the following sections:

- Configuring the RSTP
- Configuring the Link Aggregation
- Configuring the CoS Traffic Mapping
- Network Interface Administrating
- Defining the NC Card Operation Mode
- Configuring the Subtending
- Configuring the Cascading

Configuring the RSTP

The 802.1D Spanning Tree Protocol (STP) standard was designed at a time when the recovery of connectivity after an outage within a minute or so was considered adequate performance. Rapid Spanning Tree Protocol (RSTP; IEEE 802.1w) can be seen as an evolution of the 802.1D standard more than a revolution. The 802.1D terminology remains primarily the same.

Port Roles and the RSTP Topology

The RSTP selects the bridge with the highest switch priority (lowest numerical priority value) as the root bridge. When the RSTP function of NCT192 IP-DSLAM is enabled, it assigns their network interface to play one of following port-roles. Figure 6-2 shows an example of Rapid Spanning Tree Topology when the RSTP converges.

- Root port Provides the best path (lowest cost) when the switch forwards packets to the root switch.
- Designated port Connects to the designated switch, which incurs the lowest path cost when forwarding packets from that LAN to the root switch. The port through which the designated switch is attached to the LAN is called the designated port.

- Alternate port An alternate port is a port blocked by receiving more BPDUs form another bridge.
- Backup port A backup port is a port blocked by receiving more useful BPDUs from the same bridge which is on.

Figure 6-2 Rapid Spanning Tree Active Topology



The RSTP protocol smartly prevents the loop connection in your uplink networks. It improves the Spanning Tree Protocol (STP) by reducing the fail-over time whenever there is network topology change. The configuration of RSTP is divided into 2 parts. One is the system-wise configuration, which is described in the subsection "Bridge". The other one is the port-specific configuration, which is described in the subsection "Port GE1/Port GE2".

Configuring RSTP Bridge Parameters

Enter to the "config rstp" sub-group directory to set the RSTP bridge-related parameters.

CLI**# config rstp** CLI(config rstp)#

Table 6-1 shows the commands to perform the configuration of RSTP switch. Example 51 shows the usage of these commands as well as their related parameters.

Table 6-1 RSTP Switch Configuration

The following command is to enable the RSTP function.

CLI(config rstp)# enable

The following command is to disable the RSTP function.

CLI(config rstp)# disable

The following command is to specify the version, RSTP or STP compatible.

CLI(config rstp)# set forceversion <protocol>

The following command is to configure the forwarding-delay for all RSTP instance.

CLI(config rstp)# set forwarddelay <delay-sec>

The following command is to configure the interval between the generations of configuration messages by the root switch to change the hello time.

CLI(config rstp)# set hellowtime <hello-sec>

The following command is to configure the maximum-aging time for all RSTP instance.

CLI(config rstp)# set maxage <a ging-sec>

The following command is to configure the switch priority and make it more likely that the switch will be chosen as the root switch.

CLI(config rstp)# set priority <priority-value>

The following command is to configure the Tx hold count for all RSTP instance.

CLI(config rstp)# set txholdcount <count>

The following command is to view the RSTP bridge information.

CLI(config rstp)# show bridge

Parameters	Task
<protocol></protocol>	This specifies the Network interface to be acting in RSTP mode or STP-Compatible mode. Valid values: rstp, stp Default: rstp
<delay-sec></delay-sec>	This specifies the time value that controls how fast a port changes its spanning state when moving towards the Forwarding state. The value determines how long the port stays in the Learning states, which precede the Forwarding state. This value is also used, when topology change has been detected and is underway, to age all dynamic entries in the Forwarding Database. Default: 15 Valid values: 4 ~ 30 (Second)
<hello-sec></hello-sec>	The hello time is the interval between the generations of configuration messages by the root switch and specifies the amount of time between the transmission of configuration bridge PDUs by this node on any port when it is the root of the spanning tree or trying to become so. Default: 2 Valid values: 1 ~ 10 (Second)
<aging-sec></aging-sec>	This specifies the maximum age time (in second) of STP/RSTP information learned from the network on any port before it is discarded. Default: 20 Valid values: 4 ~ 60 (Second)
<priority-value></priority-value>	Configure the switch priority for an RSTP instance, the range is 0x0000 to 0xF000 in increments of 0x1000. The lower the number, the more likely the switch will be chosen as the root switch. Default: 0x8000 Valid values: 0x0000 ~ 0xF000 in steps of 0x1000.
<count></count>	This specifies the value used by the port Transmit state machine to limit the maximum transmission rate. Default: 3 Valid values: $0 \sim 10$



It is noted that the following relationships have to be maintained.

 $2 \ge (\langle delay \cdot sec \rangle - 1 \ second) \geq \langle aging \cdot sec \rangle$ $\langle aging \cdot sec \rangle \geq 2 \ge (\langle hello \cdot sec \rangle + 1 \ second)$

Example 51 RSTP switch configuration

CLI(config rstp)# set forceversion rstp 0K CLI(config rstp)# set forwarddelay 10 0K CLI(config rstp)# set hellotime 5 OK CLI(config rstp)# set maxage 30 OK CLI(config rstp)# set priority 0x1000 OK CLI(config rstp)# set txholdcount 5 OK CLI(config rstp)# show bridge [bridge] admin status : disabled : RSTP : 0x1000-00:60:64:dc:7a:17 : 4096 : 30 sec force version bridge ID bridge priority bridge max age bridge hello time : 5 sec bridge forward delay bridge Tx hold count : 10 sec : 5 : 0x8000-00:60:64:dc:7a:17 root bridge ID : N/A : O root port ID root path cost : 20 sec root max age root hello time : 2 sec root forward delay : 15 sec time since last topology change : O sec topology change count : 0

Configuring RSTP Port GE1/Port GE2 parameters

Enter to the "**config rstp**" sub-group directory to set the RSTP port-related parameters. It is noted that the RSTP port-related parameters apply to the GE1/GE2 ports only, not to the xDSL subscriber ports.

CLI**# config rstp** CLI(config rstp)#

Table 6-2 shows the commands to perform the configuration of RSTP port. Example 52 shows the usage of these commands as well as their related parameters.

CLI(config rstp)# set uge cos	t <uge-range> <cost-value></cost-value></uge-range>
The following command is to disab	le the STP function of UGE port.
CLI(config rstp)# set uge disa	able <uge-range></uge-range>
The following command is to confi	gure the edge port instance.
CLI(config rstp)# set uge edg	e <uge-range> {false true}</uge-range>
The following command is to enable	e the STP function of UGE port.
CLI(config rstp)# set uge ena	ble <uge-range></uge-range>
The following command is to migra	ate the operation of RSTP and STP swap ability.
CLI(config rstp)# set uge mc	heck <uge-range> {false true}</uge-range>
The following command is to confi	gure the point-to-pint instance.
CLI(config rstp)# set uge p2p	<pre>o <uge-range> {true false auto}</uge-range></pre>
The following command is to confi	gure the port interface priority.
CLI(config rstp)# set uge prie	ority <uge-range> <port-priority></port-priority></uge-range>
The following command is to view	the RSTP information on GE Network interface.
CLI(config rstp)# show uge	
Parameters	Task
<uge-value></uge-value>	This specifies the Network interface number (UGE port). Valid values: 1 (UGE port 1), 2 (UGE port 2)
<cost-value></cost-value>	It specifies the contribution of this port to the path cost of paths towards bridge. A port of higher speed should be configured with lower numerica When set it to be "default", its value follows the definition of IEEE 802. You can assign lower cost values to interfaces that you want to select first that you want to select last. 0 means automatically calculated default Path Default: 20000

Table 6-2 RSTP Port Configuration

The following command is to configure the path cost of port interface.

Parameters	Task
<uge-value></uge-value>	This specifies the Network interface number (UGE port).
0	Valid values: 1 (UGE port 1), 2 (UGE port 2)
<cost-value></cost-value>	It specifies the contribution of this port to the path cost of paths towards the spanning tree root bridge. A port of higher speed should be configured with lower numerical value.
	When set it to be "default", its value follows the definition of IEEE 802.1d Table 17-3.
	You can assign lower cost values to interfaces that you want to select first and higher cost values that you want to select last. 0 means automatically calculated default Path Cost value. Default: 20000
	Valid values: 0 ~ 20000000
set uge edge < uge-range > {false true}	Check to let the port become edge port in spanning tree topology. An edge port on an RSTP switch will immediately transition to the forwarding state. However, the port will be a non-edge port if the NE receives RSTP BPDU on that port. And the port state and port role of the non-edge port will be determined by the RSTP hereafter.
	Default: false
	Valid values: false, true
set uge mcheck < uge-range >	Check to force this port to transmit RSTP BPDUs.
0 0 0	Default: false
set uge p2p < uge-range >	This specifies the type of link the RSTP-enaabled port connects.
{true false auto}	<i>true:</i> Indicates to force this port always be treated as if it is connected to a point-to-point link. <i>false:</i> Indicates to let this port be treated as having a shared media connection.
	<i>auto</i> : Indicates that this port is considered to have a point-to-point link if it is an aggregator and all of its members are aggregately, or if the MAC entity is configured for full duplex operation, either through auto-negotiation or by management means.
	Default: auto
	Valid values: true, false, auto
<port-priority></port-priority>	It specifies the port priority of a port. In the case that more than one ports form a loop in the NE, the RSTP/STP will block the ports of lower Port Priority (higher numerical value). Only the port of higher Port Priority (lower numerical value) is to be at the Forwarding state.
	Default: 128
	Valid values: 0, 16, 32, 48, 64, 80, 96, 112, 128, 144, 160, 176, 192, 208, 224, and 240. All other values are rejected.



When set Path Cost to be "default", its value follows the definition of IEEE 802.1d Table 17-3 as follows.

Link Speed	Recommended value	Recommended range	Range	
<=100 Kb/s	200 000 000*	20 000 000-200 000 000	1-200 000 000	
1 Mb/s	20 000 000ª	2 000 000-200 000 000	1-200 000 000	
10 Mb/s	2 000 000ª	200 000-20 000 000	1-200 000 000	
100 Mb/s 200 000 ^a		20 000-2 000 000	1-200 000 000	
1 Gb/s	20 000	2 000-200 000	1-200 000 000	
10 Gb/s	2 000	200-20 000	1-200 000 000	
100 Gb/s	200	20-2 000	1-200 000 000	
1 Tb/s	20	2-200	1-200 000 000	
10 Tb/s	2	1-20	1-200 000 000	

Example 52 RSTP port Configuration

```
CLI(config rstp)# set uge cost 1 2000
OK
CLI(config rstp)# set uge edge 1 true
OK
CLI(config rstp)# set uge mcheck 1
OK
CLI(config rstp)# set uge priority 1 32
OK
CLI(config rstp)# show uge
[UGE 1]
   STP admin status
                                  : enabled
                                  : 0x2001
   port ID
                                  : 32
   port priority
                                   : broken
   STP state
                                   : 2000
   admin path cost
                                   : 2000
   oper path cost
   admin edge port
                                   : true
   oper edge port
                                   : true
   admin P2P MAC
                                   : auto
   oper P2P MAC
                                   : true
[UGE 2]
   STP admin status
                                   : enabled
   port ID
                                   : 0x8002
   port priority
                                  : 128
                                  : broken
   STP state
                                  : O (default)
   admin path cost
                                   : 20000
   oper path cost
                                   : false
   admin edge port
   oper edge port
                                   : false
   admin P2P MAC
                                   : auto
   oper P2P MAC
                                   : true
```

Configuring the Link Aggregation

Link aggregation (LA) is to aggregate the 2 GE ports to form a single logical GE-channel to provide higher uplink bandwidth. This NE supports both static link aggregation and LACP (IEEE802.3ad, Link Aggregation Control Protocol). Figure 6-3 shows a typical GE-channel configuration.

Static link aggregation

In this mode, the NE forces to bundle GE1 and GE2 ports to form a single logical GE-channel without negotiating with its peer L2/L3 switch/router. For the traffic to be forwarded via the GE-channel as depicted in Figure 6-3, the NE will distribute the traffic on the GE1 and GE2 ports.



When the NE is configured to operate in the static LA mode, its peer L2/L3 switch/router needs to be configured in the same mode. Otherwise, the network may malfunction.

Dynamic link aggregation (LACP)

In this mode, the GE1 and GE2 ports are to form a single logical GE-channel by the LACP negotiating with its peer L2/L3 switch/router. By using the LACP, the NE learns the capability of its LACP peer. It then groups similarly configured ports into a single logical link (GE-channel). Once the GE-channel is built at the end of LACP negotiation, the NE will will forward traffic via the GE-channel by distributing the traffic on the "member port(s)" of GE-channel as depicted in Figure 6-3. Here, the "member port(s)" indicate GE1, GE2 or both GE ports of the NE.

In the LACP, two modes, active and passive modes, are defined for the LACP engine to decide to actively or passively negotiate with its LACP peer for the physical port in interest.

• Active mode

In this mode, The NE is willing to initiate the LACP negotiation procedure on the specified group and sends out an LACP packet voluntarily. The aggregation link will be formed if the other end is running in LACP active or passive mode.

• Passive mode

In this mode, The NE does not initiate LACP negotiation procedure on the specified group voluntarily, but waits for its LACP peer (in active state) initiates negotiation. The NE will form the aggregation link with its peer at the end of the negotiation procedure.

Figure 6-3 Typical GE-Channel Configuration





A LACP enabled switch/router needs to assign its "System ID". The "System ID" is of 8 bytes which consists of 2 parts:

SystemPriority: SystemMacAddress

During the LACP negotiation process, the LACP enabled device of lowest System ID has the previliage to determine the configuration of aggregated ports. Its peer will follow it.

Enter to the "config la" sub-group directory to manage the LACP function.

CLI**# config la** CLI(config la)# Table 6-3 shows the commands to perform the configuration of LACP. Example 53 shows the usage of these commands as well as their related parameters.

Table 6-3 LACP Configuration

The following command is to enable the static link aggregation or LACP.

CLI(config la)# enable <option>

The following command is to disable the static link aggregation or LACP.

CLI(config la)# disable

The following command is to configure the LACP group to be active or passive.

CLI(config la)# set group-activity <group-id> <activity>

The following command is to define the UGE port which the LACP group is.

CLI(config la)# set group-member <uge-range> <group-id>

The following command is to configure the timeout parameter of the LACP group.

CLI(config la)# set group-timeout <group-id> <timeout>

The following command is to configure the priority of UGE in LACP.

CLI(config la)# set port-priority <uge-range> <priority>

The following command is to configure the priority of the system in LACP.

CLI(config la)# set sys-priority <priority>

The following command is to view the LACP information.

CLI(config la)# show

-	
Parameters	Task
<option></option>	Configure the aggregation mode to LACP or force to static link aggregation. Valid values: lacp static
<group-id></group-id>	This indicates the LACP group ID. Valid values: 0 1
<uge-range></uge-range>	This indicates the UGE port. Valid values: 1 2
<timeout></timeout>	It specifies the interval of periodical transmitting LACP BPDU by the peer NE. If the NE does not receive the LACP BPDU after 3 consecutive specified intervals, the NE will remove the port from the aggregation link. For a busy aggregation link, it is recommended to set a short timeout to ensure that a disabled port is removed as soon as possible. Configure the LACP timeout. Timeout = long means that BPDU is sent every 30 seconds. Timeout = short means that BPDU is sent every 1 second. Valid values: long short
<priority></priority>	This indicates the LACP port priority or LACP system priority. Valid values: 0 ~ 65535 or 0x0000 ~ 0xFFFF

Example 53 LACP Configuration

```
CLI(config la)# set group-activity 1 active
OK
CLI(config la)# set group-member 1 1
OK
CLI(config la)# set group-timeout 1 long
OK
CLI(config la)# set port-priority 1 0x0011
OK
CLI(config la)# show
```

Link aggre LACP system	nk aggregation state CP system priority			disabled 0x8000
LACP group group-	ID	activity	tim	eout
	1 2	passive passive		long long
UGE port s	tate			
UGE-po	rt	LACP-pric	ority	group-ID
	1	0)	<pre><0011 <8000</pre>	1
	۷.	0,	10000	

Configuring the CoS Traffic Mapping

In order for the NE to play the role of edge (boundary) node of a DiffServ domain, the NE supports the the configurable mapping among the following entities.

- IEEE 802.1p User Priority as configured in the VC-to-VLAN configuration.
- Queue (Traffic Class) on each uplink trunk GE port
- DiffServ Code Point (DSCP) of the IP frame to be forwarded via the uplink trunk GE port.

User priority: The IEEE 802.1p user priority is a label carried with the frame that communicates the requested priority to the next hop (bridge, router or end systems). Typically, the user priority is not modified in the intermediate hop. Thus, the user priority has end-to-end significance across bridged LANs.

Queue (traffic class): A bridge can be configured so that multiple queues are used to hold frames waiting to be transmitted on a given outbound port, in which case the traffic class is used to determine the relative priority of the queues. Whenever the bridge's physical port is configured as strict priority (SP), all waiting frames at a higher traffic class are transmitted before any waiting frames of a lower traffic class. As with access priority, traffic class is assigned by the bridge on the basis of incoming user priority.



Currently, the NE supports 8 traffic classes (queues) on its GE ports with the strict priority (SP) scheduling policy only.

Differentiated Service Code Point (DSCP): RFC 2474/2475 defines the DiffServ field, which replaces the Type of Service (ToS) field in the IPv4 header. It facilitates the network devices behind IP-DSLAM to fulfill the end-to-end QoS. Figure 6-4 shows the DiffServ field.

Figure 6-4 DiffServ Field

D85	DS4	DS3	DS2	DS1	DS0	ECN	ECN
	_	DS	СР	_			

The most significant six bits of DiffServ field are called DSCP. The network device classifies packets and marks them with appropriate DSCP value. According to these values, other network devices in the DiffServ domain can make decision for packets behavior and provide the Quality of Service properly.

A network device classify the priorities of traffic with 6 different levels, they are Express

Forwarding (EF), Assured Forwarding Class 4 (AF4), Assured Forwarding Class 3 (AF3), Assured Forwarding Class 2 (AF2), Assured Forwarding Class 1 (AF1) and Best Effort (BE). These forwarding classes are represented by the first 3 bits of DSCP as shown in Table 6-4. Moreover, the network device differentiates three drop precedence in AF4~AF1 respectively into last 3 bits of DSCP, they are Low Drop Precedence, Medium Drop Precedence and High Drop Precedence.

Decimal representation of bits DS5, DS4 and DS3	Description
7	For link layer and routing protocol keep alive.
6	For using for IP routing protocols.
5	Express Forwarding (EF)
4	Assured Forwarding Class 4 (AF4)
3	Assured Forwarding Class 3 (AF3)
2	Assured Forwarding Class 2 (AF2)
1	Assured Forwarding Class 1 (AF1)
0	Best Effort (BF)

Table 6-4 DSCP: DS3~DS5 Bit Representation

Expedited Forwarding: The code point of EF is 101110, the packets marked with EF is to be transmitted with highest priority, lowest drop probability.

Assured Forwarding: Assured Forwarding PHB is suggested for applications that require a better reliability than the best-effort service. There are 4 classes of AF. Within Each AF class, there are 3 drop precedences. In case of congestion, the drop precedence of a packet determines the relative importance of the packet within the AF class. Table 6-5 indicates the relationship of the 4 AF class.

Table 6-5 DSCP Class Relationship

	Class				
Drop	AF1	AF2	AF3	AF4	
Low Drop Probability	001010 (AF11)	010010 (AF21)	011010 (AF31)	100010 (AF41)	
Medium Drop Probability	001100 (AF12)	010100 (AF22)	011100 (AF32)	100100 (AF42)	
High Drop Probability	001110 (AF13)	010110 (AF23)	011110 (AF33)	100110 (AF43)	

The rest of this section depicts the setting of so called "per hop behavior (PHB)" defined in DiffServ. The setting of PHB is separated in two parts.

- Mapping the 802.1p value to the priority queue of GE port
- Mapping the 802.1p value to the DSCP value



In the definition of PHB defined in DiffServ, it implicates that the Hop (usually a router) needs to classify the received traffic and remark its DSCP accordingly. The classification here indicates either MFC (Multi-Field classification) or DSCP classification. When the NE is at the edge, it should adopt the MFC. Otherwise, it should adopt the DSCP classification.

Then if the physical link is Ethernet, it has to also reassign the 802.1p value to be consistent with the DSCP assignment.

However, as the NE can only support the PVC-based classification, and can only reassign the 802.1p value. We therefore adopt a way different to the formal DiffServ definition.

Mapping the 802.1p value to the priority queue of GE port

Enter to the "config cos-queue" sub-group directory to configure the CoS traffic mapping.

CLI**# config cos-queue** CLI(config cos-queue)#

Table 6-6 shows the commands to configure the CoS traffic mapping of NE. 0 shows the usage of these commands as well as their related parameters.

Table 6-6 CoS Traffic Mapping

 The following command is to configure the CoS queue mapping between 802.1p priority and system queue index.

 CLI(cos-queue)# mapping $< 802_1p > < queue-index >$

 The following command is to viewing the CoS mapping information.

 CLI(cos-queue)# show

 Parameters
 Task

 $< 802_1p >$ This indicates the 802.1p priority for VLAN traffic.

 Type: Mandatory
 Valid values: $0 \sim 7$

 < queue-index > The system switch queue index, the higher the number, the higher the forwarding priority.

 Type: Mandatory
 Valid values: $1 \sim 8$

Example 54 Set and display the CoS traffic mapping of NE

CLI(config cos-queue)**# mapping 0 1** OK

CLI(config cos-queue)# show

802.1p	queue-index
0	1
1	1
2	2
3	4
4	5
5	6
6	7
7	8

Mapping the 802.1p value to the DSCP value

Enter to the "config diffserv" sub-group directory to configure the DiffServ function.

CLI**# config diffserv** CLI(config diffserv)#

Table 6-7 shows the commands to configure the differentiated service of NE. Example 55 shows the usage of these commands as well as their related parameters.

Table 6-7 **Configuring the DiffServ**

The following command is to enable diffserv function.

CLI(config diffserv)# enable

The following command is to disable diffserv function.

CLI(config diffserv)# disable

The following command is to configure the DiffServ action mapping between 802.1p priority and DSCP value.

CLI(config diffserv)# mapping <802_1p> <dscp>

The following command is to viewing the diffserv information.

CLI(config diffserv)# show

Parameters	Task
<802_1p>	This indicates the 802.1p priority for VLAN traffic. Type: Mandatory Valid values: 0 ~ 7
<dscp></dscp>	Defines the DSCP value mapping to 802.1p priority. Type: Mandatory Valid values: BE AF11 AF12 AF13 AF21 AF22 AF23 AF31 AF32 AF33 AF41 AF42 AF43 EF

7

Set and display the differentiated service of NE Example 55

```
CLI(config diffserv)# mapping O AF11
OK
CLI(config diffserv)# enable
OK
CLI(config diffserv)# show
DiffServ: enabled
DiffServ 802.1p and DSCP mapping:
                                       5
   802.1p : 0 1 2
                              3
                                  4
                                            6
    DSCP : AF11 AF11 AF11 AF21 AF21 AF31 AF31 EF
```

Network Interface Administrating

Enter to the "config nc" sub-group directory to manege the GE network interface.

CLI**# config nc** CLI(config nc)#

Table 6-8 shows the commands to perform the network services administration of NE. Example 56 shows the usage of these commands as well as their related parameters.

Table 6-8 Network Interface Administration

The following command is to activate the network service of specific UGE port.

CLI(config nc)# enable <uge-id>

The following command is to deactivate the network service of specific UGE port.

CLI(config nc)# disable <uge-id>

The following command is to display the UGE interface status.

CLI(config nc)# show

Parameters	Task
<uge-id></uge-id>	This specifies the Network interface number (UGE port).
	Valid values: 1 (UGE port 1), 2 (UGE port 2)

Example 56 Network Services Administration of NE

```
CLI(config nc)# add subtend-vid 100
0K
CLI(config nc)# set planned-type 1 cpu
OK
CLI(config nc)# set autoneg 1 enabled
OK
CLI(config nc)# set tagged-mode untagged-only
This operation will save configuration and reboot system. Are you sure? (Y/N)
Y
Saving...
OK
CLI(config nc)# set subtend enabled
You will enable subtending. Set subtending port VLANs for passing packets.
And you should use IGMP proxy at remote NE. Make sure your IGMP usage.
Are you sure? (Y/N) y
OK
CLI(config nc)# enable 1
OK
CLI(config nc)# show
NC:
   planned-type current-type tagged-mode
            CPU
                          CPU untagged-only
UGE:
   UGE oper-status admin-status auto negotiation use-mode
     1
                                            enabled uplink
               down
                          enabled
```

2	down	disabled	enabled	subtend
Subtend VLAN	ID:			

Defining the NC Card Operation Mode

The NE supports the IEEE 802.1Q VLAN forwarding function. The operator can set the xDSL subscriber ports as well as the GE ports to only forward either tagged traffic or untagged traffic. This section depicts the commands to set the IEEE 802.1Q VLAN forwarding function on GE ports. As to the setting on the xDSL subscriber ports, please refer to Section "Defining the Line Card Operation Mode" of Chapter 5 for the configuration of xDSL subscriber port to either only forward either tagged traffic or untagged traffic on a per-LC basis.

Table 6-9 depicts the NE behavior with the following configurations.

- NC with various Tagged mode parameters.
- ADSL LC with various Tagged mode and VTP parameters.

It is noted that the run-time status of LC may be different to its corresponding configuration. In this case, the behavior of the NE is per the run-time status of NE instead of their configuration. To describe the NE behavior, the following notations are adopted in Table 6-9.

- Q_S represents the service VLAN-tag and its VLAN-ID value is provided by the NE.
- $Q_{S (CPE)}$ represents the service VLAN-tag and the notation (CPE) indicates that its VLAN-ID value is provided by the CPE (or the subscriber's PC behind the CPE).
- Q_(CPE) represents the 802.1Q VLAN-tag.
- $Q_{C (CPE)}$ represents the customer VLAN-tag and the notation (CPE) indicates that its VLAN-ID value is provided by the CPE (or the subscriber's PC behind the CPE).



Please refer to Section "Verifying Current Software and Hardware Versions" of Chapter 3 for the run-time status of the tagged mode on NC and LC.



The ADSL LC needs to be reset to perform the expected system behavior as depicted in Table 6-9 whenever its run-time status changes.



The NC needs to be reset to perform the expected system behavior as depicted in Table 6-9 whenever its configured tagged mode changes.

1	2	h	
(NO	I	E	
1	2	9	,

Whenever the GE2 is set as subtended port and the NC is set as "tagged-only" mode, in order to make the NE forward the VLAN-specific traffic between GE1 and GE2, the operator needs to manually set GE1 and GE2 as the member ports of VLANs in interest. Please refer Table 6-9 for the "subtend-vid" related CLI commands.

Table 6-9	The NE behavior when configuring NC and ADSL LC with various Tagged modes
	and VTP parameters.

NC	ADSL LC s	etting	ADSL LC Run-Time Status		Expected NE behavior			
Setting					VLAN-tagging Status of Egress Traffic		Acceptable Ingress Traffic	
Tagged mode	Tagged mode	VTP	Tagged mode	VTP	On the GE port	On the ADSL line	On the GE port	On the ADSL line
Tagged Untagged	Enabled	Tagged	Enabled	Qs (CPE)	Q (CPE)	Tagged	Tagged	
	Disabled	Tagged	Disabled	Qs+Qc (CPE)	Q (CPE)	Tagged	Tagged	
	Enabled	Untagged	Disabled	Qs	Untagged	Tagged	Untagged	
	Untaggeu	Disabled	Untagged	Disabled	Qs	Untagged	Tagged	Untagged
Tagged	Enabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged	
	Taggeu	Disabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged
Untagged	Untagged	Enabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged
	Untagged	Disabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged

It is noted that the NE will drop the tagged Ethernet frames of VLAN-ID not configured by the VC-to-VLAN setting (see Table 6-9) in the following case.

NC tagged mode = Tagged

LC tagged mode Run-Time Status = Tagged

LC VTP Run-Time Status = Enabled



The tagged mode (run-time) indicates the operational status of tagged mode.

Tagged-only: LC (or NC) only forwards the tagged Ethernet frame and drops the untagged Ethernet frame.

Untagged-only: LC (or NC) only forwards the untagged Ethernet frame and drops the tagged Ethernet frame.

It is noted that the value of configured Tagged mode and its Run-Time Status may be different. Please refer to Table 6-9 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.

Enter to the "config nc" sub-group directory to manege the GE network interface.

CLI**# config nc** CLI(config nc)#

Table 6-10 shows the commands to perform the network services administration of NE. Example 57 shows the usage of these commands as well as their related parameters.

Table 6-10 Defining the NC Card Operation Mode

Use this command to modify the planning NC card type.

CLI(config nc)# set planned-type <nc-id> {none | cpu}

Use this command to modify the negotiation mode of GE port.

CLI(config nc)# set autoneg <uge-id> {off / on}

Use this command to configure the both of the GE ports to operate either in the "tagged-only" or "untagged-only" mode.

CLI(config nc)# **set tagged-mode** { *tagged-only* | *untagged-only*}

Use this command to display the UGE interface status.

CLI(coning nc)# snow	
Parameters	Task
<nc-id></nc-id>	Identify the slot range of the NC card Type: Mandatory
	Valid values: $1 \sim 2$ (value = 2 does not apply to NCT192)
{none cpu}	Identify the NC type.
<uge-id></uge-id>	This specifies the Network interface number (UGE port).
-	Valid values: 1 (UGE port 1), 2 (UGE port 2)
$\{off \mid on\}$	Identify the auto negotiation mode of specified UGE port.
	Type: Mandatory
	Valid values: off on
{ tagged-only / untagged-only}	This specifies both of the GE ports to operate either in the " <i>tagged-only</i> " or " <i>untagged-only</i> " mode.
	Type: Mandatory
	Valid values: tagged-only untagged-only



The operator needs to add both of the GE ports as member-ports of vlan *<vid>* when the following cases hold.

• GE1 port and GE2 port on NC is configured as tagged-only mode.

• GE2 port is configured as a subtended port. (Section "Configuring the Subtending" of Chapter 6 for the configuration of GE ports to either only forward either tagged traffic or untagged traffic.)

Example 57 Network Services Administration of NE

CLI(config nc)# add subtend-vid 100 OK CLI(config nc)# set planned-type 1 cpu 0K CLI(config nc)# set autoneg 1 enabled OK CLI(config nc)# set tagged-mode untagged-only This operation will save configuration and reboot system. Are you sure? (Y/N) Y Saving... OK CLI(config nc)# set subtend enabled You will enable subtending. Set subtending port VLANs for passing packets. And you should use IGMP proxy at remote NE. Make sure your IGMP usage. Are you sure? (Y/N) y OK

```
CLI(config nc)# enable 1
OK
CLI(config nc)# show
NC:
   planned-type current-type
                                tagged-mode
            CPU
                          CPU untagged-only
UGE:
   UGE oper-status admin-status auto negotiation use-mode
     1
                          enabled
                                            enabled
                                                       uplink
               down
                         disabled
     2
               down
                                            enabled
                                                      subtend
Subtend VLAN ID:
     100
```

Configuring the Subtending

In some network deployment environment, it is desired to connect several IP-DSLNCT192 to share a single uplink to the access network as shown in Figure 6-5. As can be seen in Figure 6-5, three NCT192 IP-DSLNCT192 are connected via their GE ports to each other in a Daisy-Chain topology. The left-most NE connects to the access network (where the Internet is behind) via its GE1 port (uplink GE port). It also connects to the middle NE via its GE2 port (subtending GE port).

Figure 6-5 Illustration of 3 NCT192 IP-DSLNCT192 are connected in a Daisy-Chain topology



This section depicts the manual VLAN-member port setting procedure of GE1 and GE2. The operator needs to choose the VLAN between 1 and 4094 to apply to GE ports when the following cases hold.

- GE1 port and GE2 port on NC is configured as tagged-only mode.
- GE2 port is configured as a subtended port

Enter to the "config nc" group directory to enable the subtending function.

CLI# config nc CLI(config nc)#

Table 6-11 shows the commands to perform the configuration of subtending port. 0 shows the usage of these commands as well as their related parameters.

Table 6-11 Subtending Configuration

The following command is to enable, disable, or show the subtend status of system.

CLI(config nc)# set subtend <option>

The following command is to set GE2 as a subtendded port (by "enable") or an uplink port. (by "disable")

CLI(config nc)# set subtend { *disabled* | *enabled*}

The following command is to add both of the GE ports as member-ports of vlan *<vid>*. (See the note at the end of this section to learn the usage of this command.)

CLI(config nc)#add subtend-vid <vid>

The following command is to configure both of the GE ports to be not the member-ports of the VLAN specified by *<vid>*.

CLI(config nc)#del subtend-vid <vid>

The following command is to configure both of the GE ports to be not the member-ports of any VLAN.

CLI(config nc)	#clear subtend-vid
----------------	--------------------

Parameters	Task
{ disabled / enabled}	Specify the GE2 as either a subtendded port or an uplink port.
	Enable: GE2 works as a subtend port of the NC
	Disable: GE2 works as an uplink port of the NC.
	Type: Mandatory
	Valid values: disabled enabled
<vid></vid>	Identify the vlan id of the VLAN which the GE ports belong to.
	Type: Mandatory
	Default value: 1
	Valid values: 1 ~ 4093
<option></option>	Configure the subtend function of system.
*	Valid values: enable, disable



RSTP and LACP can not work when the subtending function is enabled.

Example 58 The configuration of subtending port

1downenabledenableduplink2downdisabledenabledsubtend

Subtend VLAN ID:

n/a

Configuring the Cascading

In some network deployment environment, it is desired to cascade several IP-DSLNCT192 to share a single uplink as well as the same management IP address to the access network. Hereafter, the NE is said to be connected in a cascading topology when it is deployed in the aforementioned way. And the NE is said to run in the cascade mode. Figure 6-6 depicts a typical cascading topology.

Figure 6-6 Illustration of cascading topology



When the NEs are connected in a cascading topology, the NE plays either one of the following roles.

• Root-NE

The Root-NE indicates the NE which is directly connected to the L2 access network as shown in Figure 6-6. The Root-NE possesses 2 IP addresses.

- UGE IP: "UGE IP" is for the communication with the EMS server, LCT and Telnet hosts.
- root IP: "root IP" is for the communication with the Remote-NE. It is invisible to the network operator.
- Remote-NE

The Remote-NE indicates the NE which is is not directly connected to the L2 access network as shown in Figure 6-6. The Remote-NE possesses only one IP address.

■ UGE IP: "UGE IP" is for the communication with the Root-NE.



The following 2 IPs should be the same otherwise, the Root-NE can not communicate with Remote-NE.

- "remote-ne-ip" of the Root-NE
- "UGE IP" of the Remote-NE

In order for the operator to manage the NEs in a cascading topology as shown in Figure 6-6, the operator needs to set them to run in the cascade mode. After appropriate configurations on the Root-NE and Remote-NEs, these NEs will work as a single NE which possesses several shelves via the EMS.

This section depicts the CLI commands to set the NE to run in the cascade mode. Once the Remote-NE is properly set, the operators can manage the remote NEs via the Root-NE by the "clogin" CLI command to login the remote NE.

Enter to the "config mgt" group directory to enable the cascade management function.

CLI# config mgt CLI(config mgt)#

Table 6-11 shows the commands to perform the configuration of cascaded management. Example 59~Example 60 shows the usage of these commands as well as their related parameters.

Table 6-12 Cascaded Management Configuration

The following command is to enable the cascaded management (single IP management) of the NE.

CLI(config mgt)# cascade enable

The following command is to disable the cascaded management (single IP management) of the NE.

CLI(config mgt)# cascade disable

The following command is to set the role of the NE to be either "Root-NE" or "Remote-NE"

CLI(config mgt)# cascade set role {root | remote}

The following command is to add a NE into the "Remote-NE-list" of the Root-NE.

CLI(config mgt)# cascade add <remote-ne-id> <remote-ne-ip> [<note>]

The following command is to remove the remote NE from the "Remote-NE-list" of the Root-NE.

CLI(config mgt)# cascade del <remote-ne-id>

The following command is to set the user login account and password for the Root-NE to login the remote NE via Telent.

CLI(config mgt)# cascade set remote-account <remote-ne-id> <login-user> <login -password>

The following command is to set the community of the remote NE for the Root-NE to access the Remote-NE via SNMP.

CLI(config mgt)# cascade set remote-community <remote-ne-id> <community-name>

The following command is to enable/disable the Root-NE to be allowed to access the Remote-NE specified by <*remote-ne-id*>

CLI(config mgt)# cascade set remote-state <remote-ne-id> {disabled | enabled}

The following command is to set the IP address as well as the associated subnet for the Root-NE to communicate with the Remote-NE

CLI(config mgt)# cascade set root-ip <root-ne-ip> <net-mask>

The following command is to view the status of the cascaded management mode.

CLI(config mgt)# cascade show <remote-ne-id>

The following command is to view the status of the cascade connection.

CLI(status)# cascade show

The following command is to access the Remote-NE via Telnet.

CLI# clogin <remote-ne-id>

Parameters	Task
<remote-ne-id></remote-ne-id>	This specifies the identified number of remote NE Type: Mandatory Valid values: 1~2147483647
<remote-ne-ip></remote-ne-ip>	This specifies the IP address of the NE to be added into the "Remote-NE-list" of the Root-NE Type: Mandatory Valid values: Any valid class A/B/C address

Parameters	Task				
[<note>]</note>	This specifies the note the operator takes for the NE to be added into the "Remote-NE-list" of the Root-NE. Type: Mandatory Valid values: none				
<login-user></login-user>	This specifies the login user name for the Root-NE to login the remote NE via Telent. Type: Mandatory Valid values: String of up to 16 characters ('A' - 'Z', 'a' - 'z', '0' - '9', '-', '_, ', ', '@')				
<login -password=""></login>	This specifies the login user password for the Root-NE to login the remote NE via Telent Type: Mandatory Valid values: String of up to 16 characters ('A' - 'Z', 'a' - 'z', '0' - '9', '-', '_, ', '@')				
<community-name></community-name>	This specifies the community name for the Root-NE to access the remote NE via SNMP. Type: Mandatory Valid values: String of up to 16 characters ('A' - 'Z', 'a' - 'z', '0' - '9', '-', ', ', ' $(@)$ ')				
<root-ne-ip></root-ne-ip>	This specifies the IP address of the Root-NE for the Root-NE to communicate with the Remote-NE. Type: Mandatory Valid values: Any valid class A/B/C address				
<net-mask></net-mask>	This specifies the subnet mask associated with <i><root-ne-ip></root-ne-ip></i> to specifies a subnet where the Remote-NE to resides in Type: Mandatory Valid values: 255.0.00 ~ 255.255.255.255				
Th following settin • "Secured h "Secured h • "SNMP tra "SNMP tra	ng of the Root-NE and Remote-NEs are different. lost" of Remote-NE: must be set to be Root-NE. lost" of Root-NE: must be set to be LCT, EMS server and so on. up station" of Remote-NE: must be set to be Root-NE. up station" of Root-NE: must be set to be LCT, EMS server and so on.				
 Th following setting of the Root-NE and Remote-NEs must be the same. "SNMP community" of the read-write privileage. <login-user> and <login -password=""> of the read-write privileage.</login></login-user> "tagged mode" of the UGE ports: Either "tagged" or "untagged". Management VLAN setting: when the the UGE ports of Root-NE and Remote-NEs to be in "tagged" mode. The software version of NC. 					
Whenever the operator establishes a telnet session to access the Root-NE, he/she can use the "clogin" command to establish a telnet session to access Remote-NE. In such situation, he/she l to use the "logout" CLI command to close the telnet session between the Root-NE and Remote-NE before he/she close the telnet session between the host PC and Root-NE. Otherwise the operator can not "clogin" the Remote-NE anymore.					
 Hence the following rules should be followed strictly. "telnet time-out value between the Root-NE and host PC" should be set to longer t "telnet time-out value between the Root-NE and Remote-NE". Be carefully not to disconnect the "telnet session between the Root-NE and Remote-NE" hefore disconnect the "telnet session between the Root-NE and Remote-NE". 					

 Table 6-12
 Cascaded Management Configuration (Continued)



When deploying NEs to form a cascading topology as shown in Figure 6-7, the IP address of UGE ports of Remote-NE1 and Remote-NE2 have to be setup up frist. As can be seen in Figure 6-7, they are set as UGE IP#1 and UGE IP#2, respectively.

On the Root-NE, suppose the operator sets *<remote-ne-ip>* corresponding to Remote-NE1and Remote-NE2 as Remote IP#1 and Remote IP#2, respectively. In this situation, the operator has to let the following equations hold. Remote IP#1 = UGE IP#1 Remote IP#2 = UGE IP#2

Moreover, the Root IP of Root NE, UGE IP#1 and UGE IP#2, have to be set in the same subnet.





The LCT does not support to manage the Remote-NE.



The operators can upgrade the firmware of Remote-NE via FTP. (Please refer to the Section "NE Firmware Upgrade in Cascade mode" of Chapter 3)

Figure 6-7 Illustration the IP configuration of NEs in a cascading topology



Example 59 Configuration of NE to play the role of "Root-NE"

CLI(config mgt)# cascade set role root OK. CLI(config mgt)# cascade set root-ip 10.10.0.254 255.255.255.0 OK CLI(config mgt)# cascade add 1 10.10.0.1 Remote_NE1 OK CLI(config mgt)# cascade set remote-account 1 admin admin OK CLI(config mgt)# cascade set remote-community 1 netman OK CLI(config mgt)# cascade set remote-state 1 enabled OK CLI(config mgt)# cascade enable OK

```
[Cascaded management]
   control status: enabledcurrent role: rootcascaded root IP: 10.10.0.254
    cascaded root net mask : 255.255.255.0
[Remote NE ID: 1]
   CLI# config ip show
UGE
    IP address : 100. 168. 100. 100
    subnet mask : 255.255.0.0
    MAC address : 00:60:64:dc:7a:17
UGE VLAN ID : 4092
NME
    IP address : 10.12.3.63
subnet mask : 255.255.0.0
    MAC address : 00:60:64:dc:7a:16
Gateway
    IP address
                  : 10.12.1.252
```

CLI(config mgt)# cascade show

Example 60 Configuration of NE to play the role of "Remote-NE"

CLI# clogin 1

CLI#

```
Please type "@.<cr>" to locally close connection
Login:admin
Password:
```

CLI# config mgt CLI(config mgt)# cascade set role remote OK

CLI(config mgt)**# cascade enable** OK

CLI(config mgt)# cascade show

[Cascaded management]	
control status	: enabled
current role	: remote
cascaded root IP	:
cascaded root net mask	: 255.255.255.0

CLI# config ip show

UGE

IP address	:	10. 10. 0. 1
subnet mask	:	255.255.0.0
MAC address	:	00:01:03:05:07:09
UGE VLAN ID	:	4092

Managing the Network Interface

IP address	: 10.12.3.125
subnet mask	: 255.255.0.0
MAC address	: 00:01:55:66:11:22
Gateway	
IP address	: 10.12.1.252

Example 61 Monitoring the Cascade Connection Status on the Root-NE

CLI(status)# cascade show

[Cascaded man control s current n cascaded cascaded	nagement] status role root IP root net mask	: enabled : root : 10.10.0 : 255.255	. 254 . 255. 0	
remote ID	remote IP	admin status	oper status	note
1	10. 10. 0. 1	enabled	connected	Remote_NE1

Example 62 Monitoring the Cascade Connection Status on the Remote-NE

CLI# clogin 1

CLI# Please type "@.<cr>" to locally close connection Login:admin Password:

CLI# status cascade show

[Cascaded management]	
control status	: disabled
current role	: root
cascaded root IP	: 172.16.1.1
cascaded root net mask	: 255.255.255.0

CLI# config mgt cascade

CLI(config mgt cascade)# set role remote

OK

CLI(config mgt cascade)# exit CLI# status cascade show

INFO: This NE is not cascaded root.

Chapter 7 Managing the Connection Services

This chapter describes how to manage the system connection services and contains the following sections:

- VC-to-VLAN Connection Management
- Multicast Service Management
- Managing the Subscriber Access Services
- Configuring the Access Control List
- Configuring the System Services

VC-to-VLAN Connection Management

The VC-to-VLAN setting can easily define the multiple to one or one to one mapping; you can group different PVCs to a single VLAN ID as well as single PVC to one VLAN mapping. Figure 7-1 illustrates the basic principle for VLAN assignment in the NCT192 IP-DSLAM. As shown in Figure 7-1, the NE forwards five data flows, A~E, which may be either owned by the same subscriber or by different subscribers. It is noted that these data flows are conveyed in five individual ATM PVCs, and they are grouped into 3 individual VLANs.



The NE supports up to 8 PVCs per xDSL port. The NE supports up to 4094 VLANs per system.

Figure 7-1 VC-to-VLAN Mapping Illustration



According to IETF RFC2684, an IP packet is encapsulated in either bridged mode or routed mode. The VC-to-VLAN settings are similar but not the same in these two encapsulation modes. This section depicts their configuration separately.

The VC-to-VLAN configuration procedures are the same to both the ADSL port and SHDSL port.

More than one PVCs can be configured in a xDSL port. Each PVC can be configured with different RFC 2684 mode (either RFC 2684 routed mode or RFC 2684 bridged mode). However, the NE supports only one RFC 2684 mode to be enabled for the PVCs in a xDSL port. Different xDSL ports are allowed to have their PVCs to run with distinct RFC 2684 mode.

NOTE

Configuring a VC-to-VLAN Connection for the VC of RFC2684 Bridged Mode

In the RFC 2684 bridged mode, the NE needs to perform the following functions for the xDSL subscriber to access the Internet.

- For the upstream traffic
 - 1. Performs the ATM SAR (Segmentation and Reassembly) function to reassemble the ATM cells to get an ATM AAL5 frame.
 - 2. Strip off the ATM AAL5 tailer to get the RFC2684-encapsulated Ethernet frame.
 - 3. Strip off the RFC2684 header to get the Ethernet frame.
 - 4. Add a VLAN tag (Q_s) to the Ethernet frame if required. (see the definition of " Q_s " in the description of Table 6-9)
 - 5. Forward the Ethernet frame from the xDSL subscriber to ISP.
- For the downstream traffic
 - 1. Strip off the VLAN tag (Q_s) from the Ethernet frame if required. (see the definition of " Q_s " in the description of Table 6-9)
 - 2. Encapsulate the downstream Ethernet frame with RFC2684 header
 - 3. Append the ATM AAL5 tailer to the RFC2684-encapsulated Ethernet frame to get an ATM AAL5 frame.
 - 4. Performs the ATM SAR (Segmentation and Reassembly) function to segment the ATM AAL5 frame to get ATM cells.
 - 5. Forward the Ethernet frame from the ISP to the xDSL subscriber.

Enter to the "**config ucast**" sub-group directory to configure the bridged services of unicast connections.

CLI# config ucast CLI(config ucast)#

Table 7-1 shows the commands to perform the configuration of bridged services.Example 63~Example 65 shows the usage of these commands as well as their related parameters.

Table 7-1 Bridged Services Configuration

The following command is to create a new VC-to-VLAN connection on specific of xDSL line port.

CLI(config ucast)# add vcvlan <port-range> <vpi> <vci>

The following command is to remove the VC-to-VLAN connection on specific of xDSL line port.

CLI(config ucast)# del vcvlan cvci><vci>

The following command is to set the bridged VC-to-VLAN parameters on specific of xDSL line port.

CLI(config ucast)# set vcvlan <port-range> <vpi> <vci> <802_1p> <iptraffic-profile> bridged <vid>

The following command is to activate the VC-to-VLAN service on specific of xDSL line port.

CLI(config ucast)# enable vcvlan <vpi><vci>

The following command is to deactivate the VC-to-VLAN service on specific of xDSL line port.

CLI(config ucast)# disable vcvlan cvci><vci>

The following command is to set the FDB (filtering Database) non-aged mode on specific PVCs.

CLI(config ucast)# set fdb-non-aged <vpi><vci><vpi><vci><option>

Table 7-1 Bridged Services Configuration (continued)

The following command is to display the FDB (filtering Database) non-aged mode on specific PVCs.

CLI(config ucast)# show fdb-non-aged [port-range>]

The following command is to change the MAC limit on specific of xDSL line ports.

CLI(config ucast)# set mac-limit <port-range> <vpi> <vci> <pvc-mac-limit>

The following command is to display the MAC limit on specific of xDSL line ports.

CLI(config ucast)# show mac-limit [port-range>]

The following command is to display the VC-VLAN connection on specific of xDSL line ports.

CLI(config ucast)# show vcvlan [<port-range>]</port-range>				
Parameters	Task			
<port-range></port-range>	Identify the port range of the system wish to configure in bridged services. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.			
<vpi></vpi>	Defines the VPI (Virtual Path Identifier) value. Type: Mandatory Valid values: 0 ~ 255			
<vci></vci>	Defines the VCI (Virtual Channel Identifier) value. Type: Mandatory Valid values: 1 ~ 65535 (1 ~ 31 are reserved)			
<802_1p>	 Defines the tagging of VLAN 802.1p priority of egress switch fabric on specific of VC-to-VLAN connection. Type: Mandatory Default value: 0 Valid values: 0 ~ 7 (low ~ high) 			
<iptraffic-profile></iptraffic-profile>	Defines the IP traffic profile name. (See the Section "Configuring the IP Traffic Profile" of Chapter 4) Type: Mandatory Valid values: The name of "ip traffic profile"			
<vid></vid>	Defines the VLAN ID to be assign on specific of VC-to-VLAN connection. Type: Mandatory Default value: 1 Valid values: 1 ~ 4093			
<pvc-mac-limit></pvc-mac-limit>	Defines the limit of MAC address learning from specific bridged service per xDSL line port. Each xDSL line port allow maximum of 8 MAC address learning in total of VC-to-VLAN usage. Type: Mandatory Default value: 1 Valid values: 1 ~ 8			
<option></option>	 Enable or disable the FDB (filtering Database) non-aged mode on specific PVCs. Valid values: enable: to let the MAC entries dynamically learned from the specific PVCs never be aged. disable:to let the MAC entries learned from the specific PVCs be aged as in normally FDB aging process. 			

Example 63 Bridged Services Configuration of NE

CLI(config ucast)# add vcvlan 1.6 8 35 OK CLI(config ucast)# set vcvlan 1.6 8 35 0 ADSL_TRAF bridged 100 OK CLI(config ucast)# enable vcvlan 1.6 8 35 OK CLI(config ucast)# show vcvlan 1.6

port	ID	VP1/V	CI	IP-traffic	VLAN	1p	MAC	RFC2684	next-hop	admin	oper
1.	6	8/	35	ADSL_TRAF	100	0	1	bridged		enabled	up

Example 64 Bridged FDB Non-Aged Mode Configuration of NE

```
CLI(config ucast)# set fdb-non-aged 1.6 8 35 enabled
OK
CLI(config ucast)# show fdb-non-aged 1.6
port ID VPI/VCI non-aged
  1.6
        8/ 35 enabled
```

Example 65 Bridged MAC Limit Configuration of NE

8

CLI(config ucast)# set mac-limit 1.6 8 35 8 0K CLI(config ucast)# show mac-limit 1.6

port ID VPI/VCI mac-limit 8/ 35

1. 6

In the RFC 2684 bridged mode, the NE supports to IP counts <= MAC limit per PVC of xDSL port.

Configuring a VC-to-VLAN Connection for the VC of RFC2684 Routed Mode

In the RFC 2684 routed mode, the NE needs to perform the following functions for the xDSL subscriber to access the Internet.

- For the upstream traffic
 - 1. Performs the ATM SAR (Segmentation and Reassembly) function to reassemble the ATM cells to get an ATM AAL5 frame.
 - 2. Strip off the ATM AAL5 tailer to get the RFC2684-encapsulated IP packet.
 - 3. Strip off the RFC2684 header to get the IP packet.
 - 4. Prefix an Ethernet header to the IP packet. The prefixed Ethernet header is of the following setting.

Destination MAC = the MAC of Next-hop router toward the ISP's router. Source MAC = an unique MAC generated by the NE.

- 5. Add a VLAN tag (Q_s) to the Ethernet frame if required. (see the definition of " Q_s " in the description of Table 6-9)
- 6. Forward the Ethernet frame from the xDSL subscriber to ISP.
- For the downstream traffic
 - 1. Strip off the VLAN tag (Q_S) from the Ethernet frame if required. (see the definition of " Q_s " in the description of Table 6-9)
 - 2. Strip off the Ethernet header from the IP packet.
 - 3. Encapsulate the downstream IP packet with RFC2684 header
 - 4. Append the ATM AAL5 tailer to the RFC2684-encapsulated Ethernet frame to get an ATM AAL5 frame.
 - 5. Performs the ATM SAR (Segmentation and Reassembly) function to segment the ATM AAL5 frame to get ATM cells.
 - 6. Forward the Ethernet frame from the ISP to the xDSL subscriber.

In the RFC 2684 routed mode, IP packets are directly encapsulated, i.e., no MAC layer is presented. Through the IWF (Inter-Work Function) of IPoA of IP-DSLAM, it needs to prefix the Ethernet MAC layer for particular subscriber interface. The source MAC address is specially generated by IP-DSLAM, and the destination MAC address is the next-hop router toward the ISP's router. The NE determines the MAC address of next-hop router by the (Address Resolution Protocol (ARP).

Figure 7-2 illustrates an example of the IWF in the case of RFC 2684 routed mode.

Figure 7-2 RFC 2684 Route Mode Connection Method





When you set the IP of "Next Hop", the NE will send ARP to query the MAC of the "Next Hop". When the MAC you observe is 00:00:00:00:00:00; it indicates something wrong such that the NE can not get the MAC of the Next-Hop router via ARP.

Enter to the "**config ucast**" sub-group directory to configure the routed services of unicast connection.

CLI**# config unast** CLI(config ucast)#

Table 7-2 shows the commands to perform the configuration of routed services. Example 66 shows the usage of these commands as well as their related parameters.

Table 7-2 Routed Services Configuration

The following command is to create a new VC-to-VLAN connection on specific of xDSL line port.

CLI(config ucast)# add vcvlan <port-range> <vpi> <vci>

The following command is to create a new ISP (Internet Service Provider) connection.

CLI(config ucast)# add nexthop <ispname> <ip-addr><vid>

The following command is to remove the VC-to-VLAN connection on specific of xDSL line port.

CLI(config ucast)# del vcvlan <port-range> <vpi> <vci>

The following command is to remove the ISP connection.

CLI(config ucast)# del nexthop <ispname>

The following command is to activate the VC-to-VLAN service on specific of xDSL line port.

CLI(config ucast)# enable vcvlan <port-range> <vpi> <vci>

The following command is to deactivate the VC-to-VLAN service on specific of xDSL line port.

CLI(config ucast)# disable vcvlan <vri><vri><vri><vri><vri>

The following command is to change the routed VC-to-VLAN parameters on specific of xDSL line port.

CLI(config ucast)# set vcvlan <port-range> <vpi> <vci> <802_1p> <iptraffic-profile> routed <ispname>

Parameters	Task
<port-range></port-range>	Identify the port range of the system wish to configure in routed services.
1 0	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
<vpi></vpi>	Defines the VPI (Virtual Path Identifier) value.
	Type: Mandatory
	Valid values: $0 \sim 255$
<vci></vci>	Defines the VCI (Virtual Channel Identifier) value.
	Type: Mandatory
	Valid values: $1 \sim 65535 (1 \sim 31 \text{ are reserved when VPI equal } 0)$
<ispname></ispname>	Defines the ISP name for routed service.
1 I	Type: Mandatory
	Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '@').
<ip-addr></ip-addr>	Defines IP address of the ISP server.
I I	Type: Mandatory
	Valid values: 0.0.0.0 ~ 255.255.255.255
<vid></vid>	Defines the VLAN ID to be assign on specific of VC-to-VLAN connection.
	Type: Mandatory
	Default value: 1
	Valid values: $1 \sim 4093$
<802_1p>	Defines the tagging of VLAN 802.1p priority of egress switch fabric on specific of VC-to-VLAN connection.
	Type: Mandatory
	Default value: 0
	Valid values: $0 \sim 7 (low \sim high)$
<iptraffic-profile></iptraffic-profile>	Defines the created IP traffic profile name.
* vv * v	Type: Mandatory
	Valid values: The name of "ip traffic profile"

Example 66 Configure the routed services of NE (Jack_Changed->Revision)

CLI(config ucast)**# add nexthop PC1 192.168.192.63 100** OK

CLI(config ucast)**# add vcvian 1.37 8 35** OK
CLI(config ucast)# set vcvlan 1.37 8 35 0 ADSL_TRAF routed PC1 OK CLI(config ucast)# enable vcvlan 1.37 8 35 OK CLI(config ucast)# show vcvlan 1.37 port ID VPI/VCI IP-traffic VLAN 1p MAC RFC2684 next-hop admin oper 1 37 8 35 ADSL_TRAF 100 0 1 bridged PC1 enabled up

Monitoring the VC-to-VLAN Connection Status

Enter to the "config ucast" sub-group directory to monitoring the unicast connection status.

CLI# config ucast CLI(config ucast)#

Table 7-3 shows the commands to perform the unicast connection status of NE. Example 67 shows the usage of these commands as well as their related parameters.

Table 7-3 Unicast Connection Status Monitor

The following command is to view the VC-to-VLAN connection of specific xDSL line port.

CLI(config ucast)# show vcvlan [<port-range>]

The following command is to view the status of ISP server use for routed services.

CLI(config ucast)# show nexthop

The following command is to view the launched service type of specific xDSL line port.

CLI(config ucast)# show servicetype [port-range>]

The following command is to view the various error code to identify the PVC errors.

CLI(config ucast)# show error-code <code-value>

Parameters	Task
<port-range></port-range>	Identify the port range of the system wish to view the VC-to-VLAN connection. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<code-value></code-value>	Identify the PVC error code to form with '0xNNNNNNN' where N is the hex between 0 to f. Type: Mandatory Valid values: 0x00000000-0xffffffff.

Example 67 Displaying the unicast connection status

CLI(config ucast)# sh	now vcvlan 1.6
------------------------------	----------------

port	ID	VP1/\	/C1	IP-traffic	VLAN	1p	MAC	RFC2684	next-hop	admin	oper
1.	6	8/	35	ADSL_TRAF	100	0	1	bridged		enab l	ed up
CLI(c	onf	ig uca	ast)#	show nexthop							
		next-	-hop i	name	next-	-ho	D IP		MAC	VLAN	status
				PC1 1	192.16	8.6	63.10	00 00:18:	f3:91:99:50	100	inactive

CLI(config ucast)# show servicetype 1.6

port		RFC2684	STC	runtime	configured	base	IP
ID	VPI/VCI	mode	status	service-type	service-type	IP address	count
1.6	8/ 35	bridged	disabled	pure-bridge	DHCP	0.0.0.0	1

Example 68 Displaying the various error code to identify the PVC errors

CLI(config ucast)# show error-code Ox000000F

Bit 0: PVC is nonexistent. Bit 1: PVC has enabled. Bit 2: PVC values are not changed.

CLI(config ucast)# show error-code Ox0000EEE

Bit 1: PVC has enabled.

Bit 2: PVC values are not changed.

Bit 4: Number of enabled VPI/VCI pair variety on this LC is maximum(32).

Bit 5: PVC amount on this port has reached maximum(8).

Bit 6: Sum of enabled PVC and MCAU on port has reached maximum(8).

Bit 8: No IP traffic profile is assigned on this PVC.

Bit 9: On this bridged PVC, service type IP amount is greater than MAC limit.

Bit10: On this routed PVC, service type IP amount is greater than 8.

Multicast Service Management

Whenever the subscriber clicks his remote controller to watch a TV channel transmitted via the ADSL line, the set-top-box sends the corresponding IGMP report packet. The NE will forward IGMP packet if its multicast IP hits the associated multicast service profile. Otherwise, the NE drops the IGMP packet. As a result, the subscriber is restricted to watch the TV progrNCT192 that he booked.

To provide multicast service, the operator needs to properly configure the multicast channel and IGMP snooping /IGMP proxy. This section contains the following two subsections.

- Configuring Multicast Channel
- IGMP Snooping/Proxy Setting

Configuring Multicast Channel

The NE supports to prevent the subscriber to receive un-booked TV channel (multicast channel) by checking the received "IGMP join" packet with a preconfigured Multicast Service Profile. (A Multicast Service Profile consists of a number of Multicast Channel Profiles.) The subscriber is restriced to receive the TV channels (recorded in the Multicast Channel Profile).

This sub-section depicts the CLI commands to associate the ADSL subscriber with the created Multicast Service Profiles.

Refer for the CLI commands to create Multicast Channel Profiles and Multicast Service Profiles in Section "Configuring the Multicast Service Related Profile" of Chapter 4.

Enter to the "config mcau" sub-group directory to configure the multicast connection.

CLI# config mcau CLI(config mcau)#

Table 7-4 shows the commands to perform the multicast connection status of NE. Example 69 shows the usage of these commands as well as their related parameters.

Table 7-4 Multicast Services Configuration

The following command is to remove the multicast service on specific of xDSL line port.

CLI(config mcau)# del <port-range>

The following command is to activate the multicast service on specific of xDSL line port.

CLI(config mcau)# enable <port-range>

The following command is to deactivate the multicast service on specific of xDSL line port.

CLI(config mcau)# disable <port-range>

The following command is to change the multicast service with desired parameters on specific of xDSL line port.

CLI(config mcau)# set <vpi><vci><vlan-id> <channel-limit> <mservice-name>

The following command is to show the multicast service with desired parameters on specific of xDSL line port.

CLI(config mcau)# show [<port-range>]</port-range>			
Parameters	Task		
<port-range></port-range>	Identify the port range of the system wish to configure in multicast services.		
	Type: Mandatory		
	Valid values: See the Section "Port Interface Indication" of Chapter 3.		
<vpi></vpi>	Defines the VPI (Virtual Path Identifier) value.		
*	Type: Mandatory		
	Default value: 8		
	Valid values: $0 \sim 255$		
<vci></vci>	Defines the VCI (Virtual Channel Identifier) value.		
	Type: Mandatory		
	Default value: 35		
	Valid values: $1 \sim 65535 (1 \sim 31 \text{ are reserved})$		
<channel-limit></channel-limit>	Defines the limit of concurrent multicast channel transmission on specific of VC-to-VLAN		
	connection.		
	Type: Mandatory		
	Default value: 1		
	Valid values: 1 ~ 5		
<vlan-id></vlan-id>	Defines the VLAN ID to be assign to a multicast VLAN		
	Type: Mandatory		
	Default value: 1		
	Valid values: $1 \sim 4093$		
<mservice-name></mservice-name>	This specifies the multicast service profile name		
	Type: Mandatory		
	Valid values: String of up to 32 characters ('0'~'9', 'A'~Z', 'a'~'z', '-', '_', '@').		

Example 69 Display the multicast connection status

CLI(config mcau)# set 1.6 8 35 100 1 program_1 OK CLI(config mcau)# enable 1.6 OK CLI(config mcau)# show 1.6 <u>port ID VPI/VCI VLAN limit service-profile status</u> 1. 6 8/ 35 100 1 program_1 enabled

IGMP Snooping/Proxy Setting

The NE supports IGMP snooping and IGMP proxy as follows.

- IGMP snooping:
 - When the IGMP snooping function is enabled,
 - 1. The NE starts to "listen in" IGMP conversations between hosts and routers.
 - 2. Once the NE hears an "IGMP join" message on an xDSL interface, it checks the associated Multicast Service Profile to prevent the subscriber to receive un-booked TV channels (multicast channel).
 - 3. If the multicast group IP of the received "IGMP join" message "hits" the Multicast Service Profile, the NE adds that xDSL interface to the corresponding multicast forwarding table and forwards this "IGMP join" message out of the GE port.
 - Otherwise, the NE drops the "IGMP join" message.
 - 4. As the NE hears an "IGMP leave" message or the 'snooping aging-time' expires, the NE will remove that xDSL interface from the corresponding multicast forwarding table.
 - IGMP proxy:

When the IGMP proxy function is enabled,

- 1. The NE starts to "listen in" IGMP conversations between hosts and routers.
- 2. Once it recieves an "IGMP join" message from the subscribers, it checks the associated Multicast Service Profile to prevent the subscriber to receive un-booked TV channels (multicast channel).
- 3. If the multicast group IP of the received "IGMP join" message "hits" the Multicast Service Profile, the NE adds that xDSL interface to the corresponding multicast forwarding table. And the NE further checks if it already forwards the TV channel requested by this "IGMP join" message. If the answer is YES, the NE drops this "IGMP join" message. Otherwise, the NE sends an "IGMP join" message to request that TV channel via the GE port. If the multicast group IP of the received "IGMP join" message "missage" the

If the multicast group IP of the received "IGMP join" message "misses" the Multicast Service Profile, the NE drops the "IGMP join" message.

4. As the NE receives an "IGMP leave" message or the 'response-time' expires, the NE will remove that xDSL interface from the corresponding multicast forwarding table.

Follow the commands to configure the IGMP snooping or proxy function.

Enter to the "config igmp" sub-group directory to configure the related parameters.

CLI**# config igmp** CLI(config igmp)**#**

Table 7-5 shows the commands to set the IGMP snooping and proxy functions of NE. Example 70 shows the usage of these commands as well as their related parameters.

Table 7-5 IGMP Snooping/Proxy Setting

The following command is to activate the IGMP snooping or proxy function for multicast services.

CLI(config igmp)# enable <i gmp-mode>

The following command is to deactivate both the IGMP snooping and proxy function for multicast services.

CLI(config igmp)# disable

The following command is to enable the IGMP proxy to perform "immediated-leave" function or not. (see the note below)

CLI(config igmp)# proxy set immediated-leave <option>

The following command is to configure the IGMP proxy response time against the subscriber link.

CLI(config igmp)# proxy set response-interval <interval>

The following command is to configure the IGMP proxy retry counter.

CLI(config igmp)# proxy set retries <times>

The following command is to enable the IGMP snooping to perform "immediated-leave" function or not. (see the note below)

CLI(config igmp)# snooping set immediated-leave <option>

The following command is to configure the IGMP snooping response time against the subscriber link.

CLI(config igmp)# snooping set response-interval <interval>

The following command is to configure the IGMP snooping retry counter.

CLI(config igmp)# snooping set retries <times>

The following command is to configure the aging time of IGMP Snooping.

CLI(config igmp)# snooping set aging-time <sec>

The following command is to configure the stateful mode of IGMP packets.

CLI(config igmp)# set stateful <level>

The following command is to viewing the IGMP status.

CLI(config igmp)# show

The following command is to set the IGMP version for query.

CLI(config igmp)# version query <version-type>

The following command is to set the IGMP version for report and leave.

CLI(config igmp)# version report-leavel < version-type >

Parameters		Task	
<igmp-mode></igmp-mode>		Define the IGMP mode for multicast services Type: Mandatory Valid values: proxy snooping	
<option></option>		Enable the IGMP snooping or proxy to perform "immediated-leave" function or not Type: Mandatory Valid values: disabled enabled	
<sec></sec>		Defines the IGMP snooping aging time in second. Type: Mandatory Valid values: 30 ~ 3600 (sec.) Default value: 300 (sec.)	
<interval></interval>		Defines the time period waiting for subscriber response the IGMP message. Type: Mandatory Valid values: 1 ~ 30 (sec.) Default value: 30 (sec.)	
<times></times>		Defines the retry counting for STB response the IGMP message, if the system did not receive IGMP message from subscriber edge, system will treat as 'leave' hence will stop the multicast stream to the particular link. Type: Mandatory Valid values: 1 ~ 5 Default value: 3 (count.)	
<level></level>		Define the print out mode when system receives IGMP packets. Type: Mandatory Valid values: none flow msg None – show nothing Flow – show flow state only Msg – show packet flag and error message	
< version-type >		 Define the IGMP version type for the NE to launch/relay the IGMP query, report and leave message. Type: Mandatory Valid values: v2 v3 auto v2 - Indicate to force the NE to launch the IGMP packets of version 2 no matter what version of IGMP packet it receives v3 -Indicate to force the NE to launch the IGMP packets of version 3 no matter what version of IGMP packet it receives auto -Indicate to launch/relay the IGMP packets of version the same as the version of IGMP packet it receives. 	
•	 If "Immediate Leave" is enabled: The NE will stop forwarding the multicast stream once it receives the corresponding IGI "leave" packet. That is, the TV image should be "freezed" immediately If "Immediate Leave" is disabled: The NE will react on the received IGMP "leave" packet and start the "leave" process as follows. 1. The NE will re-send the "IGMP query" packet 'Robustness (Query Retry)' times if does not receive "IGMP join". 2. The time interval between 2 consecutive "IGMP query" packets is 'Query Response Interval' seconds. 3. During the of "leave" process, if the NE receives the corresponding "IGMP join" p it continues to forward the multicast stream and stops the "leave" process. 4. At the end of "leave" process, the NE will stop forwarding the multicast stream if i not receive any "IGMP join" packet. 		

 Table 7-5
 IGMP Snooping/Proxy Setting (Continued)

Example 70 Configure the IGMP proxy and display its status

CLI(config igmp)**# proxy set immediate-leave enabled** OK

CLI(config igmp)# proxy set response-interval 300

OK	
CLI(config igmp) # proxy set OK	retrials 3
CLI(config igmp) # enable pro OK	ХУ
CLI(config igmp)# show	
<pre>IGMP proxy status immediate leave retrials response interval IGMP snooping status immediate leave aging time retrials response interval</pre>	: enabled : enabled : 3 : 300 in 1/10 sec : disabled : enabled : 30 sec : 2 : 100 in 1/10 sec
IGMP version query version report/leave version	: v2 : auto
Stateful level	: none - show nothing

Example 71 Configure the IGMP snooping and display its status

```
CLI(config igmp)# snooping set immediate-leave enabled
OK
CLI(config igmp)# snooping set response-interval 300
OK
CLI(config igmp)# snooping set retrials 3
OK
CLI(config igmp)# snooping set aging-time 30
OK
CLI(config igmp)# set stateful flow
OK
CLI(config igmp)# enable snooping
OK
CLI(config igmp)# show
IGMP proxy
    status: disabledimmediate leave: enabledretrials: 3response interval: 300 in 1/10 sec
IGMP snooping
   status: enabledimmediate leave: enabledaging time: 30 secretrials: 3
    response interval : 300 in 1/10 sec
IGMP version
    query version : v2
```

```
report/leave version : auto
Stateful
level : flow - show flow state only
```

Example 72 Configure the IGMP version for query, report and leave

CLI(config igmp) # version OK	query v2
CLI(config igmp) # version OK	report-leave v3
CLI(config igmp) # show IGMP proxy	
status	: disabled
immediate leave	: disabled
retrials	: 3
response interval	: 30 in 1/10 sec
IGMP snooping	
status	: enabled
immediate leave	: enabled
aging time	: 30 sec
retrials	: 2
response interval	: 100 in 1/10 sec
IGMP version	
query version	: v2
report/leave version	: v3
Stateful	
level	: none - show nothing

Monitoring the IGMP Snoopy/Proxy Information

Enter to the "**status igmp**" sub-group directory to display the IGMP snoop and proxy information with associated xDSL line port.

CLI**# status igmp** CLI(status igmp)#

Table 7-6 shows the commands to set the IGMP snooping and proxy information of NE. Example 73 shows the usage of these commands as well as their related parameters.

Table 7-6 Viewing IGMP Proxy Information

The following command is to view the IGMP group (IP) with associated xDSL line port.			
CLI(status igmp)# group show [<group-ip>]</group-ip>			
The following command is to show IGMP member information on this port.			
CLI(status igmp)# member show <port-id></port-id>			
Parameters	Task		
<group-ip></group-ip>	Defines class D IP addressing for multicast channel Type: Mandatory Valid values: 224.0.1.0 ~ 239.255.255.255		
<port-id></port-id>	Identify the port ID of the system line card Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.		

```
CLI(status igmp)# group show
Current IGMP: IGMP Snooping
Group IP [234.5.1.1]

        group MAC
        : 01:00:5e:05:01:01

        last reporter
        : 10.10.10.10

        up time
        : 00:00:00:50

        last port
        : 1.37

    member counter : 1
    member port :
          slot [ 1]: 37
          slot [ 2]: none
          slot [3]: none
          slot [4]: none
          uge
                    : none
CLI(status igmp)# member show 1.37
Current IGMP: IGMP Snooping
     port-ID group-IP state
           .....
                                       -----
         1.37 234.5.1.1 active
```

Example 73 Display the IGMP snooping/proxy information

Managing the Subscriber Access Services

The system supports the so-called "service type control" function to restrict the type of traffic to be forwarded on the PVC of individual subscriber.

- In RFC2684 routed mode, the following service type is supported.
 - Static IP
- In RFC2684 bridged mode, the following three service types are supported.
 - PPPoE
 - DHCP
 - Static IP

Enter to the "config ucast" sub-group directory to manage the access service control.

CLI**# config ucast** CLI(config ucast)#

Table 7-7 shows the commands to perform the access services configuration of NE. Example 74 shows the usage of these commands as well as their related parameters.

Table 7-7 Access Services Configuration

The following command is to define the access service of particular PVC.

CLI(config ucast)# set servicetype <port-range> <vpi> <vci> <mode>

The following command is to define the authentic IP in static IP access mode.

CLI(config ucast)# set servicetypestaticip <port-range> <vpi> <vci> <staticipbase> <iplimit>

The following command is to view the access service status in specific Subscriber port interface.

CLI(config ucast)# show servicetype <port-range>

Parameters	Task
<port-range></port-range>	Identify the port range of the system line card
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
< <i>vpi</i> >	Defines the VPI (Virtual Path Identifier) value.
	Type: Mandatory
	Valid values: $0 \sim 255$
<vci></vci>	Defines the VCI (Virtual Channel Identifier) value.
	Type: Mandatory
	Valid values: $1 \sim 65535 (1 \sim 31 \text{ are reserved})$
<staticipbase></staticipbase>	This specifies the base of the IP address if the service type is Static IP
-	Type: Mandatory
	Valid values: Any valid class A/B/C address
	Default value: None
<iplimit></iplimit>	This specifies the maximum IP counter when the service type is either "DHCP" or "Static IP".
*	Type: Mandatory
	Valid values: $1 \sim 8$
<mode></mode>	This specifies the authentic of access service mode in particular PVC.
	Type: Mandatory
	Valid values: pppoe, dhcp, static ip

Example 74 Configure the static IP access service

```
CLI(config ucast)# set servicetypestaticip 1.6 8 35 192.168.1.1 1
OK
CLI(config ucast)# set servicetype 1.6 8 35 staticip
OK
CLI(config ucast)# show servicetype 1.6
port RFC2684 STC runtime configured base
ID VPI/VCI mode status service-type service-type IP address
```

1. 6 8/ 35 bridged disabled pure-bridge



The CLI commands in this section take effect only when the **service-type** setting of ADSL LC is enabled. Please refer to Table 5-6 for the related commands.

static-IP

IP

192.168.1.1

count

1



Enabling the Service Type Control makes the NE to provide the IP/MAC anti spoofing function.

- In the case that the subscriber acquires his IP address dynamically via PPPoE The NE will block the subscriber's traffic before a valid IP address assignment. Once the subscriber possesses a valid dynamic IP, the NE will just forward the packet of valid source MAC addresses. In other words, the NE drops the subscriber's traffic of invalid source MAC addresses
- In the case that the subscriber acquires his IP address dynamically via DHCP The NE will block the subscriber's traffic before a valid IP address assignment. Once the subscriber possesses a valid dynamic IP, the NE will just forward the packet of valid source IP/MAC addresses. In other words, the NE drops the subscriber's traffic of invalid source IP/MAC addresses.
- In the case that the subscriber possesses static IP address The NE will just forward the packet of valid source IP/MAC addresses. In other words, the NE drops the subscriber's traffic of invalid source IP/MAC addresses.

Configuring the Access Control List

This section describes the configurations of the following 2 kinds of Access Control List (ACL).

- Source MAC Access Control List
- Filtering the NetBIOS and NetBEUI

Source MAC Access Control List

The NE supports the VC-to-VLAN ACL function is to provide the operator a tool to manually deny/permit the ADSL subscriber's upstream Ethernet frame according to their source MAC addresses.

For example, if there are duplicate MAC addresses from two or more individual xDSL subscriber ports, the operator should deny the hacker's traffic and permit the good guy's traffic. With the VC-to-VLAN ACL function, the operator can manually set to permit (forward) one of them and deny the rest traffic. (or via the CLI commands depicts in Section "Filtering the Upstream Traffic of Spoofed MAC" of Chapter 7)



The VC-to-VLAN ACL function is to apply to the specified PVC on the ADSL line only.



The roles of access control function, Deny and Permit, are repulsive, i.e. a "deny" role will be replaced while a new role "permit" is be configured.

Enter to the "config fdb" sub-group directory to manage the ACL statement.

CLI# config fdb CLI(config fdb)#

Table 7-8 shows the commands to configure the access control list of NE. Example 75 shows the usage of these commands as well as their related parameters.

Table 7-8 Access Control List Configuration

The following command is to add the ACL permission of the specified MAC addresses on specified xDSL line port.

CLI(config fdb)# add acl port-id> <vpi> <vci> <mac-addr> <mode>

The following command is to remove the specified MAC addresses of specified xDSL line port.

CLI(config fdb)# del <port-id> <vpi> <vci> <mac-addr>

The following command is to display the FDB entries on specified xDSL line ports

CLI(config fdb)# show [<port-range>]

Parameters	Task
<port-range></port-range>	Identify the port range of the system wish to configure in bridged services. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<port-id></port-id>	Identify the port id of the system wish to display current list of learning MAC addresses from their remote network. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<vpi></vpi>	Defines the VPI (Virtual Path Identifier) value. Type: Mandatory Valid values: 0 ~ 255
<vci></vci>	Defines the VCI (Virtual Channel Identifier) value. Type: Mandatory Valid values: 1 ~ 65535 (1 ~ 31 are reserved)
<mac-addr></mac-addr>	Indicate the target MAC address. Type: Mandatory Valid values: Valid MAC addresses form. (for example: 00:1F:AA:19:78:03)
<mode></mode>	Defines the ACL action of specific MAC address in the PVC connection. Permit or deny the specific MAC addresses of xDSL line port where addresses are learned. Type: Mandatory Valid values: permit, deny

Example 75 Configure the access control list

CLI(config fdb)# add acl 1.6 8 35 00:60:64:dc:7a:15 permit OK

CLI(config fdb)# show 1.6

port	ID	VP1/V	/CI	MAC address	VLAN	type
1.	6	8/	35	00:60:64:dc:7a:15	100	AP

Filtering the NetBIOS and NetBEUI

The NE allows the operator to configure to forward or drop the name server protocol (NetBIOS and NetBEUI) traffics received on the subscriber interfaces and network interfaces.

Enter to the "**config filter**" sub-group directory to define the NetBIOS and NetBEUI filtering function.

CLI# config filter CLI(config filter)#

Table 7-9 shows the commands to filter the NetBIOS and NetBEUI packets. Example 76 shows the usage of these commands as well as their related parameters.

Table 7-9 NetBIOS and NetBEUI Filter

The following command is to define the action NetBIOS and NetBEUI filtering.

CLI(config filter)# netbios <netbios-action>

The following command is to display current setting of NetBIOS and NetBRUI filtering.

CLI(config filter)# show	
Parameters	Task
<netbios-action></netbios-action>	Identify the NetBIOS and NetBEUI filtering action. Type: Mandatory Valid values: drop, forward

Example 76 NetBIOS and NetBEUI Filtering

CLI(config filter)**# netbios drop** OK

CLI(config filter)# **show**

NetBIOS filter action: drop

Configuring the System Services

This section describes the configurations of the following System Services.

- DHCP Broadcast Control
- DHCP Relay Setting
- DHCP Relay Option 82 Setting
- Configuring the PPPoE Suboption
- Configuring the VLAN MAC Limitation
- Configuring MAC Aging for Bridged Services
- Monitoring the VLAN Member Set
- Filtering the Upstream Traffic of Spoofed MAC
- Monitoring the Subscriber MAC

DHCP Broadcast Control

Users can set the DHCP broadcast packet rate limit and set the action to be applied to the out-of-profile traffic on a per-NE basis.

Enter to the "config dhcp" sub-group directory to configure the DHCP broadcast control.

CLI**# config dhcp** CLI(config dhcp)**#**

Table 7-10 shows the commands to perform the DHCP broadcast control. Example 77 shows the usage of these commands as well as their related parameters.

Table 7-10 DHCP Broadcast Control

The following command is to define the action to the DHCP packets which exceed the specified <rate-limit>.

CLI(config dhcp)# set bc <rate-limit> <action>

The following command is to disable the DHCP broadcast control

CLI(config dhcp)# disable bc

The following command is to enable the DHCP broadcast control

CLI(config dhcp)# enable bc

The following command is to display the DHCP broadcast control information

CLI(config dhcp)# show

Parameters	Task
<action></action>	Defines the action to be applied to the DHCP broadcast packets which exceed the specified < <i>rate-limit></i> .
	Type: Mandatory
	Valid values: none, drop, alarm, both
	none – do nothing
	drop – drop DHCP broadcast packets
	alarm - send alarm to the configured trap host (NCT192 LCT or NCT192 EMS Server)
	both- drop DHCP broadcast packets and send alarm
	Default value: none
<rate-limit></rate-limit>	Defines the rate limit of DHCP broadcast packets
	Type: Mandatory
	Valid values: $1 \sim 100000 \text{ (pkts/sec.)}$
	Default value: 100 (pkts/sec.)



When the action is set to be either "alarm" and "Drop packet and send alarm", the NE will launch SNMP traps to the SNMP trap managers as specified in the Section "Configuring the IP Address of SNMP Trap Station" of Chapter 3.

Example 77 Configure the DHCP broadcast control

CLI(config dhcp)# set bc 1000 both 0K CLI(config dhcp)# enable bc 0K CLI(config dhcp)# show DHCP option82 : disabled broadcast control : enabled rate limit : 1000 pkts/sec action over rate limit : both (drop & alarm) : none - show nothing stateful level DHCP relay : disabled relay server : no server exists

DHCP Relay Setting

The DHCP relay intercepts the DHCP request packets from subscriber interface and forwards them to the specified DHCP server. In the opposite direction, the DHCP relay transfers the DHCP reply packets from DHCP server to the specified xDSL subscriber.

Enter to the "config dhcp" sub-group directory to configure the DHCP relay.

CLI**# config dhcp** CLI(config dhcp)#

Table 7-11 shows the commands to perform the DHCP relay server configuration. Example 78 shows the usage of these commands as well as their related parameters.

Table 7-11 DHCP Relay Setting

The following command is to define the DHCP relay server and its correspondent VLAN ID.

CLI(config dhcp)# add relay-server <server-ip>

The following command is to remove the DHCP relay server IP

CLI(config dhcp)# del relay-server <server-ip>

The following command is to enable the DHCP relay functionality.

CLI(config dhcp)# enable relay

The following command is to disable the DHCP relay functionality.

CLI(config dhcp)# disable relay

The following command is to configure the stateful mode of DHCP packets.

CLI(config dhcp)# set stateful <*level*>

The following command is to view the DHCP relay status.

CLI(config dhcp)# show

Parameters	Task
<server-ip></server-ip>	This specifies the IP address of DHCP server.
-	Type: Mandatory
	Valid values: Any valid class A/B/C address
	Default value: None
<level></level>	Define the print out mode when system receives DHCP packets.
	Type: Mandatory
	Valid values: none flow pf all
	None – show nothing
	Flow – show flow state only
	Pf – show packet content and flow state
	All – all content with hexadecimal data

Example 78 Set the DHCP relay server

CLI(config dhcp)# add relay-server 192.168.192.1

0K CLI(config dhcp)# enable relay OK CLI(config dhcp)# set stateful flow OK CLI(config dhcp)# show : disabled option82 broadcast control : enabled broadcast rate limit : 1000 pkts/sec : both (drop & alarm) broadcast action stateful level : flow - show flow state only relay : enabled relay server 1 : 192.168.192.56 relay server 2 : 192.168.192.1

DHCP Relay Option 82 Setting

Enter to the "config dhcp" sub-group directory to configure the DHCP relay option 82.

CLI**# config dhcp** CLI(config dhcp)#

Table 7-12 shows the commands to perform the DHCP Relay Option 82 configuration. Example 79 shows the usage of these commands as well as their related parameters.

Table 7-12 DHCP Relay Option 82 Setting

The following command is to enable the DHCP relay option 82 functionality.

CLI(config dhcp)# enable op82

The following command is to disable the DHCP relay option 82 functionality.

CLI(config dhcp)# disable op82

Example 79 Configure the DHCP Relay Option 82

CLI(config dhcp)# enable op82

OK

CLI(config dhcp)# show

option82	: enabled
broadcast control	: disabled
broadcast rate limit	: 100 pkts/sec
broadcast action	: both (drop & alarm)
stateful level	: none - show nothing
relay	: disabled
relay server	: no server exists



The setting of DHCP option 82 contents is performed by configuring the xDSL Port Agent ID. (See the Section "Configuring the ADSL Line Port" of Chapter 5)

Configuring the PPPoE Suboption

PPPoE sub-option has similar mechanism as DHCP option 82. The NE can insert Circuit ID and Remote ID in all upstream PPPoE packets in the PPPoE discovery stage, i.e. the PADI, PADR and upstream PADT packets.



The setting of PPPoE sub-option contents is performed by configuring the xDSL Port Agent ID

Enter to the "config pppoe" sub-group directory to configure the PPPoE suboption.

CLI# config pppoe CLI(config pppoe)#

Table 7-13 shows the commands to perform the PPPoE suboption configuration. Example 80 shows the usage of these commands as well as their related parameters.

Table 7-13 PPPoE Suboption Setting

The following command is to enable the PPPoE suboption function.

CLI(config pppoe)# enable suboption

The following command is to disable the PPPoE suboption function.

CLI(config pppoe)# disable suboption

The following command is to configure the stateful mode of PPPoE packets.

CLI(config pppoe)# set stateful <level>

The following command is to display the PPPoE suboption and stateful information.

CLI(config pppoe)# show

Parameters	Task
<level></level>	Define the print out mode when system receives PPPoE packets.
	Type: Mandatory
	Valid values: none flow msg
	none – show nothing
	flow – show flow state only
	msg – show flow message

Example 80 Configure the PPPoE suboption

```
CLI(config pppoe)# set stateful flow
OK
CLI(config pppoe)# enable suboption
OK
CLI(config pppoe)# show
suboption : enabled
stateful level : flow
```

Configuring the VLAN MAC Limitation

To limit the number of source MAC address learned in a specific VLAN, the users can enable the MAC limiting function and configure the upper limit of allowed MAC for a specific VLAN.

Enter to the "config vlan-mac-limit" sub-group directory to manage the VLAN MAC limitation.

```
CLI# config vlan-mac-limit
CLI(config vlan-mac-limit)#
```

Table 7-14 shows the commands to perform the VLAN MAC limiting configuration. Example 81 shows the usage of these commands as well as their related parameters.

Table 7-14 VLAN MAC Limiting Configuration

The following command is to enable or disable the MAC limiting of specific VLAN ID.

CLI(config vlan-mac-limit)# set <vid> <option>

The following command is to define the MAC number of specific VLAN ID.

CLI(config vlan-mac-limit)# set <vid> <maclimit>

The following command is to display the status of VLAN MAC limiting.

CLI(config vlan-mac-limit)# show <vid>

Parameters	Task	
<vid></vid>	This specifies the VLAN ID of system.	
	Type: Mandatory	
	Valid values: $1 \sim 4094$	
<option></option>	This enable/disable the VLAN MAC limiting function of specific VLAN ID.	
*	Type: Mandatory	
	Valid values: enabled disabled	
<maclimit></maclimit>	This defines the MAC number of specific VLAN ID to be accept	
	Type: Mandatory	
	Valid values: $1 \sim 1536$	
	Default values: 1536	

Example 81 Configure the VLAN MAC limiting

```
CLI(config vlan-mac-limit)# set 100 43
OK
CLI(config vlan-mac-limit)# set 100 on
OK
CLI(config vlan-mac-limit)# show 100
VID [ 100]
MAC Limit : 43
```

MAC Limit Control: enabled

Configuring MAC Aging for Bridged Services

The MAC aging time sets the lifetime for the learned MAC address. A specific MAC address will be dropped when aging out until it is learned by the NE again.

Enter to the "**config bridge**" sub-group directory to configure the system bridging and monitor its status.

CLI# config bridge CLI(config bridge)#

Table 7-15 shows the commands to perform the MAC aging for bridged services. Example 82 shows the usage of these commands as well as their related parameters.

Table 7-15 Bridged Services Setting

The following command is to configure the bridging service aging time.

CLI(config bridge)# set aging-time <sec>

The following command is to view the bridging aging time status.

Parameters Task	
<sec> Defines the bridging aging time in second. Type: Mandatory Valid values: 10 ~ 1000 (sec.) Default value: 200 (sec.)</sec>	

Example 82 Display the bridging status

CLI(config bridge)**# set aging-time 300** OK

CLI(config bridge)# **show** MAC aging time: 5 min 0 sec (300 sec)

Monitoring the VLAN Member Set

Enter to the "status vlan" sub-group directory to display

- the VLAN member set of a specified VLAN.
- the VLANs which the GE port is a member port of.

CLI**# status vian** CLI(status vian)#

Table 7-16 shows the commands to show the Subscriber VLAN Group configuration. Example 83 shows the usage of these commands as well as their related parameters.

Table 7-16 Viewing Subscriber VLAN Group

Use this command to viewing the xDSL line ports which are the VLAN member ports of a specified VLAN

CLI(status vlan)# show vlan-id <vid>

Use this command to view VLANs which the GE port is a member port of

CLI(status vlan)# show uge <uge-id>

Parameters	Task
<vid></vid>	This specifies the VLAN ID of correspond xDSL line port.
	Valid values: 1~ 4094
<uge-id></uge-id>	This specifies the uge id of correspond xDSL line port. Type: Mandatory Valid values: 1~2

Example 83 Display the subscriber VLAN group

CLI(status vIan)# show vIan-id 100

VLAN [100] egress ports

LC 1: 6,21

```
LC 2:

LC 3:

LC 4:

UGE : 1, 2

CLI(status vlan)# show uge 1

Use mode: uplink

VLAN ID:

100, 4092
```

Configuring Static MAC

The NE supports the operator to add the "static" MAC addresses to specified xDSL line port manually. In comparison with the the MAC addresses learned from the associate ATM VC, the manually added "static" MAC addresses are never aged out.

Enter to the "**config fdb**" sub-group directory to add the static MAC entry to the FDB associated with the specified ATM PVC (i.e., the so-called "PVC_FDB").

CLI**# config fdb** CLI(config fdb)#

Table 7-17 shows the commands to add the static MAC entry to the PVC_FDB. Example 84 shows the usage of these commands as well as their related parameters.

Table 7-17 Configuring a static MAC entry in PVC_FDB

The following command is to add the static MAC addresses of specified ATM PVC of an xDSL line port.

CLI(config fdb)# add static <port-id> <vpi> <vci> <mac-addr>

The following command is to remove the static MAC addresses of specified ATM PVC of an xDSL line port.

CLI(config fdb)# del cypi> <vci> <mac-addr>

The following command is to display the FDB entries on specified xDSL line ports

CLI(config fdb)# show [<port-range>]

Parameters	Task
<port-range></port-range>	Identify the xDSL port range of FDB to show.
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
<port-id></port-id>	Identify the xDSL port id of the system to add/delete static MAC to
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
<vpi></vpi>	Defines the VPI (Virtual Path Identifier) value.
*	Type: Mandatory
	Valid values: $0 \sim 255$
<vci></vci>	Defines the VCI (Virtual Channel Identifier) value.
	Type: Mandatory
	Valid values: $1 \sim 65535 (1 \sim 31 \text{ are reserved})$
<mac-addr></mac-addr>	Indicate the static MAC address to be added.
	Type: Mandatory
	Valid values: Valid MAC addresses form. (for example: 00:1F:AA:19:78:03)

Example 84 Adding a static MAC addresses to specified ATM PVC of an xDSL line port.

CLI(config fdb)# add static 1.6 8 35 00:00:00:00:00:11

OK

CLI(config fdb)# show

port I	D	VP1/V	CI	MAC address	VLAN	type
1.	6	8/	35	00:00:00:00:00:11	100	S

Filtering the Upstream Traffic of Spoofed MAC

The FDB (filtering Database) of NCT192 system stored the MAC addresses learning from the associate ATM VC at bridged mode. The NE supports to prevent forwarding the upstream traffic of duplicated MAC address from xDSL subscribers as they may be maybe opportunist or hacker

When the NE learns two or more duplicated MAC addresses from xDSL subscribers's side learned at the same time, the NE's default action is to **allow the first MAC address and block all the others.** However, the illegal user's MAC address may be learned firstly. To provide the operator a tool to cure the aforementioned situation, the NE supports to manually change the default action.

Enter to the "**config fdb**" sub-group directory to configure learning MAC addresses from the associate ATM VC.

CLI**# config fdb** CLI(config fdb)#

Table 7-24 shows the commands to configure the VC MAC Learning Table. Example 85~Example 86 shows the usage of these commands as well as their related parameters.

Table 7-18 Configuring the action to the upstream traffic of spoofed MAC

The following command is to permit the upstream traffic of spoofed MAC address on the specified xDSL port.

CLI(config fdb)# set spoofed <port-id> <mac-addr> permit

The following command is to drop all the upstream traffic of spoofed MAC addresses.

CLI(config fdb)# set spoofed <mac-addr> deny-all

The following command is to display the FDB entries on specified xDSL line ports

CLI(config fdb)# show [<port-range>]

Parameters	Task
<port-range></port-range>	Identify the xDSL port range of FDB to show. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<port-id></port-id>	Identify the xDSL port id of the system to set the action to the upstream traffic of spoofed MAC address Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<mac-addr></mac-addr>	Indicate the spoofed MAC address. Type: Mandatory Valid values: Valid MAC addresses form. (for example: 00:1F:AA:19:78:03)

Example 85 Permitting the upstream traffic of spoofed MAC address on the specified xDSL port.

CLI(status fdb)# show spoofed

MAC address port VPI/VCI VLAN status

00:00:00:0	0:00:1	1	1.	6	8/	35	0	LSA	
			1.3	23	8/	35	0	LSI	
CLI(config OK	fdb)#	set	spo	ofed	1.23	00:00	0:00:00):00:11	permit
CLI(config	fdb)#	shov	1						
port ID	VP1/VC	I	M	AC ad	ddress	S	VLAN	type	
1.6	8/ 35	5 00	00:00	:00:0	00:00	:11	0	AD	

Example 86 Denying all the upstream traffic of spoofed MAC addresses

CLI(status fdb)# show spoofed

MAC address	port	VP1/VC1	VLAN	status	
00:00:00:00:00:11	1. 6	8/ 35	0	LSA	
	1.23	8/ 35	0	LSI	

CLI(config fdb)**# set spoofed 00:00:00:00:00:11 deny-all** OK

CLI(config fdb)# show

type	VLAN	MAC address	/C1	VP1/V	oort ID	p
AD	0	00:00:00:00:00:11	35	8/	1.6	
AD	0	00:00:00:00:00:11	35	8/	1.23	

Example 87 Denying all the upstream traffic of spoofed MAC addresses and then trying to permit one on the specified xDSL port.

CLI(status fdb)**#show spoofed**

MAC address	port	VP1/VC1	VLAN	status
00:00:00:00:00:11	1.6	8/ 35	0	LSI
	1.23	8/ 35	0	LSA

CLI(config fdb)**# set spoofed 00:00:00:00:00:11 deny-all** OK

CLI(config fdb)# show

port ID	VPI/VCI	MAC address	VLAN	type
1.6	8/ 35	00:00:00:00:00:11	0	AD
1.23	8/ 35	00:00:00:00:00:11	0	AD

CLI(config fdb)# set spoofed 1.6 00:00:00:00:00:11 permit

ERROR: MAC address is not spoofed.

Example 88 Permitting one spoofed MAC address and then trying to denying all the upstream traffic of spoofed MAC addresses on the specified xDSL port.

CLI(status fdb)# show spoofed

MAC address	port	VPI/VCI	VLAN	status
00:00:00:00:00:11	1. 6	8/ 35	0	LSA

1.23 8/ 35 0 LSI

CLI(status fdb)**# exit**

CLI# config fdb

CLI(config fdb)# set spoofed 1.23 00:00:00:00:00:11 permit OK

CLI(config fdb)# **show**

 port ID
 VPI/VCI
 MAC address
 VLAN
 type

 1. 6
 8/ 35
 00:00:00:00:00:11
 0
 AD

CLI(config fdb)# set spoofed 00:00:00:00:00:11 deny-all

ERROR: MAC address is not spoofed.

Monitoring the Subscriber MAC

The FDB (filtering Database) of NCT192 system stores the following MAC entries

- the manually configured MAC addresses on an ATM VC of xDSL port.
- the MAC addresses learned from the associate ATM VC of xDSL port.

According to the nature of stored MAC entry, each entry possesses "status" field. The definitions of "status" field are as follows.

- "AD": the abbreviation of "ACL Deny", It means the NE is to drop the upstream traffic of the indicated source MAC and forward the upstream traffic of other source MAC from the indicated xDSL port.
- "AP": the abbreviation of "ACL Permit", It means the NE is to forward the upstream traffic of this indicated source MAC and drops the upstream traffic of other source MAC from the indicated xDSL port.
- "S": the abbreviation of "Static",
- It means this MAC entry is configured manually in FDB.
- "LU": the abbreviation of "Learned Unique", It means this MAC is learned on the indicated xDSL port dynamically with setting aged time and is a unique one.
- "LUN": the abbreviation of "Learned Unique, non-aged", It means this MAC is learned on the indicated xDSL port dynamically with setting non-aged time and is a unique one.
- "LR": the abbreviation of "Learned Routed", It means this MAC is inserted by the xDSL LC in the case that the indicated xDSL port is in the RFC2684 routed mode.
- "LSI": the abbreviation of "Learned Spoofed Inactive", It means the following identities.
 - This MAC is learned on the indicated xDSL port.
 - The NE learns the same MAC on the xDSL ports other than the indicated xDSL port. That is, this MAC is spoofed.
 - This spoofed MAC is at the "inactive" state. That is the NE is to drop the upstream traffic of the spoofed MAC from the the indicated xDSL port.
 - "LSA" : the abbreviation of "Learned Spoofed Active",

It means the following identities.

- This MAC is learned on the indicated xDSL port.
- The NE also learns the same MAC on the xDSL ports other than the indicated xDSL port. That is, this MAC is spoofed.
- This spoofed MAC is at the "active" state. That is the NE is to forward the upstream traffic of the spoofed MAC from the the indicated xDSL port.

Table 7-19 shows how the NE treats the upstream Ethernet frame whenever its source MAC hits the PVC_FDB. Here, the "PVC_FDB" indicates the the FDB associated with the specified ATM

PVC.

Table 7-20 shows the conditions the NE will not learn the source MAC of upstream traffic.
When the status of existent MAC entry in PVC_FDB is "AP".

 Table 7-19
 The treatment of an upstream Ethernet frame of source MAC hitting the PVC_FDB

Status of hitted MAC entry in PVC_FDB	S	AD	AP	LU	LUN	LR	LSA	LSI
Forward (F) /Drop (D) packets of the same source MAC	F	D	F	F	F	F	F	D

Table 7-20 The conditions the NE does not learn additional source MAC of upstream traffic

Status of existent MAC entry in PVC_FDB	S	AD	AP	LU	LUN	LR	LSA	LSI
Allow (Y) /Deny (N) learning any additional MAC	Y	Y	N	Y	Y	NA	Y	Y

The NE may add a MAC entry to FDB due to either one of the following cases.

- The operator intends to manually add a MAC ACL entry.
- The operator intends to manually add a static MAC entry.
- The NE executes the basic "learning process of a bridge".

Depending on the status of existent MAC entries in FDB, the NE may take some or all of the following actions when it is to add a MAC entry to FDB

- Change the status of existent MAC entries of the same MAC.
- Reject to add this new MAC entry.
- Allow to add this new MAC entry but assign it some different status.

Table 7-21~Table 7-23 depicts the expected status of hitted MAC entry as well as the status of new added MAC entry in the aforementioned cases with the following notations.

- Dif Port FDB = The MAC entries of FDB associated with different port
- Dif PVC FDB = The MAC entries of FDB associated with the same port but different PVC
- PVC FDB = The MAC entries of FDB associated with the same port and the same PVC
- o: Permit x: Reject

c : Clear AP Entry

•

x : Reject # : Clear LU/LUN Entry & : Clear non-AP Entry r : Replacement

The reason to add a MACentry Status	Ν	Ianual additio	n	Dynamicaly learning on ATM PVC of			
matched MAC entry of Dif_Port_FDB	a static MAC	a MAC ACL Permit MAC	a MAC ACL Deny MAC	RFC2684 routed mode	"aged" RFC2684 bridged mode	"non-aged" RFC2684 bridged mode	
S	s	s	o	NA	S LSI	S LSI	
AP	AP	AP	AP 0	NA	LSI	LSI	
AD	AD 0	AD 0	AD 0	NA	AD	AD	
LR	LR	LR X	LR X	NA	LSI LR	LSI LR	
LU	LU X	X LU	0 LU	NA	LSI	LSI	
LUN	X LUN	X LUN	0 LUN	NA	LSI LUN	LSI	
LSA	LSA	LSA	0 LSA	NA	LSI	LSI	
LSI	LSI	LSI X	0 LSI	NA O	LSI	LSI	

Table 7-21 The expected status of hitted MAC entry as well as the status of new added MAC entry in the case that the MAC entry to be added hits the entry of Dif_Port_FDB



NA indicates "Not Applicable". As the NE reserves MACs for routed PVC. It's not possible for NE to dynamically learn such a MAC address on an ATM PVC of RFC2684 routed mode.



Whenever the following 3 cases hold simultaneously.

NE learns a new MAC entry on a ATM PVC of "non-aged"/"aged" RFC2684 bridged mode,

- This new MAC is the same as the one of FDB associated with different port •
 - The status of the MAC entry associated with different port is "LUN".

The NE will keep the status of the MAC entry associated with different port as "LUN".

The reason to add a MACentry	Ν	/anual additio	n	Dynamicaly learning on ATM PVC of			
Status of matched MAC entry of Dif_PVC_FDB	a static MAC	a MAC ACL Permit MAC	a MAC ACL Deny MAC	RFC2684 routed mode	"aged" RFC2684 bridged mode	"non-aged" RFC2684 bridged mode	
S	o	o	o	NA	s LU	LUN	
AP	AP 0	AP 0	AP 0	NA	AP	LUN	
AD	AD 0	AD 0	AD 0	NA	AD	AD	
LR	LR X	LR X	LR X	NA	NA	NA	
LU	0 LU	LU O	0 LU	NA	X LU	X LU	
LUN	0 LUN	0 LUN	0 LUN	NA	X LUN	X LUN	
LSA	X LSA	X LSA	LSA X	NA	X LSA	X LSA	
LSI	LSI X	LSI X	LSI	NA	X LSI	LSI X	

 Table 7-22
 The expected status of hitted MAC entry as well as the status of new added MAC entry in the case that the MAC entry to be added hits the entry of Dif_PVC_FDB

Table 7-23	The expected status of hitted MAC entry as well as the status of new added MAC
	entry in the case that the MAC entry to be added hits the entry of PVC_FDB

The reason to add a MACentry Status of	Ν	Ianual additio	n	Dynamicaly learning on ATM PVC of			
matched MAC entry of PVC_FDB	a static MAC	a MAC ACL Permit MAC	a MAC ACL Deny MAC	RFC2684 routed mode	"aged" RFC2684 bridged mode	"non-aged" RFC2684 bridged mode	
S	s	s	s	NA	s x	s	
AP	AP	AP	AP	NA	X AP	AP	
AD	AD	AD	AD	NA	AD X	AD	
LR	LR X	LR X	LR X	0 LR	NA	NA	
LU	r LU	r+& LU	r+c	NA	X LU	NA	
LUN	r LUN	r+& LUN	r+c LUN	NA	NA	X LUN	
LSA	X LSA	X LSA	X LSA	NA	X LSA	NA	
LSI	LSI	LSI	LSI	NA	X LSI	LSI X	

Enter to the "**status fdb**" sub-group directory to view learning MAC addresses from the associate ATM VC.

CLI**# status fdb** CLI(status fdb)#

Table 7-24 shows the commands to show the VC MAC Learning Table. Example 89 shows the usage of these commands as well as their related parameters.

Table 7-24 VC MAC Learning Table

CLI(status fdb)# show spoofed

The following command is to display the MAC addresses learned on the specified xDSL line port.

CLI(status fdb)# show port port-range>

The following command is to display the spoofed MAC addresses and the xDSL line ports where spoofed MAC addresses are learned.

The following command is to display the xDSL line ports where the specified MAC addresses are learned.					
CLI(status fdb)# show mac <	CLI(status fdb)# show mac <mac-addr></mac-addr>				
Parameters	Task				
<portrange></portrange>	Identify the port id of the system wish to display current list of learning MAC addresses from their remote network. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.				
<mac-addr></mac-addr>	Indicate the target MAC address. Type: Mandatory Valid values: Valid MAC addresses form. (for example: 00:1F:AA:19:78:03)				

Example 89 Displaying the MAC addresses learned on the specified xDSL line port

CLI(status fdb)# show port 1.6

Port 1. 6

ID	VPI	VCI	MAC Address	Status
1	8	35	00:00:00:00:00:11	LU

Example 90 Displaying the spoofed MAC addresses and the xDSL line ports where spoofed MAC addresses are learned

CLI(status fdb)# show spoofed

MAC address	port	VP1/VC1	VLAN	status
00:00:00:00:00:11	1.6	8/ 35	0	LSA
	1.23	8/ 35	0	LSI

Example 91 Displaying the xDSL line ports where the specified MAC addresses are learned

CLI(status fdb)# show mac 00:00:00:00:00:11

MAC address	port	VP1/\	/C1	VLAN	status
00:00:00:00:00:11	1.6	8/	35	0	LSA
	1.23	8/	35	0	LSI

This page is leave in blank for note or memo use

Chapter 8 Managing the System Operations

This chapter describes the system functions of NCT192 IP-DSLAM.

This chapter contains the following sections:

- System Administrating
- Alarm Definition and Relay Setting

System Administrating

The system administrating provides command for you to logout the Telnet session or reboots the system device.

Reset the Line Card and Port

Reset the line card and port using the "reset" command at the prompt for CLI#.

Table 8-1 shows the commands to reset the planning of line card and port. Example 92 shows the usage of these commands as well as their related parameters.

Table 8-1 Line Card and Port Reset Command

The following command is to reset the specify line card.

CLI# reset lc <lc-id>

The following command is to reset the specify NC card.

CLI# reset nc <nc-id>

The following command is to reset the specify xDSL port interface.

CLI# reset port <port-id>

The following command is to reset (reboot) the system device.

CLI# reset system	
Parameters	Task
<lc-id></lc-id>	Identify the slot id of the system
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
<nc-id></nc-id>	Identify the slot id of the network card
	Type: Mandatory
	Valid values: 1 2
<port-id></port-id>	Identify the port id of the system
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.

Example 92 Reset the line card and xDSL port

```
CLI# reset Ic 2
OK
CLI# reset port 1.2.1
OK
```



The pop-up information for reset line card command shows only on Console port access.

Reboot the System

The reboot command activates the software restart of system device. The configuration change will be lost if you did not committed (store) it.

Reboot the system using the "reboot" command at the prompt for CLI#.

Table 8-2 System Reboot Command

The following command is to reboot the system device.	
CLI# reboot	

Alarm Definition and Relay Setting

The alarm definition profile allows you to define the rule of alarm element in system. Through this profile, you are able to change the severity of individual alarm element and decide to report it or not. Alarm element is specified in the class of module or port. Different types of module may present different alarm element. Different types of port may also present different alarm element.

The relay input management allows you to define the alarm relay input. Please see "System Installation Guide" for the definition. Once the normal status of input signal is different from the current status, the NE will launch an "abnormal status" alarm of the specified relay input to LCT and NCT192 server.

Configuring the Alarm Definition

Enter to the "**config alarm definition**" sub-group directory to manage the alarm definition. Please refer to Appendix B for the detailed description of defined alarms and their default severity.

CLI**# config alarm definition** CLI(config alarm definition)**#**

Table 8-3 shows the commands to configure the alarm definition of line card and port. Example 93 shows the usage of these commands as well as their related parameters.

Table 8-3 Alarm Definition Configuration

The following command is to change the default alarm severities

CLI(config alarm definition)# set <vendorType> <alarmType> {none | critical | major | minor | info} {true | false} <suppressby>

The following command is to view the status of system alarm severities.

CLI(config alarm definition)# show			
Parameters	Task		
<vendortype></vendortype>	It specifies an entuty of NE. Type: Mandatory Valid values: noEntity, cpuModule, adslModule, powerModule, fanModule, adslPort, alarmRelayModule, gePort, alarmRelayInPort		
<alarmtype></alarmtype>	It specifies a numerical representation of the condition may happen to an entity (< <i>vendorType</i> >) of NE. (see the note below) Type: Mandatory Valid values: 0 ~ 31		
{none critical major minor info}	Defines the severity level of alarm type. Type: Mandatory Valid values: none, critical, major, minor, info		
{true false}	Defines the filtering status of specific alarm type. Type: Mandatory Valid values: true, false true – The NE is not to send alarm trap to the trap host whenever there is an alarm indicated by <i><vendortype></vendortype></i> and <i><alarmtype></alarmtype></i> false –The NE is to send alarm trap to the trap host whenever there is an alarm indicated by <i><vendortype></vendortype></i> and <i><alarmtype></alarmtype></i>		
<suppressby></suppressby>	Defines the prevent alarms from being reported on another alarm, when an alarm or condition exists but you do not want it to appear instead of another (see the note below) Type: Mandatory Valid values: Hexadecimal number		



The alarm suppression (suppressed by) allows you to mask specific alarms when there are sequences occurred at the same time. For example, let the LOF (Loss of Frame) be configured to be suppressed by the LOS (Loss of Signal), the LOF will not be display on the screen but only LOS whenever the corresponding ADSL loop is cut.

In Example 93, the "name" represents an abbreviation of the condition indicated by *<alarmType>*. *<alarmType>* may indicate different conditions when it appeas with different *<vendorType>*. For example, in Example 93, the *<alarmType>* of value 6 represents "TCA_DHCP_BC" when it appears with "cpuModule", "UAS_FE_15_MIN" when it appears with "adslPort" and

"TCA_SNR_NE" when it appears with "shdslPort".

Example 93 Display the system alarm definition

CLI# config alarm definition set adslModule O critical true OxOa OK

CLI# config alarm definition show

Alarm definition vendor-type	type	name	severity	filtered	supress-by
noEntity	0	EMPTY	none	false	0x0
cpuModule	0	MISSING	major	false	0x0

Managing the System Operations

cpuModule	1	TEMP	major	false	0x0
cpuModule	2	VOL	major	false	0x0
cpuModule	3	MISMATCH	major	false	0x0
cpuModule	6	TCA DHCP BC	warning	false	0x0
cpuModule	30	HW INFO INV	major	false	0x0
adsiModule	0	MISSING	critical	true	0xa
adslModule	1	TEMP	maior	false	0x0
adslModule	2	VOL	maior	false	0x0
adslModule	3	MISMATCH	maior	false	0x0
adslModule	4	NOT OPERABLE	maior	false	0x0
adslModule	30	HW INFO INV	major	false	0x0
shdslModule	0	MISSING	major	false	0x0
shds Module	1	TFMP	major	false	0x0
shdslModule	2	VOI	major	false	0x0
shdslModule	3	MISMATCH	major	false	0x0
shdslModule	4	NOT OPERABLE	major	false	0x0
shds Module	30	HW INFO INV	major	false	0x0
powerModule	0	MISSING	major	false	0x0
powerModule	4	NOT OPERABLE	major	false	0x0
nowerModule	5	PWR FALL	major	false	0x0
fanModule	0	MISSING	major	false	0x0
fanModule	1	FAN1	major	false	0x0
fanModule	2	FAN2	major	falso	0x0
fanModulo	0	VOL	major	falso	0,0
adelPort	1	ES NE 15 MIN	minor	falso	0,0
adsIPort	2	SES NE 15 MIN	minor	falso	0,0
adsIPort	2	UAS NE 15 MIN	minor	false	0,0
adsiroit	3	ES EE 15 MIN	minor	false	0,0
adsiroit	4	CO_FE_IO_WIN	minor	false	0,0
adsiPort	5	SES_FE_IS_WIN	minor	false	0x0
adsiroit	0		minor	false	0,0
adsiPort	1	ES_NE_I_DAY	minor	false	0x0
adsiPort	8	SES_NE_1_DAY	minor	false	00
adsiPort	10	UAS_NE_1_DAY	minor	false	UXU OvO
adsiPort	10	ES_FE_I_DAY	minor	false	00
adsiPort	11	SES_FE_1_DAY	minor	false	00
adsiPort	12	UAS_FE_1_DAY	minor	false	UXU OvO
adsiPort	13	LUS	minor	false	0x0
adsiroit	14		minor	false	0,0
adsiPort	10		minor	false	00
adsiPort	10	GEN_LINE_INTI_FAIL	minor	false	00
adsiPort	1/		minor	false	0x0
adsiroit	10		minor	false	0,0
adsiPort	19		minor	false	00
adsiPort	20	NU_PEER_DETECTED	minor	false	00
adsiPort	21		warning	false	UXU OvO
adsiPort	22		warning	false	0x0
adsiPort	23	PS_LZ_WANUAL	1110	false	0x0
adsiroit	24	PS_LZ_AUTO	info	false	0,0
adsiPort	25		into	false	UXU OvO
adsiPort	20		1110	false	0x0
adsiPort	29	ILLEGAL_IP	warning	false	0x0
adsiPort	30	MAC_SPUUFED	warning	Taise	UXU 0 0
adsiPort	31	DISABLED	Into	false	00
ugePort	0	MISSING	major	faise	UXU 0 0
ugePort	4	LUS	major	faise	UXU 0 0
ugePort	21	LINK_DOWN	major	faise	UXU 0 0
ugePort	29	STP_LEARN	Info	faise	UXU
ugePort	30	STP_BLUCK	into	faise	UXU
ugePort	31	DISABLED	1010	Taise	UXU
relayModule	0	MISSING	major	Taise	UXU
relayinPort	1	RELAY_ABNORMAL	major	faise	UXU
relayinPort	31	DISABLED	1010	iaise	UXU
snasiPort	1	ICA_ES_NE_ISMIN	minor	Taise	UXU
snasiPort	2	TCA_SES_NE_ISMIN	minor	Taise	UXU
snasiPort	3	TCA_UAS_NE_15MIN	minor	Taise	UXU
snasiPort	4	TCA_CRU_NE_15MIN	minor	Taise	UXU
snasiPort	5	ICA_LUSW_NE_15MIN	minor	Taise	UXU
sndsiPort	6	TCA_SNR_NE	minor	taise	0x0

shdslPort	7	TCA_ATTN_NE	minor	false	0x0
shdslPort	8	OPI	minor	false	0x0
shdslPort	9	LOS	minor	false	0x0
shdslPort	10	SEGA	minor	false	0x0
shdslPort	11	LPWR	minor	false	0x0
shdslPort	12	SEGD	minor	false	0x0
shdslPort	13	PB0_NE	info	false	0x0
shdslPort	14	DEVFAULT_NE	minor	false	0x0
shdslPort	15	DCCONT_NE	minor	false	0x0
shdslPort	16	LOSW_NE	minor	false	0x0
shdslPort	17	INI_CFG_NE	minor	false	0x0
shdslPort	18	INI_PROTOCOL_NE	minor	false	0x0
shdslPort	22	NOPEER	minor	false	0x0
shdslPort	23	PB0_FE	info	false	0x0
shdslPort	24	DEVFAULT_FE	minor	false	0x0
shdslPort	25	DCCONT_FE	minor	false	0x0
shdslPort	26	LOSW_FE	minor	false	0x0
shdslPort	27	INI_CFG_FE	minor	false	0x0
shdslPort	28	INI_PROTOCOL_FE	minor	false	0x0
shdslPort	31	DISABLED	info	false	0x0

Configuring the System Relay-In Alarm

The NCT192 support housekeeping alarm relays for input signals.

Enter to the "config alarm input" sub-group directory to activate and monitor the alarm relay-in.

CLI# config alarm input CLI(config alarm input)#

Table 8-4 shows the commands to configure system relay-in alarm input configuration. Example 94 shows the usage of these commands as well as their related parameters.

Table 8-4 System Relay-In Alarm Configuration

The following command is to set the name and index of system relay-in alarm input function.

CLI(config alarm input)# set name <index> <input-name>

The following command is to set the normal state of system relay-in alarm input function.

CLI(config alarm input)# set normal-state <index> <state>

The following command is to enable the system relay-in alarm input function.

CLI(config alarm input)# enable <index>

The following command is to disable the system relay-in alarm input function.

CLI(config alarm input)# disable <index>

The following command is to view the status of system relay-in alarm input function.

CLI(config alarm input)# show

Parameters	Task
< index>	Identify the port number of relay-in alarm. Type: Mandatory Valid values: 1 ~ 4
< input-name >	This specifies the name of given relay-in alarm port. Type: Mandatory Valid values: String of up to 10 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '', '@').
< state >	Identify one of the parameter of expects normal status of the relay-in alarm port. Type: Mandatory Valid values: open, close

Example 94 Display the system relay-in alarm input port status

CLI(config alarm input)# set name 1 Door OK CLI(config alarm input)# set normal-state 1 closed OK CLI(config alarm input)# enable 1 OK CLI(config alarm input)# show

index	name	admin-state	normal-state
1	Door	enabled	closed
2	<< not defined >>	disabled	opened
3	<< not defined >>	disabled	opened
4	<< not defined >>	disabled	opened

Configuring the System Relay-Out Alarm

The NCT192 support housekeeping alarm relays to trigger external device such as speaker or light to launch warning signal.

Enter to the "config alarm output" sub-group directory to activate and monitor the alarm relay-in.

CLI# config alarm output CLI(config alarm output)#

Table 8-5 shows the commands to configure system relay-in alarm output configuration of line card and port. Example 95 shows the usage of these commands as well as their related parameters.

Table 8-5 System Relay-Out Alarm Configuration

The following command is to set the name and index of system relay-in alarm output function.

CLI(config alarm output)# set name <index> <output-name>

The following command is to set the severities of system relay-in alarm output function.

CLI(config alarm output)# set alarm-severities <index> <severities>

The following command is to enable the system relay-in alarm output function.

CLI(config alarmoutput)# enable <index>

The following command is to disable the system relay-in alarm output function.

CLI(config alarm output)# disable <index>

The following command is to view the status of system relay-in alarm output function.

CLI(config alarm output)# show

Parameters	Task
< index>	Identify the port number of relay-in alarm.
	Type: Mandatory
	Valid values: $1 \sim 1$
<output-name></output-name>	This specifies the name of given relay-in alarm port.
*	Type: Mandatory
	Valid values: String of up to 10 characters ('0'~'9', 'A'~'Z', 'a'~'Z', '-', '_', '.', '@').
< severities >	Identify one of the parameter of expects normal status of the relay-in alarm port.
	Type: Mandatory
	Valid values: open, close

Example 95 Display the system relay-in alarm input port status

CLI(config alarm output)# set name 1 Alarm_Output OK CLI(config alarm output)# set alarm-severities 1 major OK CLI(config alarm output)# enable 1 OK CLI(config alarm output)# show

name : Alarm_Output alarm severities : major admin state : enabled This page is leave in blank for note or memo use
Chapter 9 Diagnosis and Performance Monitoring

This chapter describes the filtering rule in different network layer.

This chapter contains the following sections:

- Performance Monitoring on System and Network Interface
- Performance Monitoring on ADSL Subscriber Interface
- Performance Monitoring on SHDSL Subscriber Interface
- Monitoring System Alarms
- OAM and Loop Diagnostic Test on Subscriber Interface
- Network Ping Test
- Monitoring the System Environment
- Monitoring the System Performance

Performance Monitoring on System and Network Interface

Enter to the "**status perf**" sub-group directory to display performance parameters on the Network interface.

CLI**# status perf** CLI(status perf)#

Table 9-1 shows the commands to display the performance parameters on system and network interface of NE. Example 96 shows the usage of its command as well as its related parameters.

Table 9-1 Performance Monitoring on System and Network Interface

The following command is to viewing the performance parameters on the Network interface.

CLI(status perf)# show nc

Example 96 Display the performance parameters on network interface

inter	face	unicast	broadcast	multicast	discard	error
UGE-01	inPkts	0	0	0	0	C
	outPkts	0	3	0	0	C
UGE-02	inPkts	0	0	0	0	C
	outPkts	0	0	0	0	C
LC-01	inPkts	6218	84	0	0	C
	outPkts	6281	1	0	0	C
LC-02	inPkts	9448	88	0	0	C
	outPkts	9522	1	0	0	C
LC-03	inPkts	5912	80	0	0	C
	outPkts	5976	1	0	0	C
LC-04	inPkts	79	83	0	0	C
	outPkts	78	78	0	0	C
inter	face	pause/RX	pause/TX			
UGE-(D1 pkts	0	0			

0

0

UGE-02 pkts

Performance Monitoring on ADSL Subscriber Interface

Enter to the "**status perf**" sub-group directory to display performance parameters on the ADSL Subscriber interface.

CLI**# status perf** CLI(status perf)#

Table 9-2 shows the commands to display the performance parameters on subscriber interface of NE. Example 97 shows the usage of its command as well as its related parameters.

Table 9-2 Performance Monitoring on ADSL Subscriber Interface

Use this command to vie	w the performance parameters on the specified ADSL line port.		
CLI(status perf)# show current <pre>current</pre>			
Parameters	Task		
<port-id></port-id>	Identify the port id of the system wish to display the performance parameters with associated time period. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.		
<side></side>	Identify the performance parameters display on Near-End or Far-End, show both if not specify. Type: Optional Valid values: near, far		

Example 97 Display the performance parameters on subscriber interface

CLI(status perf)# show current 1.1.2

[UserCells/1.1.2	2]	D	0	0
l	Jurr 15Min	Prevismin	curr Ibay	Previbay
rxCells	0	0	0	3
txCells	0	0	0	0
[Perf/NE/1.1.2]				
(Curr15Min	Prev15Min	Curr1Day	Prev1Day
UAS	0	0	0	8627
LOFs	0	0	0	30
LOSs	0	0	0	0
LPRs	0	0	0	0
INITS	0	0	0	6
FullINITs	0	0	0	6
ES	0	0	0	0
SES	0	0	0	0
CV	0	0	0	0
[Perf/FE/1.1.2]				
(Curr15min	Prev15Min	Curr1Day	Prev1Day
UAS	0	0	0	8577
LOFs	0	0	0	8
LOSs	0	0	0	7
LPRs	0	0	0	8329
ES	0	0	0	144
SES	0	0	0	45
CV	0	0	0	1618

Performance Monitoring on SHDSL Subscriber Interface

Enter to the "**status perf**" sub-group directory to display performance parameters on the SHDSL Subscriber interface.

CLI**# status perf** CLI(status perf)**#**

Table 9-3 shows the commands to configure the performance parameters on SHDSL subscriber interface of NE. Example 98 shows the usage of its command as well as its related parameters.

Table 9-3 Performance Monitoring on SHDSL Subscriber Interface

The following command is to view the performance parameters on specific SHDSL line port.

CLI(status perf)# show current <port-id> <side>

The following command is to show the shdsl line historical performance data (15 minutes per interval).

CLI(status perf)# show history-15-min cport-id> <start-interval>

The following command is to show the shdsl line historical performance data (1day per interval).

CLI(status perf)# show history-1-day <pre>port-id></pre>			
Parameters	Task		
<port-id></port-id>	Identify the port id of the system wish to perform the link monitoring, the define line port must operate in running status. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.		
<start-interval></start-interval>	This specifies the adsl line historical performance data (15 minutes per interval). Type: Mandatory Valid values: 1 ~ 96		
<side></side>	Identify the given performance parameter value in Near-End or Far-End side, CLI Ex will apply the same performance parameter value for Near-End and Far-End if not specify. Type: Optional Valid values: near, far		

Example 98 Display the performance parameters on SHDSL subscriber interface

CLI(status perf)# show current 1.6 near

[UserCells/1.6]				
Cu	urr15Min	Prev15Min	Curr1Day	Prev1Day
-				
rxCells	52980	267862	22000803	0
txCells	0	0	0	0

[Perf/NE/1.6]

Current 15 Min Elapsed : 178 seconds Current 1 Day Elapsed : 73978 seconds

(Curr15Min	Prev15Min	Curr1Day	Prev1Day
UAS	0	0	44	0
LOFs	0	0	0	0
LOSs	0	0	0	0
LPRs	0	0	0	0
INITS	0	0	1	0
FailINITs	0	0	0	0
ES	0	0	0	0
SES	0	0	0	0
CV	0	0	0	0

Monitoring System Alarms

This section explains how to monitor alarms with CLI Ex, which includes viewing current and historical alarm data.

The CLI Ex detects and reports system alarms generated by the NCT192 and the adjacent network. You can use CLI Ex to monitor alarms at a card, port, or network level and view alarm with severities.

Enter to the "status alarm" sub-group directory to monitor system alarms.

CLI# status alarm CLI(status alarm)#

Table 9-4 shows the commands to configure the diagnostic the system alarm of NE. Example 100 \sim Example 102 shows the usage of its command as well as its related parameters.

Table 9-4 Viewing the System Alarm

The following command is to determine if the NE reports the current alarm on the CLI Ex in real-time.

CLI(status alarm)# report console { on / off}

The following command is to view the current alarm data.

CLI(status alarm)# show current

The following command is to view the historical alarm data.

CLI(status alarm)# show history

The following command is to view the setting of reportconsole

CLI(status alarm)# show report console

The following command is to view the detailed description of the condition happen to the entity indicated by *<unit>*.

CLI(status alarm)# show detail <unit>

The following command is to view the status of system relay-in alarm inputput function.

CLI(status alarm)# show input

The following command is to view the status of system relay-in alarm output function.

CLI(status alarm)# show output

Parameters	Task
{ <i>on off</i> }	This specifies to let the NE report the current alarm on the CLI Ex in real-time or not. Type: Mandatory Valid value: on, off
{unit}	This indicates the entity on IP-DSLAM. Type: Mandatory Valid value: All the alarm unit on IP-DSLAM (see Example 100)

Example 99 Viewing the active alarm on NE via Console Port (RS232 port)

CLI(status alarm)**# reportconsole on** OK

CLI# Alarm <10121> (0x00082000 | LOS | COMM_PROBLEM) at THU NOV 08 15:28:39 2007 CLI#



Example 99 shows the active alarm on NE via Console Port (RS232 port) when the loop between the NE and the ADSL CPE is broken.

Example 100 Viewing the current active alarm on NE

CLI(status alarm)# show curren	t			
unit	on-line type	planned type	alarm	last change	severity
shelf	shelf	shelf	-	11-07-07 11:42:49	none
LC01	adslModule	adslModule	v	11-08-07 09:39:01	major
LCO1/portO1	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/portO2	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/portO3	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/portO4	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/portO5	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/portO6	adslPort	adslPort	-	11-08-07 09:39:42	none
LCO1/portO7	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/portO8	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/portO9	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port10	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port11	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port12	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port13	adslPort	adslPort	v	11-08-07 09:39:30	minor
LCO1/port14	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port15	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port16	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port17	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port18	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port19	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port20	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port21	adslPort	adslPort	-	11-08-07 09:39:45	none
LCO1/port22	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port23	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port24	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port25	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port26	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port27	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port28	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port29	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port30	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port31	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port32	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port33	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port34	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port35	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port36	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port37	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port38	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port39	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port40	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port41	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port42	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port43	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port44	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port45	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port46	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port47	adslPort	adslPort	v	11-08-07 09:39:01	info
LCO1/port48	adslPort	adslPort	v	11-08-07 09:39:30	minor
LCO2	noEntity	noEntity	v	11-07-07 11:43:00	none
LC03	noEntity	noEntity	v	11-07-07 11:43:00	none
LC04	noEntity	noEntity	v	11-07-07 11:43:00	none
NC	cpuModule	cpuModule	v	11-08-07 11:21:05	major
UGE 1	ugePort	ugePort		11-07-07 15:40:45	none
UGE2	noEntity	ugePort	v	11-07-07 11:42:49	info
powerA	powerModule	powerModule	v	11-07-07 11:43:23	major
powerB	powerModule	powerModule		11-07-07 11:42:57	none
fan	fanModule	fanModule	v	11-07-07 11:43:26	ma ior
relav	noEntitv	relayModule	v	11-07-07 11:42:49	maior
relavin-1	relayInPort	relayInPort	-	11-08-07 10:42:08	none
relavin-2	relayInPort	relayInPort	v	11-07-07 11:42:49	info
relayin-3	relayInPort	relayInPort	v	11-07-07 11:42:49	info

relayin-4 relayInPort relayInPort v 11-07-07 11:42:49 info



Example 100 shows the current active alarm on NE. It is noted that the notation "v" in the colume "alarm" indicates an alarm occurs on the corresponding "unit". Example 100 also shows "last change" time instance and the "sever ity" of the current active alarm.

Example 101 Display the detailed description of an alarm

CLI(status alarm)# show detail LCO2

Detail alarm list is:		
alarm name	severity	description
EMPTY	none	Neither plan type nor on-line type



Example 101 shows the CLI command to inspect the details of a current active alarm which include the alarm condition ("alarm name") and its description ("description").

Example 102 Display the history of alarms

CLI(status alarm)# show alarmhistory

History Ta	ble				
i dx	phyidx	planned type	online type	alarm type	occurtime
12562	10236	adslPort	adslPort	20	10-10-00 09:18:44
12563	10236	adslPort	adslPort	21	10-10-00 09:18:44
12564	10236	adslPort	adslPort	22	10-10-00 09:18:44
12565	10236	adslPort	adslPort	23	10-10-00 09:18:44
12566	10236	adslPort	adslPort	24	10-10-00 09:18:44
12567	10236	adslPort	adslPort	25	10-10-00 09:18:44
12568	10236	adslPort	adslPort	26	10-10-00 09:18:44
12569	10236	adslPort	adslPort	29	10-10-00 09:18:44
12570	10236	adslPort	adslPort	30	10-10-00 09:18:44
12571	10236	adslPort	adslPort	31	10-10-00 09:18:44
12572	10237	adslPort	adslPort	1	10-10-00 09:18:44
12573	10237	adslPort	adslPort	2	10-10-00 09:18:44
12574	10237	adslPort	adslPort	3	10-10-00 09:18:44
12575	10237	adslPort	adslPort	4	10-10-00 09:18:44
12576	10237	adslPort	adslPort	5	10-10-00 09:18:44
12577	10237	adslPort	adslPort	6	10-10-00 09:18:44
12578	10237	adslPort	adslPort	7	10-10-00 09:18:44
12579	10237	adslPort	adslPort	8	10-10-00 09:18:44
12580	10237	adslPort	adslPort	9	10-10-00 09:18:44
12581	10237	adslPort	adslPort	10	10-10-00 09:18:44

Example 103 Display the status of alarm input

CLI(status alarm)# show input

		admin	normal	current
index	name	state	state	state
1	Alarm_Input	enabled	opened	opened
2	<< not defined >>	disabled	opened	n/a
3	<< not defined >>	disabled	opened	n/a
4	<< not defined >>	disabled	opened	n/a

Example 104 Display the status of alarm output

CLI(status alarm)# show output

name	: Alarm_Output
alarm severities	: major
admin state	: enabled

current state : enabled

OAM and Loop Diagnostic Test on Subscriber Interface

In order to diagnose and fix problem, the NE supports to perform the ATM Operation, Administration, and Maintenance (OAM) F5 diagnosis at data connection layer and the ADSL loop diagnosis at physical layer, respectively.

ATM OAM F5 VC Diagnosis

Via ATM OAM F5 loopback diagnosis, the operator is able to diagnose the health of existant ATM VC connection between the NE and ADSL CPE in intrest.

Enter to the "diag" group directory with "oam" command to perform the OAM F5 VC diagnostic.

CLI**# diag** CLI(diag)#

Table 9-5 shows the commands to configure OAM F5 VC diagnosis test of NE. Example 105 shows the usage of its command as well as its related parameters.

Table 9-5 OAM F5 VC Diagnosis Test

The following command is to testing the OAM F5 on both End-to-End and Segment-to-Segment.

CLI(diag)# oam set F5 <port-id> <vpi> <vci> both

The following command is to testing the OAM F5 on End-to-End only.

CLI(diag)# oam set F5 cypi< <vci> end-to-end

The following command is to testing the OAM F5 on Segment-to-Segment only.

CLI(diag)# oam set F5 <port-id> <vpi> <vci> seg-to-seg

Parameters	Task
<port-id></port-id>	Identify the port id of the system wish to perform the OAM F5, the define VC must existed at defines line port.
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
<vpi></vpi>	Defines the VPI (Virtual Path Identifier) value.
*	Type: Mandatory
	Valid values: $0 \sim 255$
<vci></vci>	Defines the VCI (Virtual Channel Identifier) value.
	Type: Mandatory
	Valid values: $1 \sim 65535 (1 \sim 31 \text{ are reserved})$

Example 105 shows the OAM F5 diagnostic. When the xDSL CPE echos to the OAM F5 cells, the CLI Ex shows "alive". On the other hand, check both xDSL physical layer and ATM layer setting if shows "OAM timeout" otherwise.

Example 105 Diagnosing the OAM F5 in ATM layer of Subscriber interface

CLI(diag oam)# set F5 1.1.2 0 35 both Port 1.1.2 pvc 0/35: alive. OK CLI(diag oam)# set F5 1.1.1 0 35 both

Port 1.1.1 pvc 0/35: OAM timeout. OK

ADSL Loop Diagnosis (DELT <Dual-Ended Line Test>)

The DELT loop diagnosis function provides mechanism to measure the ADSL loop quality. This action will interrupt the ADSL connection. However, more detailed inform are gathered in comparison with the aforementioned loop monitoring function.

This function is available on ADSL2 and ADSL2+ connection only, the ADSL CPE who did not complied with ITU-T standard G.992.3, G.992.4, and G.992.5 may not be able to perform the loop diagnostics.

Enter to the "diag" group directory with "delt" command to perform the ADSL loop diagnostic.

CLI**# diag** CLI(diag)#

Table 9-6 shows the commands to configure ADSL loop diagnostic test of NE. Example 106 shows the usage of its command as well as its related parameters.

Table 9-6 ADSL Loop Diagnosis

The following command is to start the ADSL loop diagnosis (DELT) process on the specific ADSL line port.

CLI(diag delt)# loopdiag start <profile-name>

The following command is to manually terminate the ADSL loop diagnosis (DELT) process.

CLI(diag delt)# loopdiag stop

The following command is to view the test result of DELT

CLI(diag delt)# loopdiag sho	W
Parameters	Task
<port-id></port-id>	Identify the port id of the system wish to perform the loop diagnostic, the define line port must operate in run-time status. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.
<profile-name></profile-name>	This specifies the ADSL connection profile of the specific ADSL line port. Type: Mandatory Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', ' ', ', '@').

Example 106 Diagnosing the ADSL loop performance via DELT

```
CLI(diag delt)# start 1.6 ADSL_P6
0K
CLI(diag delt)# show
Loop diag result:
Port 1.6
Used Profile: "ADSL_P6"
                     ATU-C ATU-R
Attainable Rate(Kbps)
                     26204.0 1296.0
Loop Attenuation(dB)
                    0.7 0.0
Signal Attenuation(dB) 0.0 0.0
SnrMargin(dB)
                     6.0 0.0
                     12.3 12.2
TxPower(dBm)
H(f) logarithmic representation(Hlog(f))
DS
             Unit: dB
[ 1] -77.0 -35.0 -39.0 -39.0 -44.0 -47.0 -44.0 -44.0
[9] -47.0 -47.0 -44.0 -47.0 -53.0 -47.0 -47.0 -47.0
[ 17] -46.0 -53.0 -50.0 -54.0 -54.0 -46.0 -44.0 -40.0
[25] -38.0 -35.0 -34.0 -30.0 -28.0 -26.0 -23.0 -21.0
```

[33] -19.0 [41] -5.0 [49] -2.0 [57] -1.0 [65] 0.0 [73] 1.0 [81] 1.0 [89] 2.0	$\begin{array}{rrrr} -17.0 & -15.0 \\ -4.0 & -4.0 \\ -2.0 & -2.0 \\ -1.0 & -1.0 \\ 0.0 & 0.0 \\ 1.0 & 1.0 \\ 2.0 & 2.0 \\ 2.0 & 2.0 \end{array}$	-13.0 -3.0 -2.0 -1.0 0.0 1.0 2.0 2.0	-11.0 -3.0 -2.0 -1.0 0.0 1.0 2.0 2.0	-9.0 -3.0 -1.0 0.0 0.0 1.0 2.0 2.0	-7.0 -2.0 -1.0 0.0 1.0 1.0 2.0 2.0	-6.0 -2.0 -1.0 0.0 1.0 1.0 2.0 2.0
[441] -1.0 [449] -1.0 [457] -2.0 [465] -3.0 [473] -4.0 [481] -6.0 [489] -8.0 [497] -10.0 [505] -12.0	-1.0 -1.0 -1.0 -1.0 -2.0 -2.0 -3.0 -3.0 -4.0 -5.0 -6.0 -6.0 -8.0 -8.0 -10.0 -10.0 -12.0 -12.0	-1.0 -2.0 -3.0 -5.0 -6.0 -8.0 -11.0 -13.0	-1.0 -2.0 -3.0 -4.0 -5.0 -7.0 -9.0 -11.0 -13.0	-1.0 -2.0 -3.0 -4.0 -5.0 -7.0 -9.0 -11.0 -13.0	-1.0 -2.0 -3.0 -4.0 -5.0 -7.0 -9.0 -11.0 -13.0	-1.0 -2.0 -3.0 -4.0 -6.0 -7.0 -9.0 -12.0 -13.0
US [1] -34.0 [9] 0.0 [17] 3.0 [25] -3.0 [33] N/A [41] N/A [49] N/A [57] N/A	Unit: dB N/A N/A 3.0 3.0 3.0 2.0 -4.0 -5.0 N/A N/A N/A N/A N/A N/A N/A N/A	N/A 3.0 2.0 -5.0 N/A N/A N/A	-71.0 4.0 1.0 -6.0 N/A N/A N/A N/A	-61.0 4.0 0.0 -7.0 N/A N/A N/A N/A	-18.0 4.0 -1.0 -8.0 N/A N/A N/A	-8.0 4.0 -2.0 -9.0 N/A N/A N/A
Quiet Line No DS [1] -120.0 [9] -141.0 [17] -141.0 [25] -138.0 [33] -129.0 [41] -120.0 [49] -119.0 [57] -118.0 [65] -118.0 [73] -117.0 [81] -117.0 [89] -116.0 	Dise PSD (QLN Unit: dB -140.0 -141.0 -141.0 -141.0 -140.0 -140.0 -138.0 -137.0 -127.0 -125.0 -119.0 -119.0 -118.0 -97.0 -117.0 -117.0 -117.0 -117.0 -116.0 -116.0	(f)) -141.0 - -141.0 - -140.0 - -136.0 - -136.0 - -124.0 - -118.0 - -119.0 - -117.0 - -117.0 - -117.0 - -117.0 - -117.0 - -116.0 -	-141.0 -141.0 -139.0 -134.0 -124.0 -119.0 -118.0 -117.0 -116.0 -116.0	-141.0 -141.0 -140.0 -134.0 -122.0 -119.0 -118.0 -117.0 -116.0 -116.0 -116.0	-141.0 -141.0 -140.0 -132.0 -121.0 -119.0 -118.0 -118.0 -117.0 -117.0 -117.0	-141.0 -141.0 -139.0 -130.0 -121.0 -119.0 -118.0 -118.0 -117.0 -117.0 -117.0 -116.0
[441] -113.0 [449] -113.0 [457] -113.0 [465] -114.0 [473] -115.0 [473] -115.0 [481] -115.0 [489] -116.0 [497] -116.0 [505] -115.0	-113.0 -114.0 -114.0 -114.0 -114.0 -114.0 -114.0 -115.0 -115.0 -114.0 -115.0 -114.0 -115.0 -114.0 -115.0 -115.0 -116.0 -116.0 -116.0 -115.0	-114.0 - -114.0 - -114.0 - -115.0 - -115.0 - -114.0 - -116.0 - -115.0 - -116.0 -	-113.0 -114.0 -114.0 -114.0 -114.0 -115.0 -115.0 -115.0 -116.0	-114.0 -113.0 -114.0 -114.0 -114.0 -115.0 -115.0 -115.0 -116.0	-114.0 -114.0 -114.0 -114.0 -114.0 -115.0 -115.0 -115.0 -115.0	-114.0 -114.0 -114.0 -114.0 -115.0 -114.0 -115.0 -115.0 -115.0 -116.0
US [1] N/A [9] -113.0 [17] -115.0 [25] -116.0 [33] -118.0 [41] -119.0 [49] -118.0 [57] -119.0	Unit: dB -117.0 -118.0 -113.0 -114.0 -115.0 -115.0 -114.0 -115.0 -118.0 -119.0 -120.0 -118.0 -118.0 -118.0	-119.0 - -111.0 - -113.0 - -117.0 - -119.0 - -119.0 - -118.0 - -118.0 -	-118.0 -114.0 -115.0 -116.0 -118.0 -118.0 -118.0 -118.0	-118.0 -113.0 -116.0 -117.0 -118.0 -120.0 -119.0 -118.0	-117.0 -113.0 -108.0 -117.0 -118.0 -120.0 -119.0 -118.0	-117.0 -112.0 -113.0 -118.0 -118.0 -118.0 -118.0 -118.0 -118.0

Diagnostic and Performance Monitoring

DS [1] [9] [17] [25] [33] [41] [49] [57] [65] [73] [81] [89]	0.0 0.0 0.0 40.0 50.0 57.0 60.0 61.0 61.0	Unit: 0.0 0.0 0.0 31.0 41.0 52.0 57.0 59.0 61.0 61.0	dB 0.0 0.0 32.0 43.0 52.0 44.0 60.0 61.0 62.0	0.0 0.0 0.0 32.0 44.0 53.0 58.0 60.0 61.0 61.0	0.0 0.0 0.0 34.0 45.0 59.0 60.0 61.0 61.0	0.0 0.0 0.0 35.0 46.0 59.0 60.0 61.0 61.0	0.0 0.0 0.0 36.0 48.0 56.0 58.0 60.0 62.0 61.0	0.0 0.0 0.0 38.0 49.0 57.0 59.0 61.0 61.0 61.0	
[441] [449] [457] [465] [473] [481] [489] [497] [505]	55.0 55.0 54.0 53.0 52.0 52.0 50.0 48.0 41.0	55.0 55.0 54.0 53.0 53.0 52.0 50.0 46.0 38.0	55.0 54.0 54.0 53.0 51.0 50.0 45.0 38.0	54.0 55.0 54.0 53.0 52.0 51.0 50.0 43.0 38.0	55.0 54.0 54.0 53.0 52.0 49.0 43.0 37.0	55.0 54.0 53.0 52.0 51.0 49.0 42.0 32.0	55.0 54.0 53.0 53.0 51.0 49.0 42.0 32.0	54.0 53.0 53.0 52.0 51.0 48.0 41.0 25.0	
US [1] [9] [17] [25] [33] [41] [49] [57]	N/A 36. 0 52. 0 56. 0 N/A N/A N/A	Unit: N/A 42.0 52.0 55.0 N/A N/A N/A N/A	dB N/A 44.0 53.0 54.0 N/A N/A N/A N/A	N/A 46.0 53.0 52.0 N/A N/A N/A N/A	N/A 49.0 54.0 51.0 N/A N/A N/A	N/A 49.0 55.0 48.0 N/A N/A N/A	N/A 51.0 56.0 44.0 N/A N/A N/A	30.0 51.0 55.0 39.0 N/A N/A N/A	
CLI(dia OK CLI(dia Loop di Port 1 Used Pr	ng delt; ng delt; ag resu · 6 rofile:)# stop)# show ult: "ADSL_	<u>P</u> 6"						
Attaina Loop At Signal SnrMarg TxPower H(f) Ic DS	ble Rat tenuat Attenua in(dB) (dBm) ogarithr	te(Kbps) ion(dB) ation(dB nic repr Unit:	ATU- 2620 0.7) 0.0 6.0 12.3 esenta	-C ATU- 04.0 129 0.0 0.0 0.0 3 12.2 tion(H	-R 96.0)			
[1] [9] [17] [25] [33] [41] [49] [57] [65] [73] [81] [89]	-77. 0 -47. 0 -46. 0 -38. 0 -19. 0 -5. 0 -2. 0 -1. 0 0. 0 1. 0 2. 0	-35.0 -47.0 -53.0 -35.0 -17.0 -4.0 -2.0 -1.0 0.0 1.0 2.0 2.0	-39.0 -44.0 -50.0 -34.0 -15.0 -4.0 -2.0 -1.0 0.0 1.0 2.0 2.0	-39.0 -47.0 -54.0 -30.0 -13.0 -3.0 -2.0 -1.0 0.0 1.0 2.0 2.0	-44.0 -53.0 -54.0 -28.0 -11.0 -3.0 -2.0 -1.0 0.0 1.0 2.0 2.0	-47.0 -47.0 -26.0 -9.0 -3.0 -1.0 0.0 0.0 1.0 2.0 2.0	-44.0 -47.0 -23.0 -7.0 -2.0 -1.0 0.0 1.0 1.0 2.0 2.0	-44.0 -47.0 -40.0 -21.0 -2.0 -1.0 0.0 1.0 1.0 2.0 2.0	
 [441] [449] [457]	-1.0 -1.0 -2.0	-1.0 -1.0 -2.0	-1.0 -1.0 -2.0	-1.0 -2.0 -2.0	-1.0 -2.0 -3.0	-1.0 -2.0 -3.0	-1.0 -2.0 -3.0	-1.0 -2.0 -3.0	

[465] [473] [481] [489] [497] [505]	-3.0 -4.0 -6.0 -8.0 -10.0 -12.0	-3.0 -4.0 -6.0 -8.0 -10.0 -12.0	-3.0 -5.0 -6.0 -8.0 -10.0 -12.0	-3.0 -5.0 -6.0 -8.0 -11.0 -13.0	-4.0 -5.0 -7.0 -9.0 -11.0 -13.0	-4.0 -5.0 -7.0 -9.0 -11.0 -13.0	-4.0 -5.0 -7.0 -9.0 -11.0 -13.0	-4.0 -6.0 -7.0 -9.0 -12.0 -13.0
US [1] [9] [17] [25] [33] [41] [49] [57]	-34. 0 0. 0 3. 0 -3. 0 N/A N/A N/A	Unit N/A 3.0 3.0 -4.0 N/A N/A N/A	:: dB N/A 3.0 2.0 -5.0 N/A N/A N/A N/A	N/A 3.0 2.0 -5.0 N/A N/A N/A	-71.0 4.0 1.0 -6.0 N/A N/A N/A	-61.0 4.0 0.0 -7.0 N/A N/A N/A	-18.0 4.0 -1.0 -8.0 N/A N/A N/A	-8.0 4.0 -2.0 -9.0 N/A N/A N/A
Quiet DS [1] [9] [17] [25] [33] [41] [49] [57] [57] [73] [81] [89] 	Line No -120.0 -141.0 -141.0 -138.0 -129.0 -120.0 -119.0 -118.0 -118.0 -117.0 -117.0 -116.0	Dise PSL Unit -140.0 -141.0 -140.0 -138.0 -127.0 -119.0 -118.0 -118.0 -117.0 -117.0 -117.0 -117.0) (QLN4 -141.0 -141.0 -140.0 -137.0 -125.0 -119.0 -97.0 -117.0 -117.0 -117.0 -117.0	(f)) -141.0 -141.0 -140.0 -136.0 -124.0 -118.0 -119.0 -117.0 -117.0 -117.0 -117.0 -117.0	-141.0 -141.0 -139.0 -134.0 -114.0 -119.0 -118.0 -117.0 -117.0 -116.0 -117.0	-141.0 -141.0 -140.0 -134.0 -122.0 -119.0 -119.0 -118.0 -117.0 -116.0 -116.0 -116.0	-141.0 -141.0 -140.0 -132.0 -119.0 -119.0 -118.0 -118.0 -117.0 -117.0 -117.0	-141.0 -141.0 -139.0 -121.0 -119.0 -118.0 -118.0 -117.0 -117.0 -117.0 -116.0
 [441] [449] [457] [465] [473] [481] [489] [497] [505]	-113.0 -113.0 -113.0 -114.0 -115.0 -115.0 -116.0 -116.0 -115.0	-113.0 -114.0 -114.0 -115.0 -115.0 -115.0 -115.0 -116.0 -116.0	-114.0 -114.0 -114.0 -115.0 -114.0 -114.0 -115.0 -115.0 -116.0	-114.0 -114.0 -115.0 -115.0 -115.0 -114.0 -116.0 -115.0 -116.0	-113.0 -114.0 -114.0 -114.0 -114.0 -115.0 -115.0 -115.0 -115.0	-114.0 -113.0 -114.0 -114.0 -114.0 -115.0 -115.0 -115.0 -116.0	-114.0 -114.0 -114.0 -114.0 -114.0 -115.0 -115.0 -115.0 -116.0	-114.0 -114.0 -114.0 -114.0 -115.0 -115.0 -115.0 -115.0 -115.0
US [1] [9] [17] [25] [33] [41] [49] [57]	N/A -113.0 -115.0 -116.0 -118.0 -119.0 -118.0 -119.0	Unit -117.0 -113.0 -115.0 -114.0 -118.0 -120.0 -118.0 -119.0	-118.0 -114.0 -115.0 -115.0 -119.0 -119.0 -118.0 -118.0	-119.0 -111.0 -113.0 -117.0 -119.0 -119.0 -118.0 -118.0	-118.0 -114.0 -115.0 -116.0 -118.0 -118.0 -118.0 -118.0	-118.0 -113.0 -116.0 -117.0 -118.0 -120.0 -119.0 -118.0	-117.0 -113.0 -108.0 -117.0 -118.0 -120.0 -119.0 -118.0	-117.0 -112.0 -113.0 -118.0 -118.0 -118.0 -118.0 -118.0
SNR(f)		10					
[1] [9] [17] [25] [33] [41] [49] [57] [65] [73] [81] [89]	0.0 0.0 0.0 40.0 50.0 57.0 60.0 61.0 61.0	00011 0.0 0.0 0.0 31.0 41.0 52.0 57.0 59.0 61.0 61.0 61.0	0.0 0.0 0.0 0.0 32.0 43.0 52.0 44.0 60.0 61.0 61.0 62.0	0.0 0.0 0.0 32.0 44.0 53.0 58.0 60.0 61.0 61.0	0.0 0.0 0.0 34.0 54.0 59.0 60.0 61.0 61.0 61.0	0.0 0.0 0.0 35.0 54.0 59.0 60.0 61.0 61.0 61.0	0.0 0.0 0.0 36.0 48.0 56.0 58.0 60.0 62.0 61.0	0.0 0.0 38.0 49.0 57.0 59.0 61.0 61.0 61.0 61.0

. . .

•••								
[441]	55.0	55.0	55.0	54.0	55.0	55.0	55.0	54.0
[449]	55.0	55.0	54.0	55.0	54.0	54.0	54.0	54.0
[457]	54.0	54.0	54.0	54.0	54.0	54.0	54.0	53.0
[465]	54.0	53.0	54.0	53.0	54.0	53.0	53.0	53.0
[473]	53.0	53.0	53.0	52.0	53.0	52.0	53.0	52.0
[481]	52.0	52.0	51.0	51.0	52.0	51.0	51.0	51.0
[489]	50.0	50.0	50.0	50.0	49.0	49.0	49.0	48.0
[497]	48.0	46.0	45.0	43.0	43.0	42.0	42.0	41.0
[505]	41.0	38.0	38.0	38.0	37.0	32.0	32.0	25.0
110		11	10					
US		Unit	: dB					
US [1]	N⁄A	Unit N∕A	: dB N/A	N/A	N/A	N/A	N/A	30.0
US [1] [9]	N∕A 36.0	Unit N/A 42.0	: dB N/A 44.0	N/A 46.0	N/A 49.0	N/A 49.0	N⁄A 51.0	30.0 51.0
US [1] [9] [17]	N/A 36.0 52.0	Unit N/A 42.0 52.0	: dB N/A 44.0 53.0	N/A 46.0 53.0	N/A 49.0 54.0	N/A 49.0 55.0	N/A 51.0 56.0	30.0 51.0 55.0
US [1] [9] [17] [25]	N/A 36.0 52.0 56.0	Unit N/A 42.0 52.0 55.0	: dB N/A 44.0 53.0 54.0	N/A 46.0 53.0 52.0	N/A 49.0 54.0 51.0	N/A 49.0 55.0 48.0	N/A 51.0 56.0 44.0	30.0 51.0 55.0 39.0
US [1] [9] [17] [25] [33]	N/A 36.0 52.0 56.0 N/A	Unit N/A 42.0 52.0 55.0 N/A	: dB N/A 44.0 53.0 54.0 N/A	N/A 46.0 53.0 52.0 N/A	N/A 49.0 54.0 51.0 N/A	N/A 49.0 55.0 48.0 N/A	N/A 51.0 56.0 44.0 N/A	30.0 51.0 55.0 39.0 N/A
US [1] [9] [17] [25] [33] [41]	N/A 36.0 52.0 56.0 N/A N/A	Unit N/A 42.0 52.0 55.0 N/A N/A	: dB N/A 44.0 53.0 54.0 N/A N/A	N/A 46.0 53.0 52.0 N/A N/A	N/A 49.0 54.0 51.0 N/A N/A	N/A 49.0 55.0 48.0 N/A N/A	N/A 51.0 56.0 44.0 N/A N/A	30.0 51.0 55.0 39.0 N/A N/A
US [1] [9] [17] [25] [33] [41] [49]	N/A 36.0 52.0 56.0 N/A N/A N/A	Unit N/A 42.0 52.0 55.0 N/A N/A N/A	: dB N/A 44.0 53.0 54.0 N/A N/A N/A	N/A 46.0 53.0 52.0 N/A N/A N/A	N/A 49.0 54.0 51.0 N/A N/A N/A	N/A 49.0 55.0 48.0 N/A N/A N/A	N/A 51.0 56.0 44.0 N/A N/A N/A	30.0 51.0 55.0 39.0 N/A N/A N/A



It is suggested to view the graphical presentation of the DELT diagnosis via the NCT192 LCT or NCT192 client.

ADSL Link Monitoring

The ADSL link monitoring function provides the records of ADSL loop characteristics and Quite Line Noise (QLN) measured during the last training. It is noted that the measured results are only available in the show-time.

Enter to the "diag" group directory with "**portmon**" command to perform the ADSL link monitoring.

CLI**# diag** CLI(diag)#

Table 9-7 shows the commands to configure ADSL link monitoring of NE. Example 107 shows the usage of its command as well as its related parameters.

Table 9-7 ADSL Link Monitoring

The following command is to start the link monitoring process on the specific ADSL line port.

CLI(diag portmon)# start cport-id>

The following command is to manually terminate the ADSL link monitoring process.

CLI(diag portmon)# stop

The following command is to view the ADSL loop charactertics

CLI(diag portmon)# show	
Parameters	Task
<port-id></port-id>	Identify the port id of the system wish to perform the link monitoring, the define line port must operate in running status. Type: Mandatory Valid values: See the Section "Port Interface Indication" of Chapter 3.

Example 107 Display the ADSL loop charactertics (H(f)) and QLN

CLI(diag portmon)# start 1.6

CLI(diag portmon)# show Port monitor result: Port 1.6 H(f) logarithmic representation(Hlog(f)) DS Unit: dB [1] -77.0 -37.0 -39.0 -41.0 -41.0 -43.0 -44.0 -44.0 [9] -47.0 -47.0 -46.0 -47.0 -43.0 -46.0 -44.0 -47.0 -44.0 -47.0 -53.0 -51.0 -48.0 -41.0 -45.0 -40.0 [17] 25] -37.0 -36.0 -32.0 -30.0 -28.0 -25.0 -23.0 -21.0 ٢ [33] -19.0 -17.0 -15.0 -13.0 -11.0 -9.0 -7.0 -6.0 [41] -5.0 -4.0 -4.0 -3.0 -3.0 -3.0 -2.0 -2.0 [49] -2.0 -2.0 -2.0 -2.0 -2.0 -1.0 -1.0 -1.0 [57] -1.0 -1.0 -1.0 -1.0 -1.0 0.0 0.0 0.0 [65] 0.0 0.0 0.0 0.0 0.0 0.0 1.0 1.0 [73] 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 [81] 1.0 2.0 2.0 2.0 2.0 2.0 2.0 2.0 2.0 [89] 2.0 2.0 2.0 2.0 2.0 2.0 2.0 [441] -1.0 -1.0 -1.0 -2.0 -1.0 -2.0 -2.0 -2.0 -2.0 -2.0 -2.0 -2.0 [449] -2.0 -2.0 -2.0 -2.0 [457] -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -4.0 [465] -3.0 -4.0 -4.0 -4.0 -4.0 -4.0 -4.0 [473] -4.0 -4.0 -5.0 -5.0 -5.0 -5.0 -5.0 -5.0 [481] -5.0 -5.0 -5.0 -6.0 -6.0 -6.0 -6.0 -6.0 [489] -6.0 -6.0 -6.0 -7.0 -7.0 -7.0 -7.0 -7.0 -7.0 [497] -7.0 -7.0 -7.0 -7.0 -7.0 -7.0 -8.0 [505] -8.0 -8.0 -8.0 -8.0 -8.0 -8.0 -8.0 -8.0 US Unit: dB -32.0 N/A -68.0 -66.0 -59.0 -18.0 [1] N/A -8.0 [9] 0.0 3.0 3.0 3.0 4.0 4.0 4.0 4.0 [17] 3.0 3.0 2.0 2.0 1.0 0.0 -1.0 -2.0 -3.0 -4.0 -5.0 -5.0 -6.0 -7.0 -8.0 -9.0 [25] [33] N/A N/A N/A N/A N/A N/A N/A N/A [41] N/A N/A N/A N/A N/A N/A N/A N/A [49] N/A N/A N/A N/A N/A N/A N/A N/A [57] N/A N/A N/A N/A N/A N/A N/A N/A Quiet Line Noise PSD (QLN(f)) Unit: dB DS [1] -54.0 -110.0 -124.0 -134.0 -133.0 -144.0 -146.0 -146.0 ſ 9] -35.0 -35.0 -31.0 -35.0 -144.0 -30.0 -146.0 -35.0 [17] -146.0 -35.0 -63.0 -52.0 -38.0 -130.0 -23.0 -128.0 [25] -112.0 -107.0 -89.0 -78.0 -68.0 -54.0 -44.0 -33.0 [33] -149.0 -139.0 -128.0 -118.0 -109.0 -100.0 -92.0 -85.0 [41] -80.0 -76.0 -73.0 -70.0 -69.0 -68.0 -67.0 -66.0 [49] -65.0 -65.0 -64.0 -63.0 -63.0 -62.0 -61.0 -61.0 [57] -60.0 -60.0 -59.0 -58.0 -58.0 -57.0 -57.0 -56.0 [65] -55.0 -55.0 -54.0 -54.0 -53.0 -53.0 -52.0 -52.0 [73] -51.0 -51.0 -50.0 -50.0 -49.0 -49.0 -48.0 -48.0 [81] -48.0 -47.0 -47.0 -46.0 -46.0 -46.0 -46.0 -45.0 [89] -45.0 -45.0 -45.0 -44.0 -44.0 -44.0 -44.0 -44.0 [441] -61.0 -62.0 -62.0 -63.0 -62.0 -63.0 -63.0 -63.0 -63.0 [449] -64.0 -64.0 -65.0 -65.0 -66.0 -66.0 -67.0 -67.0 [457] -68.0 -68.0 -69.0 -69.0 -70.0 -70.0 -71.0 -71.0 [465] -72.0 -73.0 -73.0 -74.0 -74.0 -75.0 -75.0 -76.0 [473] -77.0 -77.0 -78.0 -78.0 -79.0 -80.0 -80.0 -80.0 [481] -81.0 -82.0 -82.0 -83.0 -84.0 -84.0 -85.0 -85.0 [489] -86.0 -86.0 -87.0 -88.0 -88.0 -88.0 -89.0 -89.0 [497] -90.0 -90.0 -91.0 -91.0 -92.0 -92.0 -92.0 -93.0 [505] -93.0 -93.0 -93.0 -93.0 -94.0 -94.0 -94.0 -93.0

0K

Unit: dB US [1] -86.0 N/A N/A -140.0 -131.0 -95.0 -145.0 -93.0 [9] -53.0 -42.0 -40.0 -38.0 -36.0 -35.0 -35.0 -36.0 [17] -38.0 -40.0 -44.0 -47.0 -51.0 -56.0 -61.0 -65.0 [25] -69.0 -74.0 -78.0 -82.0 -87.0 -91.0 -95.0 -98.0 [33] N/A N/A N/A N/A N/A N/A N/A N/A [41] N/A [49] N/A N/A N/A N/A [57] N/A N/A N/A N/A N/A N/A N/A CLI(diag portmon)# stop OK CLI(diag portmon)# show Port monitor result: Port 1.6 H(f) logarithmic representation(Hlog(f)) DS Unit: dB [1] -77.0 -37.0 -39.0 -41.0 -41.0 -43.0 -44.0 -44.0 [9] -47.0 -47.0 -46.0 -47.0 -43.0 -46.0 -44.0 -47.0 [17] -44.0 -47.0 -53.0 -51.0 -48.0 -41.0 -45.0 -40.0 [25] -37.0 -36.0 -32.0 -30.0 -28.0 -25.0 -23.0 -21.0 [33] -19.0 -17.0 -15.0 -13.0 -11.0 -9.0 -7.0 -6.0[41] -5.0 -4.0 -4.0 -3.0 -3.0 -3.0 -2.0 -2.0 -2.0 [49] -2.0 -2.0 -2.0 -2.0 -1.0 -1.0 -1.0 -1.0 -1.0 [57] -1.0 -1.0 -1.0 0.0 0.0 0.0 [65] 0.0 0.0 0.0 0.0 0.0 0.0 1.0 1.0 [73] 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 [81] 1.0 2.0 2.0 2.0 2.0 2.0 2.0 2.0 [89] 2.0 2.0 2.0 2.0 2.0 2.0 2.0 2.0 . . . [441] -1.0 -1.0 -1.0 -2.0 -1.0 -2.0 -2.0 -2.0 -2.0 -2.0 [449] -2.0 -2.0 -2.0 -2.0 -2.0 -2.0 [457] -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -3.0 -4.0 -4.0 [465] -3.0 -4.0 -4.0 -4.0 -4.0 -4.0 [473] -4.0 -4.0 -5.0 -5.0 -5.0 -5.0 -5.0 -5.0 [481] -5.0 -5.0 -5.0 -6.0 -6.0 -6.0 -6.0 -6.0 -7.0 -7.0 -6.0 -6.0 -6.0 -7.0 -7.0 -7.0 [489] [497] -7.0 -7.0 -7.0 -7.0 -7.0 -7.0 -7.0 -8.0 [505] -8.0 -8.0 -8.0 -8.0 -8.0 -8.0 -8.0 -8.0 US Unit: dB -32.0 N/A N/A -68.0 -66.0 -59.0 -18.0 -8.0 [1] ſ 9] 0.0 3.0 3.0 3.0 4.0 4.0 4.0 4.0 [17] 3.0 2.0 2.0 1.0 0.0 -1.0 -2.0 3.0 -6.0 -4.0 -5.0 -5.0 -7.0 -8.0 -9.0 [25] -3.0 [33] N/A N/A N/A N/A N/A N/A N/A N/A [41] N/A N/A N/A N/A N/A N/A N/A N/A [49] N/A N/A N/A N/A N/A N/A N/A N/A [57] N/A N/A N/A N/A N/A N/A N/A N/A Quiet Line Noise PSD (QLN(f)) DS Unit: dB [1] -54.0 -110.0 -124.0 -134.0 -133.0 -144.0 -146.0 -146.0 [9] -35.0 -35.0 -31.0 -35.0 -144.0 -30.0 -146.0 -35.0 [17] -146.0 -35.0 -63.0 -52.0 -38.0 -130.0 -23.0 -128.0 [25] -112.0 -107.0 -89.0 -78.0 -68.0 -54.0 -44.0 -33.0 [33] -149.0 -139.0 -128.0 -118.0 -109.0 -100.0 -92.0 -85.0 [41] -80.0 -76.0 -73.0 -70.0 -69.0 -68.0 -67.0 -66.0 [49] -65.0 -65.0 -64.0 -63.0 -63.0 -62.0 -61.0 -61.0 [57] -60.0 -60.0 -59.0 -58.0 -58.0 -57.0 -57.0 -56.0 [65] -55.0 -55.0 -54.0 -54.0 -53.0 -53.0 -52.0 -52.0 [73] -51.0 -51.0 -50.0 -50.0 -49.0 -49.0 -48.0 -48.0

 [81]
 -48.0
 -47.0
 -46.0
 -46.0
 -46.0
 -45.0

 [89]
 -45.0
 -45.0
 -45.0
 -44.0
 -44.0
 -44.0
 -44.0

 . . .

[441]] -61.0	-62.0	-62.0	-63.0	-62.0	-63.0	-63.0	-63.0
[449]] -64.0	-64.0	-65.0	-65.0	-66.0	-66.0	-67.0	-67.0
[457]	-68.0	-68.0	-69.0	-69.0	-70.0	-70.0	-71.0	-71.0
[465]] -72.0	-73.0	-73.0	-74.0	-74.0	-75.0	-75.0	-76.0
[473]] -77.0	-77.0	-78.0	-78.0	-79.0	-80.0	-80.0	-80.0
[481]] -81.0	-82.0	-82.0	-83.0	-84.0	-84.0	-85.0	-85.0
[489]	-86.0	-86.0	-87.0	-88.0	-88.0	-88.0	-89.0	-89.0
[497]] -90.0	-90.0	-91.0	-91.0	-92.0	-92.0	-92.0	-93.0
[505]] -93.0	-93.0	-93.0	-93.0	-94.0	-94.0	-94.0	-93.0
US		Unit	: dB					
US [1]] -86.0	Unit N∕A	: dB N/A	-140.0	-131.0	-95.0	-145.0	-93.0
US [1] [9]] -86.0] -53.0	Unit N/A -42.0	: dB N/A -40.0	-140.0 -38.0	-131.0 -36.0	-95.0 -35.0	-145.0 -35.0	-93.0 -36.0
US [1] [9] [17]] -86.0] -53.0] -38.0	Unit N/A -42.0 -40.0	: dB N/A -40.0 -44.0	-140.0 -38.0 -47.0	-131.0 -36.0 -51.0	-95.0 -35.0 -56.0	-145.0 -35.0 -61.0	-93.0 -36.0 -65.0
US [1] [9] [17] [25]] -86.0] -53.0] -38.0] -69.0	Unit N/A -42.0 -40.0 -74.0	: dB N/A -40.0 -44.0 -78.0	-140.0 -38.0 -47.0 -82.0	-131.0 -36.0 -51.0 -87.0	-95.0 -35.0 -56.0 -91.0	-145.0 -35.0 -61.0 -95.0	-93.0 -36.0 -65.0 -98.0
US [1] [9] [17] [25] [33]] -86.0] -53.0] -38.0] -69.0] N/A	Unit N/A -42.0 -40.0 -74.0 N/A	: dB N/A -40.0 -44.0 -78.0 N/A	-140.0 -38.0 -47.0 -82.0 N/A	-131.0 -36.0 -51.0 -87.0 N/A	-95.0 -35.0 -56.0 -91.0 N/A	-145.0 -35.0 -61.0 -95.0 N/A	-93.0 -36.0 -65.0 -98.0 N/A
US [1] [9] [17] [25] [33] [41]] -86.0] -53.0] -38.0] -69.0] N/A] N/A	Unit N/A -42.0 -40.0 -74.0 N/A N/A	: dB N/A -40.0 -44.0 -78.0 N/A N/A	-140.0 -38.0 -47.0 -82.0 N/A N/A	-131.0 -36.0 -51.0 -87.0 N/A N/A	-95.0 -35.0 -56.0 -91.0 N/A N/A	-145.0 -35.0 -61.0 -95.0 N/A N/A	-93.0 -36.0 -65.0 -98.0 N/A N/A
US [1] [9] [17] [25] [33] [41] [49]	 -86.0 -53.0 -38.0 -69.0 N/A N/A N/A 	Unit N/A -42.0 -40.0 -74.0 N/A N/A N/A	: dB N/A -40.0 -44.0 -78.0 N/A N/A	-140.0 -38.0 -47.0 -82.0 N/A N/A N/A	-131.0 -36.0 -51.0 -87.0 N/A N/A N/A	-95.0 -35.0 -56.0 -91.0 N/A N/A N/A	-145.0 -35.0 -61.0 -95.0 N/A N/A N/A	-93.0 -36.0 -65.0 -98.0 N/A N/A N/A



It is suggested to view the graphical presentation of the ADSL loop characteristics and QLN via the NCT192 LCT or NCT192 client.

Loop SELT Test (Single End Loop Test)

The SELT loop function diagnosis function is to estimate the distance of the DSL connection from the NE to the subscriber's location without connecting a subscriber device.

Enter to the "diag" group directory with "selt" command to perform the SELT link monitoring.

CLI**# diag selt** CLI(diag selt)#

Table 9-8 shows the commands to configure SELT link monitoring of NE. Example 108 shows the usage of its command as well as its related parameters.

Table 9-8 SELT Link Monitoring

The following command is to start the SELT process on the specific ADSL line port.
CLI(diag selt)# start <port-id></port-id>
The following command is to view the SELT result.

Parameters	Task
<port-id></port-id>	Identify the port id of the system wish to perform the link monitoring, the define line port must operate in running status. Valid values: See the Section "Port Interface Indication" of Chapter 3.

Example 108 Diagnosing the run-time ADSL line port loop performance

CLI(diag selt)# **start 1.6** OK: But the result displays by diag selt show.

CLI(diag selt)# show

Port single end loop test result: Port 1. 6

Cable Type: 24 AWG

. . .

Loop Length: 13468 (ft.)



Please refer to ITU-T 992.3 for the details of SELT.

Network Ping Test

The "**ping**" command is a very common method for troubleshooting the accessibility of devices. It uses a series of ICMP (Internet Control Message Protocol) Echo messages to determine if the NE can reach the target or not.

To diagnose the remote hosts using the "ping" command at the prompt for CLI#. (From UGE or MGE)

Table 9-9 shows the commands to set network ping test. Example 109 shows the usage of its command as well as its related parameters.

Table 9-9 Network Ping Test

The following command is to send the ICMP Echo message to target host.

CLI# ping <hostname>

Parameters	Task
<hostname></hostname>	Defines IP address or hostname of the target host to reply ICMP Echo message.
	Type: Mandatory
	Valid values: 0.0.0.0 ~ 255.255.255.255 string

Example 109 Using Ping command to test the remote host status

CLI# ping 192.168.192.1

192.168.192.1 PING Statistics: 5 packets transmitted, 5 packets received

Monitoring the System Environment

In the hardware monitoring list dialog, you can monitor the temperature and voltage status of any specific card module.

Enter to the "**status**" group directory with proper command to perform the system environment monitoring.

CLI**# status** CLI(status)#

Table 9-10 shows the commands to display the system environment monitoring. Example 110 shows the usage of its command as well as its related parameters.

Table 9-10 System Environment Monitoring

The following command is to display the system ventilation fan speed information.

CLI(status)# fanspeed show

The following command is to display the temperature of specific line card.

CLI(status)# temp show lc <lc-id>

The following command is to display the temperature of network card.

CLI(status)# temp show nc

The following command is to display the voltage of fan module.

CLI(status)# voltage show fan

The following command is to display the voltage of specific line card.

CLI(status)# voltage show lc <lc-id>

The following command is to display the voltage of network card.

CLI(status)# voltage show nc

Parameters	Task
<lc-id></lc-id>	Identify the slot range of the line card
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.

Example 110 Display the performance monitor of the system environment

CLI(status)# fanspeed show

fan	fan speed (rpm)	fan status
1	4428	FAILED (2880~4320)
2	4551	FAILED (2880~4320)

CLI(status)# temp show Ic 1

Temperature of LC 1 (centigrade)

threshold-low	threshold-high	temperature	sensor
5	95	43	sensor1 (g767 local)
5	95	41	sensor2 (g767 remote)
-	95	37	sensor3 (max6652 #1)
	95	34	sensor4 (max6652 #1)

CLI(status)# temp show nc

Temperature of network card 1 (centigrade).

sensor	temperature	threshold-high	threshold-low
sensor1 (g767 local)	40	95	5
sensor2 (g767 remote)	35	95	5
sensor3 (max6652 #1)	35	95	-

CLI(status)# voltage show fan

fan tray (5V)	: 4.97 \	l
low threshold	: 4.00 \	l
high threshold	: 5.00 \	l

CLI(status)# voltage show ic 1

Diagnostic and Performance Monitoring

LC 1

VO	Itage	of	the	first	m

voltage of the	first	max6652		
item		voltage	threshold-high	threshold-low
voltage (1	.2V)	1.17	1.31	1.08
voltage (1	2 V)	11.78	13.19	10.88
voltage (1	.8V)	1.77	1.98	1.63
voltage (3	.2V)	3.15	3.51	2.89
voltage of the	secon	d max6652		
item		voltage	threshold-high	threshold-low
voltage (1	.5V)	1.47	1.64	1.35
voltage (0 V)	0.00	0.00	0.00
voltage (2	.5V)	2.49	2.75	2.27
voltage (3	.2V)	3.15	3.51	2.89

CLI(status)**# voltage show nc** Voltage of network card 1

itage of network	k card i		
item	voltage	threshold-high	threshold-low
voltage (1.25	V) 1.22	1.36	1.13
voltage (2.5	V) 2.48	2.75	2.25
voltage (1.8 '	V) 1.77	1.98	1.63
voltage (3.3 '	V) 3.28	3.61	2.99

Monitoring the System Performance

Enter to the "status" group directory with proper command to perform the system environment monitoring.

CLI# status CLI(status)#

Table 9-11 shows the commands to display the system performance parameters.Example 111 shows the usage of its command as well as its related parameters.

Table 9-11 System Performance Monitoring

The following command is to show adsl line historical performance data (15 minutes per interval).

CLI(status)# perf show history-15-min cport-id> <start-interval>

The following command is to show adsl line historical performance data (1day per interval).

CLI(status)# perf show history-1-day <port-id>

The following command is to show those VLANs on specific line cards that currently are allowed to forward broadcast packets.

CLI(status)# broadcast dsfilter show [<slot-range>]

The following command is to display LACP status.

CLI(status)# lacp show

The following command is to display line card status.

CLI(status)# lcstatus show

The following command is to display RSTP status.

CLI(status)# rstp show [bridge | uge]

The following command is to display the system up time.

CLI(status)# time show

Parameters	Task
<port-id></port-id>	Identify the port id of the system wish to perform the link monitoring, the define line port must operate in running status.
	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
<start-interval></start-interval>	This specifies the adsl line historical performance data (15 minutes per interval).
	Valid values: 1 ~ 96
<slot-range></slot-range>	Identify the slot range of the line card
C C	Type: Mandatory
	Valid values: See the Section "Port Interface Indication" of Chapter 3.
[bridge uge]	This specifies the Rapid Spanning Tree Protocol status
	Type: Mandatory
	Valid value: bridge, uge

Example 111 Display the performance monitor of the system

CLI(status)# perf show history-15-min 1.6 5

Port: 1.6 interv	val: 5/96		
rxCells:	0	txCells:	0
!	Near End	Far End	
UAS	0	0	
LOFs	0	0	
LOSs	0	0	
LPRs	0	0	
ES	0	0	
SES	0	0	
CV	0	0	
INITS	0		
FailINITs	0		
Port: 1.6 interv	val: 6/96		
rxCells:	0	txCells:	0

Near End Far End

UAS LOFs LOSs LPRs ES SES CV INITS	0 0 0 0 0 0 0 0 0	
FailINITs	0	
Port: 1.6 inte rxCells:	erval: 7/96 0	txCells:
	Near End	Far End
UAS LOFs LOSs LPRs ES SES CV INITs FailINITS		
Port: 1.6 inte rxCells:	erval: 8/96	txCells:
	Near End	Far End
UAS LOFs LOSs LPRs ES SES CV INITs FailINITS	Near End 0 0 0 0 0 0 0 0 0 0 0 0	Far End 0 0 0 0 0 0 0 0 0 0
UAS LOFs LOSs LPRs ES SES CV INITS FailINITS CLI(status) # br Down stream bro No any filt	Near End 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Far End 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
UAS LOFs LOSs EPRs ES SES CV INITS FailINITS CLI(status) # br Down stream bro No any filt	Near End 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Far End 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
UAS LOFs LOSs LPRs ES SES CV INITS FailINITS CLI(status)# br Down stream bro No any filt CLI(status)# ia LACP	Near End 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Far End 0 0 0 0 0 0 0 0 0 0 0 0 0

CLI(status)# Icstatus show

Line ca	nd stat	us
LC	type	status
1	ADSL	active
2	SHDSL	active
3	ADSL	active
4	ADSL	active

CLI(status)# rstp show

[bridge]
oper status
force version
bridge ID

: disabled : RSTP

0

0

- : 0x8000-00:60:64:dc:7a:17

bridge priority: 32768bridge hello time: 2 secbridge forward delay: 15 secbridge max age: 20 secbridge message age: 0 secbridge Tx hold count: 3root path cost: 0root port ID: 0x8000-00:60:64:dc:7a:17root bridge priority: 0 x8000topology change count: 0time since last topology change: 0 secroot forward delay: 15 secroot max age: 20 secdesignated bridge ID: 0x8000-00:60:64:dc:7a:17designated port ID: 0x8000-00:60:64:dc:7a:17 GE 1] STP admin status : enabled STP oper status : enabled port ID : 0x8001 port priority : 128 STP state : broken role : disabled admin path cost : 0 (default) oper path cost : 20000 admin non-STP : no admin edge port : no oper edge port : no oper edge port : no admin P2P MAC : auto oper P2P MAC : yes send RSTP BPDU : yes mcheck : no root bridge ID : 0x8000-00:60:64:dc:7a:17 root bridge priority : 0x8000 root hello time : 2 sec root forward delay : 15 sec root max age : 20 sec designated bridge ID : 0x8001 [UGE 1]

CLI(status)# time show

system	uptime	:	120:56:43		
system	datetime	:	2007-10-31	11:08:42	GMT+8

Appendix A Abbreviations and Acronyms

The abbreviations and acronyms used in this document.

Abbreviations	Full Name
AAL	ATM Adaptation Layer
ADSL	Asymmetric Digital Subscriber line
ATM	Asynchronous Transfer Mode
ATU-C	ADSL Transceiver Unit at the central office end
ATU-R	ADSL Transceiver Unit at the remote end
CV	Coding Violation
DSCP	Differentiated Service Code Point
DSLAM	Digital Subscriber line Access Multiplexer
ES	Error Seconds
EOA	Ethernet over ATM
GBIC	Gigabit Interface Converter
GE	Gigabit Ethernet
IP	Internet Protocol
LAN	Local Area Network
LOF	Loss of Frame
LOS	Loss of Signal
LPR	Loss of Power
OAM	Operation, Administration, and Maintenance
PSD	Power Spectral Density
PVC	Permanent Virtual Channel
SFP	Small Form Pluggable
SNR	Signal-to Noise Ratio
SNMP	Simple Network Management Protocol
UAS	Unavailable Seconds
UBR	Unspecified Bit Rate
VC	Virtual Channel
VCI	Virtual Channel Identify
VCL	Virtual Channel Link
VLAN	Virtual Local Area Network
VP	Virtual Path
VPI	Virtual Path Identifier
WAN	Wide Area Network
xDSL	ADSL/SHDSL

Table A-1 Abbreviations and Acronyms Table

This page is leave in blank for note or memo use

Appendix B Alarm Definition

NE Model	Module Name	Alarm Name	Default Severity	Alarm Description
All	noEntity	EMPTY	No	Neither plan type nor on-line type configured
NCT192		MISSING	Major	CPU Module is off-line
		TEMP	Major	Temperature is over the threshold
		VOL Major Voltage is below		Voltage is below the threshold
	CPU Module	MISMATCH	Major	Planned type and online type are mismatched
		TCA_DHCP_BC	Warning	DHCP broadcast request rate threshold-crossing alert
		MISSING	Major	ADSL module is off-line
		TEMP	Major	Temperature is over the threshold
	ADSL Module	VOL	Major	Voltage is below the threshold
		MISMATCH	Major	Planned type and online type are mismatched
		NOT_OPERABLE	Major	ADSL line card is not operable
	D)(11	MISSING	Major	Power module is off-line
	Power Module	NOT_OPERABLE	Major	Power card is not operable
		MISSING	Major	Fan module is off-line
	F M 11	FAN1_SPEED	Major	Fan1 speed is below the threshold
	Fan Module	FAN2_SPEED	Major	Fan2 speed is below the threshold
		VOL	Major	Voltage is below the threshold
		ES_NE_15_MIN	Minor	15 min near end ES is over threshold
		SES_NE_15_MIN	Minor	15 min near end SES is over threshold
		UAS_NE_15_MIN	Minor	15 min near end UAS is over threshold
	ADSL Port	ES_FE_15_MIN	Minor	15 min far end ES is over threshold
		SES_FE_15_MIN	Minor	15 min far end SES is over threshold
		UAS_FE_15_MIN	Minor	15 min far end UAS is over threshold
		ES_NE_1_DAY	Minor	1 day near end ES is over threshold
		SES_NE_1_DAY	Minor	1 day near end SES is over threshold
		UAS_NE_1_DAY	Minor	1 day near end UAS is over threshold
		ES_FE_1_DAY	Minor	1 day far end ES is over threshold
		SES_FE_1_DAY	Minor	1 day far end SES is over threshold
		UAS_FE_1_DAY	Minor	1 day far end UAS is over threshold
		LOS	Minor	Loss of signal
		LOF	Minor	Loss of frame
		LPWR	Warning	CPE loss of power
		GEN_LINE_INIT_FAIL	Minor	Generic line initialization failure
		CONFIG_ERROR	Minor	Line initialization failure - configuration error
		HIGH_BIT_RATE	Minor	Line initialization failure - high bit rate
		COMM_PROBLEM	Minor	Line initialization failure - communication problem
		NO_PEER_DETECTED	Minor	No peer detected
		TRAINING	Warning	Port is under training
		NO_CONFIG	Information	Port is not configured
		PS_L2_MANUAL	Information	ADSL2/ADSL2+ Power State transfers to L2 by manual mode

Table B-1Alarm Definition

NE Model	Module Name	Alarm Name Default Severity		Alarm Description
NCT192	ADSL Port	PS_L2_AUTO	Information	ADSL2/ADSL2+ Power State transfers to L2 by automatic mode
		PS_L3_CO	Information	ADSL2/ADSL2+ Power State transfers to L3 by CO side
		PS_L3_CPE	PE Information ADSL2/ADSL2+ Power Sta L3 by CPE side	
		ILLEGAL_IP	Warning	Packets with illegal IP addresses have been dropped
		ILLEGAL_MAC Warning duplicated MAC address line ports are made out		duplicated MAC addresses from different line ports are made out
		DISABLED	Information	The port is disabled
		MISSING	Major	GE Port is off-line
		NOT_OPERABLE	Major	GE Port is not operable
	GE Port	STP_LEARN	Information	GE port is transited to STP-learning state
		STP_BLOCK	Information	GE port is transited to STP-blocking state
		DISABLED	Information	GE port is disabled
	Alarm Relay Module	MISSING	Major	Alarm relay module is off-line
		MISSING	Major	Alarm relay port is off-line
	Alarm Relay Port	RELAY_ABNORMAL	Major	The alarm relay port is under abnormal status
		DISABLED	Information	The alarm repay port is disabled
		MISSING	Major	SHDSL module is off-line
		TEMP	Major Major	Temperature is over the threshold
	SHDSL Module	MISMATCH	Major	Planned type and online type are
			Major	mismatched
		TCA ES NE 15 MIN	Minor	15-min pear end ES is over the threshold
		TCA SES NE 15 MIN	Minor	15-min near end SES is over the threshold
		TCA UAS NE 15 MIN	Minor	15-min near end UAS is over the threshold
	SHDSL Port	TCA CRC NE 15MIN	Minor	15-min near end CRC is over the threshold
		TCA_LOSW_NE_15MIN	Minor	15-min near end LOSW is over the threshold
		TCA_SNR_NE	Minor	Near end SNR margin is over the threshold
		TCA_ATTN_NE	Minor	Near end loop attenuation is over the threshold
		OPI	Information	Operation state change indication
		LOS	Minor	Loss of signal (FOH lost bit)
		SEGA	Minor	Segment anomaly - CRC anomaly (FOH sega bit)
		LPR	Minor	Loss of power - power status (FOH ps bit)
		SEGD	Minor	bit)
		PBO_NE	Minor	Near end enhanced power back off
		DEVFAULT_NE	Minor	Near end device fault - Diagnostic or self-test fault
		DCCONT_NE	Minor	Near end DC continuity fault - interfere with span powering
		LOSW_NE	Minor	Near end LOSW failure
		INI_CFG_NE	Minor	support requested configuration
		INI_PROTOCOL_NE	Minor	Near end indicates incompatible protocol used by Far end
		NOPEER	Minor	No peer detected
		PBO_FE	Minor	Far end enhanced power back off
		DEVFAULT_FE	Minor	Far end device fault - Diagnostic or self-test fault
		DCCONT_FE	Minor	Far end DC continuity fault - interfere with span powering

NE Model	Module Name	Alarm Name	Default Severity	Alarm Description
NCT192		LOSW_FE	Minor	Far end LOSW failure
SHDSI Port		INI_CFG_FE	Minor	Far end indicates Near end not able to support requested configuration
SIDSETOR	Shibbliton	INI_PROTOCOL_FE	Minor	Far end indicates incompatible protocol used by Near end
		DISABLED	Information	The port is disabled

Appendix C: Legal & Regulatory Information

This manual is copyright. Apart from any fair dealing for the purposes of private study, research, criticism or review, as permitted under the Copyright Act, no part may be reproduced, stored in a retrieval system or transmitted in any form, by any means, be it electronic, mechanical, recording or otherwise, without the prior written permission of NetComm Limited. NetComm Limited accepts no liability or responsibility, for consequences arising from the use of this product.

NetComm Limited reserves the right to change the specifications and operating details of this product without notice.

NetComm is a registered trademark of NetComm Limited.

All other trademarks are acknowledged the property of their respective owners.

Customer Information

ACA (Australian Communications Authority) requires you to be aware of the following information and warnings:

- (1) This unit shall be connected to the Telecommunication Network through a line cord which meets the requirements of the ACA TS008 Standard.
- (2) This equipment has been tested and found to comply with the Standards for C-Tick and or A-Tick as set by the ACA. These standards are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio noise and, if not installed and used in accordance with the instructions detailed within this manual, may cause interference to radio communications. However, there is no guarantee that interference will not occur with the installation of this product in your home or office. If this equipment does cause some degree of interference to radio or television reception, which can be determined by turning the equipment off and on, we encourage the user to try to correct the interference by one or more of the following measures:
- Change the direction or relocate the receiving antenna.
- Increase the separation between this equipment and the receiver.
- Connect the equipment to an alternate power outlet on a different power circuit from that to which the receiver/TV is connected.
- Consult an experienced radio/TV technician for help.
- (3) The power supply that is provided with this unit is only intended for use with this product. Do not use this power supply with any other product or do not use any other power supply that is not approved for use with this product by NetComm. Failure to do so may cause damage to this product, fire or result in personal injury.

Product Warranty

The warranty is granted on the following conditions:

- 1. This warranty extends to the original purchaser (you) and is not transferable;
- 2. This warranty shall not apply to software programs, batteries, power supplies, cables or other accessories supplied in or with the product;
- The customer complies with all of the terms of any relevant agreement with NetComm and any other reasonable requirements of NetComm including producing such evidence of purchase as NetComm may require;
- 4. The cost of transporting product to and from NetComm's nominated premises is your responsibility; and,
- 5. NetComm does not have any liability or responsibility under this warranty where any cost, loss, injury or damage of any kind, whether direct, indirect, consequential, incidental or otherwise arises out of events beyond NetComm's reasonable control. This includes but is not limited to: acts of God, war, riot, embargoes, acts of civil or military authorities, fire, floods, electricity outages, lightning, power surges, or shortages of materials or labour.

6. The customer is responsible for the security of their computer and network at all times. Security features may be disabled within the factory default settings. NetComm recommends that you enable these features to enhance your security.

The warranty is automatically voided if:

- 1. You, or someone else, use the product, or attempts to use it, other than as specified by NetComm;
- 2. The fault or defect in your product is the result of a voltage surge subjected to the product either by the way of power supply or communication line, whether caused by thunderstorm activity or any other cause(s);
- 3. The fault is the result of accidental damage or damage in transit, including but not limited to liquid spillage;
- 4. Your product has been used for any purposes other than that for which it is sold, or in any way other than in strict accordance with the user manual supplied;
- 5. Your product has been repaired or modified or attempted to be repaired or modified, other than by a qualified person at a service centre authorised by NetComm; and,
- 6. The serial number has been defaced or altered in any way or if the serial number plate has been removed.

Limitations of Warranty

The Trade Practices Act 1974 and corresponding State and Territory Fair Trading Acts or legalisation of another Government ("the relevant acts") in certain circumstances imply mandatory conditions and warranties which cannot be excluded. This warranty is in addition to and not in replacement for such conditions and warranties.

To the extent permitted by the Relevant Acts, in relation to your product and any other materials provided with the product ("the Goods") the liability of NetComm under the Relevant Acts is limited at the option of NetComm to:

- · Replacement of the Goods; or
- Repair of the Goods; or
- Payment of the cost of replacing the Goods; or
- Payment of the cost of having the Goods repaired.

All NetComm ACN 002 490 486 products have a standard 12 months warranty from date of purchase. However some products have an extended warranty option (refer to packaging). To be eligible for the extended warranty you must supply the requested warranty information to NetComm within 30 days of the original purchase by registering on-line via the NetComm web site at

www.netcomm.com.au



Product Warranty

NetComm products have a standard 12 months warranty from date of purchase. However some products have an extended warranty option, via registering your product online at the NetComm website **www.netcomm.com.au**.

Technical Support

If you have any technical difficulties with your product, please refer to the support section of our website. WWW.netcomm.com.au/support

Note: NetComm Technical Support for this product only covers the basic installation and features outlined in the Quick Start Guide. For further information regarding the advanced features of this product, please refer to the configuring sections in the User Guide or contact a Network Specialist.



 PTCOMM LIMITED
 PO Box 1200, Lane Cove NSW 2066 Australia

 P: 02 9424 2070
 F: 02 9424 2010

 E: sales@netcomm.com.au
 W: www.netcomm.com.au



DYNALINK NZ 224b Bush Road, Albany, Auckland, New Zealand P: 09 448 5548 F: 09 448 5549 E: sales@dynalink.co.nz W: www.dynalink.co.nz

Trademarks and registered trademarks are the property of NetComm Limited or their respective owners. Specifications are subject to change without notice. Images shown may vary slightly from the actual product.