

External Modem User's Manual

External Modem User's Manual

No part of this publication may be reproduced in any form by any means without the prior written permission.
Other trademarks or brand names mentioned herein are trademarks or registered trademarks of their respective companies.

November 2000

Contents

CHAPTER 1 BEFORE YOU BEGIN	1
1.1 Features	1
1.2 Package Contents	1
1.3 Minimum System Requirements	1
CHAPTER 2 HARDWARE INSTALLATION.....	3
2.1 Connecting Your Modem.....	3
2.2 LED Indicators	3
CHAPTER 3 DRIVER INSTALLATION	5
3.1 Driver Installation for Windows 95	5
3.2 Driver Installation for Windows 98	8
3.3 Driver Installation for Windows Me.....	12
3.4 Driver Installation for Windows NT 4.0.....	15
3.5 Driver Installation for Windows 2000.....	18
3.6 Country Selection for Windows 95/98/Me/NT/2000.....	20
3.7 Verify that Your Modem is Properly Installed	22
3.7.1 For Windows 95/98/Me.....	22
3.7.2 For Windows 2000	24
3.8 Software Installation for Linux Red Hat 6.0.....	27
CHAPTER 4 DRIVER UNINSTALLATION.....	29
4.1 Uninstallation from Windows 95/98/Me.....	29
4.2 Uninstallation from Windows NT 4.0	30
4.3 Uninstallation from Windows 2000	32
CHAPTER 5 COMMAND REFERENCE.....	35
5.1 AT Commands.....	35
5.1.1 Basic Command Set	35
5.1.2 Commands Preceded by &.....	38
5.2 Dial Modifiers.....	41
5.3 Commands Not Preceded By AT	42
5.4 S Register Reference	43
5.4.1 Register Summary	43
5.4.2 Glossary of the S Registers	43
CHAPTER 6 MODEM REFERENCE	49
6.1 Troubleshooting.....	49
6.2 Result Codes	49
6.3 Application Examples	50
6.3.1 Dialing a Remote Modem.....	50
6.3.2 Dialing a Stored Number	50
6.3.3 Manual Answer an Incoming Call.....	51
6.3.4 Auto Answer an Incoming Call	51
6.3.5 Voice to Data Switch	51
APPENDICES	53
Appendix A: Caller ID Commands (Optional).....	53
Appendix B: Technical Specifications	55
Appendix C: Quick Reference	56
Appendix D: Glossary	57
Appendix E: ASCII CODE TABLE.....	59
Appendix F: FCC/DOC REQUIREMENTS.....	60

F.1 FCC General Information60

F.2 FCC Notice60

F.3 DOC Notice..... 60

CHAPTER 1

BEFORE YOU BEGIN

1.1 Features

These Fax/Data Modems combine the features of a 56000(receive only)/33600/28800/14400/9600 bps data modem and a 14400/9600 bps FAX modem. Your new Fax/Data Modem gives your personal computer the ability to send and receive FAX messages over the telephone line like a standard FAX machine. Your Fax/Data Modem also allows your PC to communicate with other personal computers, terminals or BBS's (Bulletin Board Systems) through the data modem functions.

When used as a data modem your Fax/Data Modem uses the standard AT command set and is fully compatible with ITU-T V.42, V.42bis, V.34 (ANNEX 12), V.32bis, V.32, V.22bis, V.23, V.22, V.21, MNP 2-5, Bell 103, 212A, V.90. When used as a Fax/Data Modem it communicates with all ITU-T Group 3 FAX machines and is compatible with ITU-T V.27ter and V.29, V.17, T.4 and T.30. Switching between DATA mode operation and FAX mode operation of your Fax/Data Modem is done through its firmware, no hardware settings are required.

The communication software, which should be used, depends on the kind of machine that you are going to communicate with. If you are going to call a FAX machine then you must use the Fax software. If the machine that you are going to communicate with is a modem then you must use a data modem communications software.

Note: This manual is written to be used for several models of Fax/Data Modems. Some of the information in this manual may not apply to your fax/data modem.

All the description in this manual about Caller ID, V.90 and Fax class 1 applies only to the models which support these functions.

1.2 Package Contents

Before installation, please check the items of your package. The package should include the following items:

- The External Modem
- Quick Installation
- Installation CD

If any of the above items are missing, please contact your supplier.

1.3 Minimum System Requirements

Before installation, please check the following requirements with your equipment:

- Pentium MMX CPU 166 or above (Recommended CPU: Intel Pentium MMX , AMD K6 MMX, Cyrix 6x86 MMX)
- 16MB RAM
- Operating System: Windows 95/ 98 /Me/ NT 4.0 /2000 /Linux RedHat
- CD-ROM drive

CHAPTER 2

HARDWARE INSTALLATION

2.1 Connecting Your Modem

Step 1: Power off your computer.


Step 2: Connect one end of the RS-232 serial cable to the modem and the other to your computer's serial port.

Note: Connect the male end of the RS-232 cable to the modem's serial port and the female end to your computer. Choose suitable 9-pin or 25-pin female connector according to your computer's serial port.

Step 3: Plug one end of the RJ-11 phone cord into the **LINE** jack on the modem, and plug the other end into your phone jack.

Step 4: Plug the AC adapter into the modem's **AC IN** jack, and plug the other end into an electrical outlet.

The diagram below illustrates the typical external modem connection:



2.2 LED Indicators

After hardware installation, turn on the modem and then your computer. The PWR, HS, and MR LEDs should illuminate. The description of the LED indicators on the front panel are listed below: (from left to right)

MR	Modem Ready/ Self-testing	On: Power on Flash: Self-testing/ In diagnostic mode
HS	High Speed Speeds	On: Operating speed at 24000bps or higher
CD	Carrier Detect	On: Receiving a data carrier signal from remote modem
OH	Off Hook	On: Modem off hook OFF: Modem on hook
SD	Send Data	Flash: Transferring data from the modem
RD	Receive Data	Flash: Receiving data from the modem
TR	Terminal Ready	ON: Modem is on (unless setup by AT commands)
AA	Auto-answer	On: Set up to answer incoming calls
PWR	Power	ON: power on

CHAPTER 3

DRIVER INSTALLATION

After hardware installation, turn on your modem and then power on your PC. Follow the instructions below to install the drivers for the modem.

3.1 Driver Installation for Windows 95


Step 1: Start Windows 95. The **Update Device Driver Wizard** appears. Insert the provided Installation CD into your CD-ROM drive. Click **Next**.



Step 2: Windows will be unable to locate a driver. Click **Other Locations**.




Step 3: Click **Browse** to locate the path of the driver: **x:\Driver\Win9x** (where x is your CD-ROM drive) and click **OK**.




Step 4: Windows will find the location of driver; click **Finish**.



Step 5: When **Insert Disk** window appears, click **OK**.



Step 6: Click **Browse** to locate the path of the driver: **x:\Driver\Win9x** (where x is your CD-ROM drive) and click **OK**.




Step 7: Windows will continue to detect another device. Click **Next**.



Step 9: Click **Other Locations**.



Step 10: Click **Browse** to locate the path of the driver: **x:\Driver\Win9x** (where x is your CD-ROM drive) and click **OK**.




Step 11: Click **Finish** to complete installation.



When you are done with driver installation, you will need to specify the country where you locate upon different telecommunication regulations/ laws. Please proceed to “**3.6 Country Selection for Windows 95/98/Me/NT/2000**” on page 20 for instructions.

3.2 Driver Installation for Windows 98

- Step 1: Start Windows 98. The **Add New Hardware Wizard** appears announcing the detecting of a new hardware. Click **Next**. Insert the provided Installation CD into your CD-ROM drive.




- Step 2: Select **Search for the best driver for your device** and click **Next**.




- Step 3: Check **Specify a location**. Click **Browse** to locate the path of the driver: **x:\Driver\Win9x** (where x is your CD-ROM drive) and click **OK**. Click **Next**.



Step 4: When Windows finds the driver file for the device, click **Next**.




Step 5: Click **Finish** to complete the installation.



Step 6: Windows will continue to detect another device. Click **Next**.



Step 7: With **Search for the best driver for your device** checkbox selected, click **Next**.



Step 8: Again, select **Specify a location** checkbox and the location should be: **x:\Driver\Win9x** where x is your CD-ROM drive. Otherwise, repeat step 3 to specify the location. Click **Next**.



Step 9: When Windows finds the driver file, click **Next**.




Step 10: Click **Finish** to complete the installation.




When you are done with driver installation, you will need to specify the country where you locate upon different telecommunication regulations/ laws. Please proceed to “**3.6 Country Selection for Windows 95/98/Me/NT/2000**” on page 20 for instructions.

3.3 Driver Installation for Windows Me


- Step 1: Start Windows Me. The **Add New Hardware Wizard** appears. Insert the Installation CD into your CD-ROM drive. Select **Specify the location of the driver (Advanced)** and then click **Next**.



- Step 2: With **Search for the best driver for your device** selected, uncheck the **Removable Media** checkbox and then check only the **Specify a location** checkbox. Click **Browse** to locate the path of the driver: **x:\Driver\WinME** (where x is your CD-ROM drive) and click **OK**. Click **Next**.



- Step 3: Windows will find the driver for the device. Click **Next** to continue.



Step 4: When installation is complete, click **Finish**.



Step 5: Windows will continue to detect another device. Select **Specify the location of the driver (Advanced)** and then click **Next**.




Step 6: Again, select **Search for the best driver for your device** and check only the **Specify a location** checkbox. The location should be: **x:\Driver\WinME** where x is your CD-ROM drive. Otherwise, repeat step 2 to specify the location. Click **Next**.



Step 7: Windows will find the driver for the device. Click **Next** to continue.




Step 8: When installation is complete, click **Finish**.



When you are done with driver installation, you will need to specify the country where you locate upon different telecommunication regulations/ laws. Please proceed to “**3.6 Country Selection for Windows 95/98/Me/NT/2000**” on page 20 for instructions.

3.4 Driver Installation for Windows NT 4.0


Step 1: Start Windows NT4.0. Click **Start**, point to **Settings** and then click on **Control Panel**. Double-click the **Modems** icon.



Step 2: In **Install New Modem** box, with **Don't detect my modem, I will select it from a list** checkbox selected, click **Next**. Insert the Installation CD into your CD-ROM drive.




Step 3: Click **Have disk**.




Step 4: Click **Browse** to locate the path of the driver: **x:\Driver\NT40** (where x is your CD-ROM drive) and click **OK**.




Step 5: Select the **Topic 56K External Data Fax Voice Modem** from the list and then click **Next**.




Step 6: Highlight the communication port connected to your modem and then click **Next**.



Step 7: Click **Finish** to complete installation.



Step 8: When **Modem Properties** window appears, click **Close**.




When you are done with driver installation, you will need to specify the country where you locate upon different telecommunication regulations/ laws. Please proceed to “**3.6 Country Selection for Windows 95/98/Me/NT/2000**” on page 20 for instructions.

3.5 Driver Installation for Windows 2000


Step 1: Start Windows 2000. Windows will detect a new hardware device, click **Next** to continue.




Step 2: Select **Search for a suitable driver...** and click **Next**.




Step 3: Insert the Installation CD into your CD-ROM drive. Check **ONLY Specify a location** and click **Next**.




- Step 4: Click **Browse** to locate the path of the driver: **x:\Driver\W2K** (where x is your CD-ROM drive) and click **OK**.




- Step 5: When Windows finds the location of the driver, click **Next**.



- Step 6: When **Digital Signature Not Found** window appears, click **Yes** to continue.



- Step 7: Click **Finish**. When **Found New Hardware** screen appears, wait for completing the installation.



When you are done with driver installation, you will need to specify the country where you locate upon different telecommunication regulations/ laws. Please proceed to “**3.6 Country Selection for Windows 95/98/Me/NT/2000**” on page 20 for instructions.


3.6 Country Selection for Windows 95/98/Me/NT/2000


Before starting the modem, you may need to specify the country where you locate upon different telecommunication regulations/ laws.

- Step 1: Click **Start**, point to **Settings** and then click on **Control Panel**. Double-click the **Modem Regional Settings** icon.




- Step 2: The utility will start detecting automatically. You may click on the drop down arrow to reset your country and then click **OK**.





Step 3: Wait for resetting. When resetting is finished, the following window will appear. Click **OK** to finish your country selection.




3.7 Verify that Your Modem is Properly Installed

3.7.1 For Windows 95/98/Me


- Step 1: Click **Start**, point to **Settings** and then click on **Control Panel**. Double-click the **Modems** icon.




Note: If **Location Information** is not provided yet, you will see the screen below. Enter your location information and then click **Close**. If you are using Windows 95, you will not see this window. Just proceed to next step.




- Step 2: Highlight the **Topic 56k External Data Fax Voice Modem Pnp** and then click on **Diagnostics** tab.




Step 3: Click on **More Info...**



Step 4: Wait for communication with your modem.



Step 5: If your modem is properly installed, the command response should appear in the box as the following. Click **OK** to exit the **More Info...** window. When returning to **Modems Properties** window, click **OK** to return to Windows.
Congratulations! You have successfully installed the modem hardware and its driver.




NOTE: If your modem fails to respond, you will see an error message. Make sure your modem is properly installed and turned on. If your modem still fails to respond, you may need to remove the driver and reinstall again.

3.7.2 For Windows 2000


Step 1: Click **Start**, point to **Settings** and then click on **Control Panel**. Double-click the **Phone and Modem Options** icon.




Note: If **Location Information** is not provided yet, you will see the screen below. Enter your location information and then click **OK**.




Step 2: In **Phone And Modem Options** window, click on **Modems** tab. Highlight the **Topic 56k External Data Fax Voice Modem Pnp** and then click on **Properties**.




Step 3: Click on **Diagnostics** tab and then click on **Query Modem**



Step 4: Wait for communication with your modem.



Step 5: If your modem is properly installed, the command response should appear in the box as the following. Click **OK** to exit the window. When returning to **Phone And Modem Options** window, click **OK** to return to Windows.
Congratulations! You have successfully installed the modem hardware and its driver.



3.8 Software Installation for Linux Red Hat 6.0


- Step 1: After hardware installation, power on your modem and start Linux RedHat.
- Step 2: Click **System Menu** button and select **System**.
- Step 3: Click **Control Panel**, and then click **Modem Configuration** button.
- Step 4: At the path /dev, enter the single command line:
`setserial tty-number uart 16550A irq IRQ-number port I/O-address`
 For example: **setserial ttyS2 uart 16550A irq 5 port 0xe400**
- Step 5: At the path /dev, remove the default modem link, and then link the modem to the tty you assign in last step.
 For example: **rm modem**
ln -s ttyS2 modem
- Step 6: Select one from ttyS0 to ttyS3 depending on what COM port you plug in.
 ttyS0 – COM1
 ttyS1 – COM2
 ttyS2 – COM3
 ttyS3 – COM4
- Step 7: Before starting the modem, you may need to specify the country where you locate upon different telecommunication regulations/ laws.
 Copy the two files: **tp560i** and **tp 560il** from the Installation CD into the path /bin.
 When prompted to select serial port, select the number you assign in Step 4.
 When prompted with the country table, select the country you locate.

CHAPTER 4


DRIVER UNINSTALLATION

4.1 Uninstallation from Windows 95/98/Me


Step 1: On the desktop, click on **My Computer** and right-click on **Properties**.




Step 2: Click on **Device Manager** tab and then double-click the **Modem** icon. Highlight **Topic 56k External Data Fax Voice Modem Pnp** and then click on **Remove**.



Step 3: When confirm message appears, click **OK**.




- Step 4: You will return to **System Properties** window and find that your modem is removed from the hardware list. Click on **Close** to return to Windows.




4.2 Uninstallation from Windows NT 4.0


- Step 1: Click **Start**, point to **Settings** and then click on **Control Panel**. Double-click the **Modems** icon.




- Step 2: Highlight **Topic 56k External Data Fax Voice Modem** and then click **Remove**.



Step 3: When prompted, click **Yes**.



Step 4: You will return to **Modems Properties** window and find the modem device is removed. Click **Close** to exit this window.



4.3 Uninstallation from Windows 2000


Step 1: Click **Start**, point to **Settings** and then click on **Control Panel**. Double-click the **Add/Remove Hardware** icon.




Step 2: Click **Next**.




Step 3: Select the **Uninstall/Unplug a device** option and then click **Next**.




Step 4: Select **Uninstall a device** and then click **Next**.




Step 5: Highlight **Topic 56k External Data Fax Voice Modem Pnp** from your device list and then click **Next**.



Step 6: Select **Yes, I want to...** and then click **Next**.



Step 7: Click **Finish** to complete uninstallation.



CHAPTER 5

COMMAND REFERENCE

This chapter includes all commands, S-Registers supported by the modem. Before using the commands, make sure your communications software package provides the function of operating the modem through its internal commands. If your software does not support the function, ignore Chapter 4 and 5.

More than one command can be placed on a single line and, if desired, separated with spaces for readability. Once the carriage return (**Enter**) key is pressed, the command line will be executed. A line with no carriage return is ignored. If you come across terms that you don't understand, consult the glossary. Words in **boldface type** are command names, commands, or default settings. Carriage returns (Enter) are noted with <CR> or [ENTER]; this does not mean to enter these characters literally; but instead to press the **Enter** key.

The modem accepts either upper or lower case characters in the command line and ignores any space within or between commands. Typing errors can be corrected with the **Backspace** key. Exceptions are noted in the description of specific commands.

Variables (r and x) are listed in italics. Punctuation symbols (, ; ! @) use as dial modifiers are listed alphabetically according to their English names at the beginning of Section 4.2 Where two commands are separated by a slash, either command will have the same effect. For example, if the command is listed as **B0/B**, issuing either **B0** or **B** will have the same effect.

Note: Except for the **A/** command and the **+++** escape command described in Section 4.3, all commands must be prefixed with the attention code **AT**. For instance, the **A** command (below) would be entered as: "**AT A <CR>**". Without the **AT** prefix, the command line cannot be executed. Once entered, AT cannot be deleted with the **Backspace** or **Delete** keys.

5.1 AT Commands

5.1.1 Basic Command Set

A **Go On-line in Answer Mode**

This command instructs the modem to go off-hook immediately and then make a handshake with the remote modem. Handshaking is not available during leased line operation.

A is usually used to manually answer an incoming call or to switch from voice conversation to data communication.

Bn **Select Protocol to ITU-V.22 or Bell 212A**

- | | |
|-------------|---|
| B0/B | Selects ITU-V.22 protocol once the command line prefix AT has been entered at the 1200 bps data rate. |
| B1 | Selects BELL 212A protocol once the command line prefix AT has been entered at the 1200 bps data rate. (Default) |

D **Go On-line in Originate Mode**

D instructs the modem to go off-hook immediately and automatically dial the number contained in the dial string following **D**. The dial string may contain any of the dial modifiers contained in the following section. The **D** command without a dial string is usually used to switch from voice conversation to data communication or to call a remote modem in leased-line operation mode.

En Command Echo

E0/E	Disables command echo.
E1	Enables command echo. (Default)

Hn Hang Up

H0/H	Goes on-hook. (hangs up)
H1	Goes off-hook. (ready to dial)

In Identification

I0/I	Report the product code.
I1	Report the hardware checksum.
I2	Report " NVRAM Test Result ".
I3	Report "TP56 0 Data/Fax/Voice 56K Modem).
I4	Report Firmware Version.
I5	Report the country code parameter.
I6	Report Local Phone Status.

Ln Control Speaker Volume

L0/L	Low volume.
L1	Low volume.
L2	Medium volume. (Default)
L3	High volume.

Mn Monitor Speaker On/Off

M0/M	Speaker is always off.
M1	Speaker is off while receiving carrier. (Default)
M2	Speaker is always on.
M3	Speaker disabled while dialing.

Nn Automode Enable

N0/N	Automode detection is disabled.
N1	Automode detection is enabled.(Default)

On Return to On-Line Data Mode

O0/O	Enters on-line data mode without a retrain. Handling is determined by the Call Establishment task. Generally, if a connection exists, this command connects the DTE back to the remote modem after an escape (+++).(Default)
O1	Enters on-line data mode with a retrain before returning to on-line data mode.
O2	Enters on-line data mode with a rate re-negotiation before returning to on-line data mode.

P Set Pulse Dial as Default

Causes the modem to assume that all subsequent dial commands are pulse dials. You may omit the "P" from the dial strings.

Q Result Code Display

Determines whether the modem sends the result codes to the DTE.

Q0/Q Enables result codes to the DTE (Default).

Q1 Disables result codes to the DTE.

T Set Tone Dial as Default

Causes the modem to assume that all subsequent dial commands are tone dial.

Vn Select Word or Digit Result Codes

V0/V Displays result codes in digital format.

V1 Displays result codes in verbose format. (Default)

W Connect Message Control

This command controls the format of CONNECT messages.

W0/W Upon connection, the modem reports only the DCE speed (e.g., CONNECT 19200). Subsequent responses are disabled.

W1 Upon connection, the modem reports the line speed, the error correction protocol, and the DTE speed, respectively. Subsequent responses are disabled.

W2 Upon connection, the modem reports the DCE speed (e.g., CONNECT 14400). Subsequent responses are enabled.(Default)

W3 Upon connection, the modem reports the line speed, the error correction protocol, and the DTE speed, respectively. Subsequent responses are enable.

Xn Extended Result Codes

This command selects which subset of the result messages will be used by the modem to inform the DTE of the results of commands.

Blind dialing is enabled or disabled by country parameters. If the user wishes to enforce dial tone detection, a "W" can be placed in the dial string(see **D** command). Note that the information below is based upon the default implementation of the **X** results table.

If the modem is in facsimile mode (**+FCLASS=1**) , the only message sent to indicate a connection is CONNECT without a speed indication.

X0/X CONNECT result code is given upon entering online data state. Dial tone and busy detection are disable.

X1 CONNECT<text> result code is given upon entering online data state. Dial tone and busy detection are disable.

X2 CONNECT<text> result code is given upon entering online data state. Dial tone detection is enabled, and busy detection is disable.

X3	CONNECT<text> result code is given upon entering online data state. Dial tone detection is disabled, and busy detection is enable.
X4	CONNECT<text> result code is given upon entering online data state. Dial tone and busy detection are enable.(Default)

Z Reset

Zn, which must be placed at the end of the command line, resets the active configuration of the modem to the stored configuration saved in nonvolatile RAM, hangs up the modem, and clears the command buffer.

Z0/Z	Resets the modem and loads stored configuration 0.
Z1	Resets the modem and loads stored configuration 1.

5.1.2 Commands Preceded by &**&Cn Select DCD Options**

&C0/&C Maintains an ON status for the Data Carrier Detect (DCD).

&C1 Uses the actual state of the carrier from the remote modem for DCD. (Default)

&Dn Select DTR Options

Determines actions taken by the modem in relation to the Data Terminal Ready (DTR) signal of the serial port.

&D0/&D	DTR is ignored. Allows operation with DTEs that do not provide DTR.
&D1	DTR drop is interpreted by the modem as if the escape sequence has been entered. The modem returns to the command state without disconnecting.
&D2	DTR drop causes the modem to hang up. Auto answer is inhibited. (Default)
&D3	DTR drop causes the modem to perform a soft reset as if the Z command were received.

&F Fetch Factory Configuration

&F Load Factory Setting.

&Gn Select Guard Tone

&G0/&G	Disable guard tone. (Default)
&G1	Select 550Hz -guard tone.
&G2	Select 1800Hz-guard tone.

&Kn DTE/Modem Flow Control

Determines how the modem controls the flow of data between the local DTE and the modem. When the modem terminal buffer is nearly full, the modem will either send an XOFF or drop CTS to stop the data flow. When the buffer is nearly empty, the modem will either send an XON or raise CTS to start the data flow.

&K0/&K	Disable DTE/DCE flow control.
&K3	Enable RTS/CTS DTE/DCE flow control. (Default)
&K4	Enables XON/XOFF DTE/DCE flow control.
&K5	Enable RTS/CTS and transparent XON/XOFF DTE/DCE flow control.

&Pn Select Pulse Dial Make/Break Ratio

&P0/&P Sets a 39/61 make/break ratio @ 10 pps. (Default)

&P1	Sets a 33/67 make/break ratio @ 10 pps.
&P2	Sets a 39/61 make/break ratio @ 20 pps.
&P3	Sets a 33/67 make/break ratio @ 20 pps.

&Rn CTR Signal Select

Determines whether CTR operates in accordance with the EIA-232-D specification or remains ON

&R1/&R	CTR will become active when RTS is On.
&R0	CTS is always ON. (Default)

&Sn DSR Option

Determines whether DSR operates in accordance with the EIA-232-D specification or remains ON

&S0/&S	DSR is always ON. (Default)
&S1	DSR will become active after answer tone has been detected and inactive after the carrier has been lost.

&Un Protocol Selection

&U0/&U	V.90 mode.(Default)
&U1	V.34 mode.
&U2	V.32bis/V.32/V.22bis mode.
&U3	Bell 103 300bps mode.
&U4	V.21 300bps mode.
&U5	V.23 mode.

&V View Configuration Profiles

&V	Displays the active configuration profile.
---------------	--

&W Store the Current Configuration to Nonvolatile RAM

&W0/&W	Writes the current active configuration to profile 0 in nonvolatile RAM. (Default)
&W1	Writes the current active configuration to profile 1 in nonvolatile RAM.

&Yn Select the Default Profile

&Y0/&Y	Uses profile 0 on power-up. (Default)
&Y1	Uses profile 1 on power-up.

&Zn Store Telephone Numbers (n=0to2)

&Zn Store one of four dial strings (including a telephone number) of up to 31 digits in nonvolatile RAM.

For example: to store the telephone number 002852117 to RAM location 1, issue the following command:

Command:**AT&Z1=002852117<CR>**

***In Connect Speed Selection**

***10** Selects connect speed 1200bps

- ***I1** Selects connect speed 2400bps
- ***I2** Selects connect speed 4800bps
- ***I3** selects connect speed 7200bps
- ***I4** Selects connect speed 9600bps
- ***I5** Selects connect speed 12000bps
- ***I6** Selects connect speed 14400bps
- ***I7** Selects connect speed 16800bps
- ***I8** Selects connect speed 19200bps
- ***I9** Selects connect speed 21600bps
- ***I10** Selects connect speed 24000bps
- ***I11** Selects connect speed 26400bps
- ***I12** Selects connect speed 28800bps
- ***I13** Selects connect speed 31200bps
- ***I14** Selects connect speed 33600bps (Dafault)

select V.90

- ***I1** Selects connect speed 28000bps
- ***I2** Selects connect speed 29333bps
- ***I3** selects connect speed 30666bps
- ***I4** Selects connect speed 32000bps
- ***I5** Selects connect speed 33333bps
- ***I6** Selects connect speed 34666bps
- ***I7** Selects connect speed 36000bps
- ***I8** Selects connect speed 37333bps
- ***I9** Selects connect speed 38666bps
- ***I10** Selects connect speed 40000bps
- ***I11** Selects connect speed 41333bps
- ***I12** Selects connect speed 42666bps
- ***I13** Selects connect speed 44000bps
- ***I14** Selects connect speed 45333bps
- ***I15** Selects connect speed 46666bps
- ***I16** Selects connect speed 48000bps
- ***I17** Selects connect speed 49333bps
- ***I18** Selects connect speed 50666bps
- ***I19** Selects connect speed 52000bps
- ***I20** Selects connect speed 53333bps
- ***I21** Selects connect speed 54666bps
- ***I22** Selects connect speed 56000bps (Dafault)

***Gn User Abort Selection**

***G0/*G** Enables key abort feature.(Default)

***G1** Disables key abort feature.

***Hn Auto Retrain Selection**

***H0/*H** Disables auto retrain

***H1** Enables auto retrain.(Dafault)

5.1.3 Commands Preceded by \

\Nn Operation Mode Control

Selects the operating mode to be used during connection

\N0	Selects Normal (speed buffering) Mode.
\N1	Selects Direct (pass-through) Mode.
\N2	Selects MNP or disconnect mode.
\N3	Selects MNP or Buffer.
\N4	Select V.42 without ODP&ADP phase detection, MNP or buffer.
\N5	Select V.42 with ODP&ADP phase detection, MNP or buffer.(Default)
\N6	Select V.42 without ODP&ADP or disconnect.
\N7	Select V.42 with ODP&ADP or disconnect.

\Vn Single Line Connect Message Enable

The single line connect message format can be enabled or disabled by the \Vn command as follows:

\V0	Disable protocol result code appended to DCE speed. (Default)
\V1	Enable protocol result code appended to DCE speed.

5.1.4 Commands Preceded by %

%C Enable/Disable Data Compression

Enables or disables data compression negotiation. The modem can only perform data compression on an error-corrected link.

%C0	Disables data compression.
%C1	Enables V.42bis/MNP 5.(Default)

5.2 Dial Modifiers

This section describes all of the dial modifiers that are used in dial strings.

@ Answer

"@", placed after a phone number, this modifier tells the modem to wait for 5 seconds of silence before dialing the next number in the dial string. @ is usually used to access a secure computer system that provides a silent answer as permission for further entrance.

, Pause

",", placed anywhere in the dial string, tells the modem to pause for the number of seconds specified by S-register S8 before processing the rest of the dial string.

! Initiate a Hookflash

"I", placed anywhere in the dial string, tells the modem to initiate a hookflash, which means to hang up for 0.5 seconds and then go off-hook again before processing the rest of the dial string. This modifier allows access to PBX features like call transferring .

; **Return to Command State after Dialing**

";", which must be placed at the end of the dial string, returns to the command state after dialing the number placed ahead of it. A long telephone number would overflow the 40 character command buffer if placed all in one command line, so it must be broken into two or more command lines. Each part includes part of the number, and all but the last command line end with the ";" followed by a carriage return.

^ **Tone Control**

Toggles calling tone enable/disable: applicable to current dial attempt only.

P **Pulse Dialing**

P, placed ahead of a number, tells the modem to dial a number using pulse dialing.

S **Dial a Stored Number**

S is used to dial one of four numbers stored in nonvolatile memory. For example, instead of entering a dial string, you can use this command:

Command: **ATDTS=1<CR>**

T **Touchtone Dialing**

T, placed ahead of a number, tells the modem to dial a number using touchtone dialing.

W **Wait for Dialtone**

W, placed after a number, tells the modem to wait up to 30 seconds to detect a one-second continuous dialtone before dialing the next number. W is most often used in a PBX system to wait for the dialtone of an outside telephone line.

5.3 Commands Not Preceded By AT

Two commands, A/ and ++, are neither preceded by the attention code **AT** nor followed by a carriage return.

A/ **Repeat Command**

A/ repeats the execution of the last command line stored in the command buffer. If the last command line is invalid, the ERROR result code will appear on the screen. Note that A/ cannot be preceded by AT; if it is, ERROR will appear on the screen.

++ **Escape**

++ followed by AT <CR> allows the modem to escape from the data mode to the on-line command state (command state without breaking the established connection.)

To escape, stop transmitting data, wait at least one escape guard time (the default time is one second), and then enter three consecutive escape characters (the default character is +) followed by AT <CR>.

The modem will return to the command state and send the **OK** result code to the screen. Note that the escape command is the only command that can be recognized by the modem in the one-line state; it cannot be recognized in the command state.

5.4 S Register Reference

Your modem has status registers. These registers are memory locations inside your modem which control your modem's operation. You usually do not have to worry about setting any register because the default values work for most applications.

The S registers are summarized in 4.4.1, along with their default values. Registers denoted with an "*" may be stored in one of the two user profiles by entering the **&Wn** command. One of these profiles may be loaded at any time by using the **Zn** command.

The factory default values are stored in ROM and are loaded into the active configuration at power-up or by the **Zn** command. In addition, the designated default profile is subsequently loaded, and may change some of the factory default values. The designated default profile can be changed by entering the **&Yn** command, where 'n' is one of the two possible user profiles. The factory defaults can be loaded at any time by entering the **&F** command.

5.4.1 Register Summary

Important: The contents of the following registers are for reference.

The following chart summarizes your modem's registers:

Reg.#	Range	Unit	Default Dec	Hex	Description
S0	0 - 255	rings	0	00h	Number of rings before auto-answer.
S1	0 - 55	rings	0	00h	Ring count.
S2	0 - 255	ASCII	43	2Bh	Escape character code.
S3	0 - 127	ASCII	13	0Dh	Command terminator (<CR>character).
S4	0 - 127	ASCII	10	0Ah	Line feed character.
S5	0 - 127	ASCII	8	08h	Backspace character.
S6	3 - 7	seconds	06h		Wait time for blind dialing.
S7	1 - 255	seconds	60h		Wait time for carrier after dial.
S8	1 - 255	seconds	02h		Pause time for comma (dial delay).
S9	1 - 255	1/10 sec.	6*	06h	Carrier detect response time.
S10	1 - 255	1/10 sec.	14*	0Eh	Lost carrier to hang-up delay.
S11	50 - 255	1/1000 sec.	95	5Fh	DTMF Tone Duration.
S12	0 - 255	1/50 sec.	50*	32h	Escape code timing.
S14	[Bit Mapped Options]				
S21	[Bit Mapped Options]				
S22	[Bit Mapped Options]				
S23	[Bit Mapped Options]				
S25	0 - 255	seconds	5*	05h	Delay to DTR.
S26	0 - 255	1/100 sec	1*	01h	RTS to CTS Delay Interval.
S29	[Bit Mapped Options]				
S30	0 - 255	10 s	0*	00h	Inactivity Disconnect Timer.
S95	[Bit Mapped Options]				
S96	[Bit Mapped Options]				
S97	[Bit Mapped Options]				
S98	[Bit Mapped Options]				
S99	0 - 255		2	16	Energy detection threshold.

5.4.2 Glossary of the S Registers

S0 Number of Rings Before Auto Answer

S0 determines the number of rings that must be received before the modem automatically answers an incoming call. For example, when **S0=3**, the modem automatically answers after the third ring. When

S0=0, the modem does not automatically answer an incoming call; it stays on-hook until the **A** command is issued manually to answer the incoming call.

Range: 0 - 255 rings

S1 Ring Counter

S1 automatically increments its value by one each time the modem receives a ring while in the command state. **S1** is reset to zero if no ring is detected within **8** seconds.

Range: 0 - 255 rings

S2 Escape Character

S2 holds the decimal value of the ASCII character used as the escape character. The default value corresponds to an ASCII '+'. A value over 127 disables the escape process, i.e., no escape character will be recognized.

Range: 0 - 255, ASCII decimal.

S3 Line Termination Character

S3 sets the decimal value of the command line and result code terminator character. Pertains to asynchronous operation only.

Range: 0 - 127, ASCII decimal.

S4 Response Formatting Character

S4 sets the decimal value of the character generated by the modem as part of the header, trailer, and terminator for result codes and information text, along with the **S3** parameter. If the value of **S4** is changed in a command line, the result codes issued in response to that command line will use the new value of **S4**. The Response Formatting character is output after the Line Termination character if verbose result codes are used.

Range: 0 - 127, ASCII decimal.

S5 ASCII Value of Backspace Character

S5 stores the ASCII value of the backspace character. The backspace is used to edit a command line. If your computer does not recognize the default as a backspace, change the value.

Range: 0 - 127, ASCII decimal.

S6 Wait Time before Blind Dialing

S6 controls how long the modem waits after it goes off-hook before it dials the first digit of the telephone number. The modem always pauses for at least 3 seconds, even if **S6** is set to less than 3 seconds.

Range: 3 - 7 seconds.

S7 Wait for Carrier after Dial

S7 controls how long the modem waits for a carrier signal from a remote modem after originating a call or from the calling modem after going off-hook when answering a call.

S7 also controls how long the modem waits for a one-second continuous dialtone after dialing a number followed by the **W** dial modifier. If the modem detects a one-second continuous dialtone within the specified wait time, it proceeds to dial.

Range: 1 - 255 seconds.

S8 Pause Time for Comma

S8 controls how long the modem pauses when a comma ", " is encountered in a dial string while executing a dial command.

Range: 1 - 255 seconds.

S9 Carrier Detect Response Time

S9 determines how long a carrier signal must be present for the modem to confirm it. The longer the response time, the easier it is for the modem to correctly recognize a carrier without mistaking other signals or transient noise on the line as a carrier.

Range: 1 - 255 tenths of a second.

S10 Lost Carrier To Hang Up Delay

S10 sets the length of time, in tenths of a second, that the modem waits before hanging up after a loss of carrier. This allows for a temporary loss of carrier without causing the local modem to disconnect. When **S10** is set to 255, the modem functions as if a carrier is always present.

The actual interval the modem waits before disconnecting is the value in **S10** minus the value in **S9**. Therefore, the value in **S10** must be greater than that in **S9**, or else the modem disconnects before it recognizes the carrier.

Range: 1 - 255 tenths of a second.

S11 DTMF (Touch-tone) Tone Duration

S11 sets the duration of tone in DTMF dialing. This value has no effect on pulse dialing.

Range: 50 - 255 milliseconds.

S12 Escape Guard Time

S12 determines the escape guard time. The escape guard time is the minimum waiting time required before and after entering the escape code (three consecutive escape characters) in the on-line state. It is also the maximum waiting time allowed between any two consecutive escape characters. If the waiting time before or after the

escape code is shorter than the guard time, or if the waiting time between consecutive escape characters is longer than the guard time, then the modem does not recognize the escape command and stays on-line.

If the escape guard time is set at 0 second, it is impossible to return the modem to command state.

Range: 0 - 255 fiftieths of a second.

S14 Bit Mapped Options

Bit	Value	Description
bit 0 (E)	0	Disabled.
	1	Enabled.
bit 2 (Q)	0	Disabled.
	1	Enabled.
bit 3 (V)	0	Numeric.
	1	Verbose.
bit 4,5 (&P)	00	39/61 make to break ratio/10pps
	01	33/67 make to break ratio/10pps
	10	39/61 make to break ratio/20pps
	11	33/67 make to break ratio/20pps
bit 6(P or T)	0	T (Tone dial).
	1	P (Pulse dial).
bit 7	0	Answer mode.
	1	Originate mode.

S21 Bit Mapped Options

Bit	Value	Description
bit 0	[RESERVED]	
bit 2	0	&R0.
	1	&R1.
bit 3,4	00	&D0.
	01	&D1.
	10	&D2.
	11	&D3.
bit 5	0	&C0.
	1	&C1.
bit 6	0	&S0.
	1	&S1.

S22 Bit Mapped Options

Bit	Value	Description
bit 0,1	00	Select L0.
	01	Select L1.
	10	Select L2.
	11	Select L3.
bit 2,3	00	Select M0.
	01	Select M1.
	10	Select M2.
	11	Select M3.
bit 4,5,6	000	Select X0.
	001	Select X1.
	010	Select X2.
	011	Select X3.
	100	Select X4.
bit 7	[RESERVED]	

S23 Bit Mapped Options

Bit	Value	Description
Bit 0,1,2,3	0000	Communications rate = 300 bps.
	0001	Communications rate = 600 bps.
	0010	Communications rate = 1200 bps.
	0011	Communications rate = 2400 bps.
	0100	Communications rate = 4800 bps.
	0101	Communications rate = 9600 bps.
	0110	Communications rate = 19200 bps.

bit 4,5	0111	Communications rate = 38400 bps
	1000	Communications rate = 57600 bps
	1001	Communications rate = 115200 bps
	00	Even parity.
bit 6,7	01	None parity.
	10	Odd parity.
	11	Mark parity.
	00	&G0.
	01	&G1.
	10	&G2

S25 Delay to DTR

S25 serves two purposes. When the modem is operating in synchronous mode 1, the value assigned to **S25** specifies the length of time the modem waits after a connection has been made before examining DTR. This allows the modem to ignore an ON-to-OFF transition of DTR, giving the user time to disconnect the modem from the asynchronous terminal and attach it to a synchronous terminal, without forcing the modem back to the asynchronous command mode. During this time, the value for **S25** is read in whole seconds.

Range: 0 - 255 (0.01 second)

S26 RTS to CTS Delay Interval

Pertains to synchronous operation only. When CTS tracks RTS (**&R0**) and the modem detects an ON-to-OFF transition on RTS, this register sets the time delay before the modem turns CTS to ON.

Range: 0 - 255 hundredths of a second

S29 Bit Mapped Options

Bit	Value	Description
bit0-4	(n)	AT*I (n)
bit 5,6,7	000	AT&U0
	001	AT&U1
	010	AT&U2
	011	AT&U3
	100	AT&U4
	101	AT&U5

S30 Inactivity Disconnect Timer

This register determines the length of time, in seconds, the modem waits before disconnecting when no data is sent or received. This function is only applicable to buffer mode.

Range: 0 - 255 tenths of a second

S95 Bit-Mapped Options

Bit	Value	Description
bit 0,1	0 0	W0.
	0 1	W1.
	1 0	W2.
	1 1	W3.
Bit 2	0	W0.
	1	W1.
Bit 3	0	N0.
	1	N1.
Bit 4-7	(n)	*On.

S97 Bit-Mapped Options

Bit	Value	Description
bit 0,1,2	000	N0.
	001	N1.
	010	N2.
	011	N3.
	010	N4.
	011	N5.
	110	N6.
	111	N7.
Bit 7	0	%C0.
	1	%C1.

S98 Bit-Mapped Options

Bit	Value	Description
bit 0,1	0 0	*H0.
	0 1	*H1.
	1 0	*H2.
	1 1	*H3.
Bit 2	0	*G0.
	1	*G1.
Bit 3	0	*T0.
	1	*T1.
Bit 4-6	000	&K0.
	001	&K1.
	010	&K2.
	011	&K3.
	101	&K4.
	110	&K5.

S99 Energy detection threshold

This register can use in Call Progress Mode (CPM) for dial tone detection threshold. The default value is 16 This register determine the detection threshold for call progress tone.

CHAPTER 6

MODEM REFERENCE

6.1 Troubleshooting

This chapter describes common problems in the installation, configuration and regular usage of your Fax/Data Modem. To test the Fax/Data Modem, a communication software package is needed and the package must include a mode that allows you to operate your Fax/Data Modem by directly issuing internal commands to the modem.

Follow the procedures in the following sections to resolve these common problems:

No Response From Your Modem

1. If you are using the internal add-on card modems, make sure that the COM port address you have set your modem to corresponds to the appropriate selection in the communications software which you are using.
2. Issue the **ATZ** command to reset your modem. The returned result code should be "0" or "K" depending on what communications program you are using. Your modem is OK if you get one of these responses. If there is no response after issuing the **ATZ<CR>**, continue to the next step.
3. Check if there are any other interface cards in your computer that use the same COM port address as your modem. If so, you must set your modem to another COM port address.
4. Issue the command: **AT&F&W <CR>**, if a "0" or "K" result code is displayed on the screen, your modem is OK. Otherwise, contact your dealer for assistance.

Your Modem Does Not Connect After It Has Dialed a Phone Number

The problem may have several causes. The phone line may be too noisy or the telephone cord may be poor. Try the line with a regular phone. Also the remote modem may not recognize your modem baud rate.

You Can Transmit After You Have Connected to the Remote Modem

In this case, check the communication parameters of the remote modem, then configure your software to the same number of data bits, stop bit, and parity.

6.2 Result Codes

The modem sends a response to the user via the screen after a command is issued. As shown in the figure below, there are two forms for each result code: Modem Response code and digit code.

<u>Response</u>	<u>Digital</u>					<u>n value in ATXn</u>	<u>Description</u>
	0	1	2	3	4		
OK	0					x x x x x	Command executed without errors
CONNECT	1					x x x x x	Connect to another modem
RING	2					x x x x x	Detect an incoming ring
NO CARRIER	3					x x x x x	Carrier lost or never detected
ERROR	4					x x x x x	Invalid command or invalid character
CONNECT 1200	5					x x x x	Connection established at 1200 bps
NO DIALTONE	6					x x	Dial tone not detected within timeout
BUSY	7					x x	Detected a busy tone after dialing
NO ANSWER	8					x x	No ringback or quiet answer was detected.
CONNECT 300	9					x x x x	Connection established at 300 bps
CONNECT 2400	10					x x x x	Connection established at 2400 bps
CONNECT 4800	11					x x x x	Connection established at 4800 bps
CONNECT 9600	12					x x x x	Connection established at 9600 bps
CONNECT 7200	13					x x x x	Connection established at 7200 bps
CONNECT 12000	14					x x x x	Connection established at 1200 bps
CONNECT 14400	20					x x x x	Connection established at 14400 bps
CONNECT 19200	21					x x x x	Connection established at 19200 bps
CONNECT 38400	22					x x x x	Connection established at 38400 bps
CONNECT 57600	23					x x x x	Connection established at 56700 bps

CONNECT 115200	24	x x x x	Connection established at 115200 bps
CONNECT 1200TX/75RX	25	x x x x	V.23 established:transmit at 75 bps, receive at
1200 bps			
CONNECT 75TX/1200RX	26	x x x x	V.23 established:transmit at 1200 bps, receive
at 75 bps			
CONNECT BELL 300	28	x x x x	Connection established at Bell 300 bps
CONNECT V21	29	x x x x	Connection established at V.21 300 bps

(Display DCE speeds by ATW0 and ATW2)

CONNECT 16800	15	x x x x	Connection established at 16800 bps
CONNECT 19200	16	x x x x	Connection established at 19200 bps
CONNECT 21600	17	x x x x	Connection established at 21600 bps
CONNECT 24000	21	x x x x	Connection established at 24000 bps
CONNECT 26400	30	x x x x	Connection established at 26400 bps
CONNECT 28800	31	x x x x	Connection established at 28800 bps
CONNECT 31200	32	x x x x	Connection established at 31200 bps
CONNECT 33600	33	x x x x	Connection established at 33600 bps

(V.90 mode)

CONNECT 28000	34	x x x x	Connection established at 28000 bps
CONNECT 29333	35	x x x x	Connection established at 29333 bps
CONNECT 30666	36	x x x x	Connection established at 30666 bps
CONNECT 32000	37	x x x x	Connection established at 32000 bps
CONNECT 33333	38	x x x x	Connection established at 33333 bps
CONNECT 34666	39	x x x x	Connection established at 34666 bps
CONNECT 36000	40	x x x x	Connection established at 36000 bps
CONNECT 37333	41	x x x x	Connection established at 37333 bps
CONNECT 38666	42	x x x x	Connection established at 38666 bps
CONNECT 40000	43	x x x x	Connection established at 40000 bps
CONNECT 41333	44	x x x x	Connection established at 41333 bps
CONNECT 42666	45	x x x x	Connection established at 42666 bps
CONNECT 44000	46	x x x x	Connection established at 44000 bps
CONNECT 45333	47	x x x x	Connection established at 45333 bps
CONNECT 46666	48	x x x x	Connection established at 46666 bps
CONNECT 48000	49	x x x x	Connection established at 48000 bps
CONNECT 49333	50	x x x x	Connection established at 49333 bps
CONNECT 50666	51	x x x x	Connection established at 50666 bps
CONNECT 52000	52	x x x x	Connection established at 52000 bps
CONNECT 53333	53	x x x x	Connection established at 53333 bps
CONNECT 54666	54	x x x x	Connection established at 54666 bps
CONNECT 56000	55	x x x x	Connection established at 56000 bps

6.3 Application Examples

6.3.1 Dialing a Remote Modem

Command line: ATDP9WT002, (886)-7128423<CR>

This command line instruct the modem to dial a remote modem through a PBX. The modem first use pulse dialing to dial 9 (the access code of the PBX), wait for outside dial tone, and then use touch tone dialing to dial 002 once a one-second continuous dial tone is detected within 30 seconds, pause for 2 seconds (if S8=2) and then dial 8867128423.

6.3.2 Dialing a Stored Number

Command line: AT&Z2=T03,709394<CR>

Command line: ATDS=2<CR>

The first command line store the dial string T03, 709394 to the 3rd location in NVRAM. Afterwards you can use the second command line to dial this stored number. The dial string T03, 709394 will appear on the screen to indicate the number being dialed.

6.3.3 Manual Answer an Incoming Call

Command line: **ATA <CR>**

The factory setting of the S-register S0 is S0=0. This condition disables the auto answer capability so that you must issue an ATA command to answer a call. At power up, your modem always monitors if there are incoming rings. If incoming rings are detected, your modem will display result codes on the screen as :

RING

:

:

RING

Seeing that, you may issue the ATA command to answer the call. This command must be entered within the quiet interval between any two rings.

6.3.4 Auto Answer an Incoming Call

Command line: **AT S0=2 &W &Y <CR>**

Auto answer can be enabled by changing the setting of the S-register S0 to a value between 1 and 255. In the above command line, S0=2 instructs the modem to answer an incoming call automatically after the 2nd ring. The &W command writes this configuration to profile 0 in NVRAM. &Y command instruct the modem to load profile 0 as the active configuration on power-up. The last two commands make S0=2 the default value at power-up or reset.

This example also shows the insertion of space between two neighboring commands to make the command line more readable.

6.3.5 Voice to Data Switch

Command line: **ATA <CR>** or **ATX1D <CR>**

If you are talking with a remote modem user through the telephone set and want to initiate data communication with the remote modem, follow the procedures below:

1. You or the remote user issue an ATA command first to switch to data communication.
2. When the person on the other end hears an answer tone from the phone, issues an ATX1D command (X1 to disable the dial tone monitor) to instruct the modem to go off-hook and wait for a carrier. If connection is successful, the CONNECT XXXX result code will be displayed on the screen. Now you can hang up your phone and begin data communication with the remote modem.

APPENDICES

Appendix A: Caller ID Commands (Optional)

+VCIDn - Caller ID (Enables or disables Caller ID.)(for U.S.A)

This command only apply to models which support the Caller ID function.

- +VCID=0** Disables Caller ID.(Default.)
- +VCID=1** Enables Caller ID with formatted presentation to the DTE. The modem will present the data items in a <Tag><Value> pair format. The expected pairs are data, time, caller code (telephone number), and name.
- +VCID=2** Enables Caller ID with unformatted presentation to the DTE. The modem will present the entire packet of information, excluding the leading U's, in ASCII printable hex numbers.

Result Codes:

OK n=0, 1 or 2.

ERROR Otherwise.

Inquiries :

+VCID? Retrieves the current Caller ID mode from the modem.

+VCID=? Returns the mode capabilities of the modem in a list with each element separated by commas.

Formatted Form Reporting

The modem presents the data in the <tag>=<value> pair format as described in the table below. Spaces are present on both sides of the equal sign.

TAG	Description
DATE	DATE=MMDD where MM is the month number(01 to 12) and DD is the day number (01..31).
TIME	TIME=HHMM where HH is the hour number (00 to 23) and MM is the minute number (00 to 59).
NMBR	NMBR=<number> or P or O where <number> is the telephone number of the caller, where P indicates that the calling number information is not available since the originating caller as requested private service, and where O indicates that the calling number information is not available or out of service at the calling location.
NAME	NAME=<listing name> where <listing name> is the subscription name.
MESG	MESG=<data tag><length of message><data><checksum> in printable ASCII hex numbers. This tag indicates a data item not listed above. The message is only possible for Multiple Message Format.

Notes:

1. The modem does not present any Caller ID information if the DCE detects a checksum error in the Caller ID packet.
2. In the event of an unrecognized data tag, the modem will present the data in ASCII hex numbers following the MESG tag.

Example of Formatted Form Reporting

1. The following example illustrates the standard Caller ID message packet.
RING
DATE = 0321
TIME = 1405
NMBR = 504551234
NAME = A N OTHER
RING
RING
2. The following example illustrates the case where the tag of the packet is not recognized by the modem.
RING
MESG = 06034242431
RING
RING

Unformatted Form Reporting

The modem presents all information and packet control information found in the message. The modem, however, excludes the leading U's (channel seizure information) from the presentation. The packet is presented in ASCII printable hex numbers, the modem does not insert spaces, or line feeds, for formatting between bytes or words of the packet. The modem does not detect the checksum of the packet.

Example of Unformatted From Reporting

RING
0412303332323234303539313435353132333435
RING
RING

Appendix B: Technical Specifications

Data Rates(bps)

V.90: 56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000 (Receive only)

Compatibility (Data)

ITU-T V.90, V.34, V.32 bis, V.32, V.23, V.22 bis, V.22, and V.21
Bell: 212A and 103

(Fax)

ITU-T V.17, V.29, V.27 ter, and V.21 ch 2

Command Set

Enhanced 'AT' command set, Fax Class 1 command

Flow Control

Xon/Xoff, Hardware RTS/CTS

Data Compression

V.42bis, MNP5

Error Correction

V.42, MNP 2-4

Operation

Maximum 56000 bps/download and 33600 bps/ download with 28800, 26400, 24000, 21600, 19200, 14400, 9600, 4800, 2400 and 1200 bps auto fallback

Audio Monitor

Built-in speaker, with software-controllable volume control

Guard Tone

550/1800 Hz

Compliance

FCC 15&68

Command Buffer

30 characters

Extra Memory

4 x 36 digits

Transmit Level

-11(+/-)dBm

Receive Sensitivity

-40dBm

Pulse Dialing Specifications

	USA	International
Make/Break Ratio	39/61	33/67
Break Length	61ms	67ms
Dial Pulse Length	100ms	100ms
Dial Pulse Rate	10pps	10pps
Interdigit Time	800ms	800ms

Appendix C: Quick Reference

A	Go On-line in Answer Mode
Bn	Select Protocol to 300 bps or 1200 bps
D	Go On-line in Originate Mode
En	Command Echo
Hn	Hang Up
In	Identification
Ln	Control Speaker Volume
Mn	Monitor Speaker On/Off
Nn	Automode Enable
On	Return to On-line Data Mode
P	Set Pulse Dial as Default
Q	Result Code Display
Sn	Reading and Writing to S Registers
T	Set Tone Dial as Default
Vn	Select Word or Digit Result Codes
Wn	Negotiation Progress Reporting
Xn	Extended Result Codes
Zn	Reset
&Cn	Select DCD Options
&Dn	DTR Option
&F	Fetch Factory Configuration
&Gn	Set Guard Tone
&Kn	DTE/Modem Flow Control
&Mn	Communication Mode
&Pn	Select Pulse Dialing Make/Break Ratio
&Rn	CTS Option
&Sn	DSR Option
&V	View Configuration Profiles
&Wn	Store the Current Configuration to Nonvolatile RAM
&Yn	Select the Default Profile
&Zn	Store Telephone Numbers (n=0 to 2)
*In	Connect Speed Selection
*Gn	User Abort Selection
*Hn	Auto Retain Selection
Wn	Operating Mode Control
Vn	Single Line Connect Message Enable
%Cn	Enable/Disable Data Compression
@	Answer
,	Pause
!	Initiate a Hookflash
;	Return to Command State after Dialing
^	Tone Control
J	Perform MNP
P	Pulse Dialing
S	Dial a Stored Number
T	Touchtone Dialing
W	Wait for Dialtone
A/	Repeat Command
+++	Escape

Appendix D: Glossary

ASCII	An acronym for American Standard Code for Information Exchange. ASCII is a seven-bit code which defines 128 standard characters, including control characters, letters, numbers, and symbols. An extra 128 characters comprise the extended ASCII set.
Baud Rate	The transmission rate between two serial devices, e.g., modems, fax machines, etc. Measured in Bits Per Second.
Blind Dialing	In blind dialing, the modem continues to dial, regardless of the existence of a dialtone, ring, or busy signal.
BPS	Bits Per Second; the number of bits that can be transmitted in one second.
Carrier Signal	The analog data signal that a modem sends over telephone wires.
COMx	Where (x = 1, 2, 3, or 4), COMx is the name(address) of serial communications ports on personal computers. Each serial port in a personal computer has a different number.
CTS	Clear To Send.
Default	The assumed value that is used for a command parameter when no other value is explicitly provided.
DCD	Data Carrier Detect.
DCE	Data Communication Equipment.
DTE	Data Terminal Equipment.
DTMF	Dual Tone Multi-Frequency (for touchtone dialing).
DTR	Data Terminal Ready.
FSK	Frequency Shift Keying.
Make/Break Ratio	The ratio of the off-hook (make) to on-hook (break) interval is the make/break ratio in pulse dialing.
Modem	A combination of the words MODulator and DEM odulator. Modems transform digital data into analog signals and back again.
Nonvolatile Memory	An area of memory inside the modem where the default configuration profile is stored. Values recorded in this memory will not be lost when the power is turned off.
Off-Hook	The condition when the modem has picked up the telephone line.
Off-Line Command State	A modem state in which the modem accepts, interprets and executes commands from an asynchronous computer or terminal.
On-Hook	The condition when the modem has not picked up the telephone line; the telephone is hung up.
On-Line	A carrier signal link with a remote modem has been established; communication is in progress.
On-Line State	A modem state in which the modem is connected with a remote modem. Data can be sent or received from the remote modem in this state. No commands will be accepted from the modem except the escape command which will bring the modem into the on-line command state.
On-Line Command State	A modem state in which the modem can accept or execute commands from an asynchronous computer or terminal while remaining connected with the remote modem. The user can return the modem to the on-line state by issuing the ATOn command or put it into the off-line command state by issuing command such as ATZ or ATH .
Parity	An error-checking method by which the modem verifies that the data just sent is correct.

Pps	Pulse per second.
Profile	A list of default settings.
Protocol	A technical specification for serial communications; the protocols supported by the modem are listed in Appendix B.
PSK	Phase Shift Keying.
Pulse Dialing	A dialing form in which each digit is represented by a series of pulses. Rotary telephones all use pulse dialing.
QAM	Quadrature Amplitude Modulation.
Result Codes	The response the modem returns to the screen upon executing a command.
RAM	Random Access Memory.
ROM	Read-Only Memory. A chip inside the modem which stores the factory default settings. This memory cannot be changed.
RTS	Request To Send.
RX	Reception.
S Register	RAM locations in the modem which store the active configuration.
Serial Port	See COMx.
TCM	Trellis -Coded Modulation.
Touchtone Dialing	A dialing format in which each digit is represented by a musical frequency.
TX	Transmission.

Appendix E: ASCII CODE TABLE

Decimal	Hex Value	Decimal	Hex Value	Decimal	Hex Value	Decimal	Hex Value
000	00	NUL	032	20	(space)	064	40 @
001	01	SOH	033	21	!	065	41 A
002	02	STX	034	22	"	066	42 B
003	03	ETX	035	23	#	067	43 C
004	04	EOT	036	24	\$	068	44 D
005	05	ENQ	037	25	%	069	45 E
006	06	ACK	038	26	&	070	46 F
007	07	BEL	039	27	'	071	47 G
008	08	BS	040	28	(072	48 H
009	09	HT	041	29)	073	49 I
010	0A	LF	042	2A	*	074	4A J
011	0B	VT	043	2B	+	075	4B K
012	0C	FF	044	2C	,	076	4C L
013	0D	CR	045	2D	-	077	4D M
014	0E	SO	046	2E	.	078	4E N
015	0F	SI	047	2F	/	079	4F O
016	10	DLE	048	30	0	080	50 P
017	11	DC1	049	31	1	081	51 Q
018	12	DC2	050	32	2	082	52 R
019	13	DC3	051	33	3	083	53 S
020	14	DC4	052	34	4	084	54 T
021	15	NAK	053	35	5	085	55 U
022	16	SYN	054	36	6	086	56 V
023	17	ETB	055	37	7	087	57 W
024	18	CAN	056	38	8	088	58 X
025	19	EM	057	39	9	089	59 Y
026	1A	SUB	058	3A	:	090	5A Z
027	1B	ESC	059	3B	;	091	5B [
028	1C	FS	060	3C	<	092	5C \
029	1D	GS	061	3D	=	093	5D]
030	1E	RS	062	3E	>	094	5E ^
031	1F	US	063	3F	?	095	5F _
						127	7F DEL

Appendix F: FCC/DOC REQUIREMENTS

F.1 FCC General Information

The Federal Communications Commission (FCC) of the United States restricts specific uses of modems, and places registration responsibilities on both the manufacturer and the individual user:

1. The modem may not be connected to a party line or to a coin operated telephone.
2. The modem manufacturer must make any repairs to the modem to maintain valid FCC registration.
3. Notification to the telephone company is no longer required prior to connecting registered equipment, but upon request from the telephone company, the user shall tell the telephone company which line the equipment is connected to as well as the registration number and ringer equivalence number of the registered protective circuitry. FCC information is printed on a label on the bottom of the modem.

F.2 FCC Notice

This equipment has been tested and found to comply with the limits for a digital device, pursuant to Subpart B of Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and uses radio frequency energy and if not installed with the instructions, may cause interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interconnect cables and a shielded power cord must be employed with this equipment to insure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

Note : The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

F.3 DOC Notice

Notice: The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

The Load Number (LN) assigned to each terminal device denotes the percentage or the total load to be connected to a telephone loop which is used by the device, to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all the devices does not exceed 100.

Note: Locate an analog telephone line. Many offices have digital telephone lines, which will not work with a modem.

Warning: Do not connect your modem to a digital telephone line. Modems are designed for use only with analog telephone lines; connecting to a digital telephone line may damage the modem. Verify that the line is analog before connecting.

Fax machines use analog telephone lines. If you can't find an analog voice line, find a fax machine and use its line.