

Quick Start **Guide**

NWL-11 - M2M CDMA Router



Quick Start Guide

This quick start guide is designed to get you up and running quickly with your new NWL-11 M2M CDMA router. More advanced set up instructions can be found in the user manual which can be downloaded from www.netcommwireless.com

Package contents

This package includes

- 1 x NetComm Wireless NWL-11 router
- 1 x 1.5m yellow Ethernet cable 8P8C
- 1 x DIN rail mounting bracket
- 1 x DC terminal block
- 1 x quick start guide and safety manual

Device overview



| ITEM | DESCRIPTION |
|------------------------|---|
| Main antenna socket | SMA female connector for an optional external antenna. |
| Two-way captive power | Terminal block for connecting power cable. Operates in the 8-35V DC range. |
| Reset button | Press and hold for less than 5 seconds to reboot to normal mode. |
| | Press and hold for 5 to 15 seconds to reboot to recovery mode. |
| | Press and hold for 15 to 20 seconds to reset the router to factory default settings. |
| RJ45 PoE Ethernet port | Connect one or several devices via a network switch here. This port can also optionally receive Power over Ethernet (802.3af PoE) in which case the DC power supply can serve as a backup power source if required. |

Getting started

Depending on your individual setup, you may need certain components to configure your device correctly.


- External power supply unit for the NetComm Wireless NWL-11 (not included).
- Flathead screwdriver (no 3) for terminating power input wires.
- Notebook or PC for advanced configuration.
- Additional fasteners and screwdrivers for specific wall or rail mounting.

Mounting options

The NetComm Wireless NWL-11 can be installed quickly and easily in a variety of locations.

| MOUNT TYPE | DESCRIPTION | BENEFITS |
|--------------------------|--|--|
| Wall mount | Flat against the wall | Slimline form factor, close to wall |
| | Perpendicular to the wall | Small wall footprint |
| | Mount via DIN rail bracket | Easy to remove |
| C Section DIN rail mount | Slide onto a rail | Simplicity |
| Top hat DIN rail mount | Mount on a bracket and slide onto a rail | Simplicity. Can mount in between other devices |
| Desk mount | Stand on a desk | Simplicity, versatility |


Wall mount
Flat against the wall



Perpendicular to the wall



Mounted via DIN Rail Bracket




DIN Rail mounting bracket



DIN Rail mounting bracket

- | | |
|---|---|
| 1 | Push to release |
| 2 | V Bend allows you to snap the DIN bracket onto the middle of a DIN rail, rather than sliding it onto the end. |


C Section DIN rail mount



Top hat DIN rail mount



Desk mount



Installing your device

Step 1

Mount your router in a suitable location using the options listed on page 4.

When selecting a location to mount the NWL-11 router, keep in mind that it houses two high performance internal antennas designed to provide optimum signal strength in a wide range of environments. If you find the signal strength is weak, try moving the router to a different place or mounting it differently. If signal strength doesn't improve, you may need to attach an external antenna (not included) to the router's female SMA connector.

Note: If you connect an external antenna to the female SMA connector, the main internal antenna disables automatically but the auxiliary internal antenna remains connected to provide (where possible) diversity assistance.

Step 2

Connect power to your router using one of three options.

Power over Ethernet (802.3af PoE)

Connect your router to a PoE injector or PoE network switch using the bundled yellow Ethernet cable 8P8C. This method uses the Ethernet connection to power and transfer data to and from the router.

DC power via 2-pin connector

Remove the attached green terminal block from your router and connect to the router's power socket using a DC power supply, sold separately.

DC power via field terminated power source

If a 8-35V DC power supply is available, you can insert the wires into the supplied terminal block to power your router. Use a no 3 flathead screwdriver to tighten the terminal block screws and secure the power wires, making sure the polarity of the wires are correctly matched, as illustrated below.

Polarity for MC100#50802 Terminal Block



The green power LED on the router lights up when a power source is connected.

Tip: You can connect both the PoE and DC power sources at the same time. When both are connected, the DC power acts as backup to the PoE input.

Step 3

Connect equipment that requires network access to the Ethernet port of your router. You can connect one device directly, or several devices using a network switch.

If you're using PoE as the power source, you need to connect any devices via an available Ethernet port on your PoE power source (be it a PoE network switch or PoE power injector).

Switch on your power supply and wait 2 minutes for your NetComm Wireless NWL-11 to start up and connect to the mobile network.

Your router is now connected.

To check the status of your router, compare the LED indicators on the device with those listed on the next page of this guide.

Overview of LED indicators

| LED ICON | NAME | COLOR | STATE | DESCRIPTION |
|--|-----------------|---|---------------|---------------------------|
|  | Power |  | Off | Power off |
| | |  | Double flash | Powering up |
| | |  | On | Power on |
| | |  | On | Power on in recovery mode |
| | |  | Slow flashing | Hardware error |
|  | Network |  | On | Connected via WWAN |
| | |  | Blinking | Traffic via WWAN |
| | |  | Slow flashing | Connecting data session |
| | |  | On | Registered network |
| | |  | Slow flashing | Registering network |
| | |  | On | Can't connect |
| | |  | Slow flashing | Not activated |
|  | Signal strength |  | On | EVDO coverage |
| | |  | On | CDMA 1x coverage |

Logging into the router and activating it on the network

Before you can use your M2M CDMA Router it needs to be activated on the carrier's network. The following steps guide you through logging into the web based configuration interface and activating the router.

The web based configuration interface is also used for status monitoring, advanced configuration and troubleshooting.

To access this interface you'll need a computer with an Ethernet port and web browser (such as IE, Chrome, Firefox or Safari) installed.

Step 1

Make sure your NetComm Wireless NWL-11 is turned on and disconnect any Ethernet connections.

Step 2

Attach the supplied yellow Ethernet cable 8P8C to the LAN Ethernet port on your router and the other to your computer. Then access the user interface by entering **http://192.168.1.1/** into your web browser, enter your username and password and click **Log in**.

There are two system management accounts (Root Manager and Admin) with different management capabilities.

Root Manager account

Grants full privileges such as firmware upgrades, device configuration, backup and restore, and reset to factory default settings. To access the Root Manager account, use these login details.

| http://192.168.1.1 | |
|--------------------|-------|
| Username: | root |
| Password: | admin |

Admin account

Allows updates to general settings. To access the Admin account, use these login details.

| http://192.168.1.1 | |
|--------------------|-------|
| Username: | admin |
| Password: | admin |

Step 3


Once logged in you'll see the Status page. The Status page displays an overview of information about the network your router is connected to (if any), signal strength and data connection status.

The first time you log in to the router, its activation status is deactivated and the router prompts you to activate it with a pop-up window containing the following text:

"This device is not currently activated on a service provider network. If you wish to use the device with the cellular data network please ensure the device is inside the service provider coverage area and a service plan is already associated with this device. Click OK to start the activation process, Cancel to abort."

Click **OK** to begin the activation process.

The router displays "Programming In Progress". Wait approximately **2 minutes** for the activation process to complete.



When the activation process is complete, the router displays the Status page. The word **Activated** appears in the **Activation Status** field on the Status page. Your NWL-11 is now activated and ready for use.

For more information on advanced configuration, refer to the full product User Manual available from the **Help** link in the web configuration interface or from the NetComm Wireless website at

<http://www.netcommwireless.com/>


Configuring multiple devices

To apply your advanced configuration settings to more than one NetComm Wireless NWL-11 router, follow these simple steps.

Step 1

Back up your router's configuration

- ❖ Log in to the web configuration interface, click on the **System** menu, select **System Configuration** and click on **Settings Backup / Restore**.
- ❖ If you want to password protect your backup configuration files, enter your password in the fields under **Save a copy of current settings** and click on **Save**. If you don't want to password protect your files, just click on **Save**. The router will then prompt you to select a location to save the settings file.




Step 2

Restore your backup configuration

- 📶 In the web configuration interface click on the **System** menu, select **System Configuration** and click on **Settings Backup / Restore**.
- 📶 From the **Restore saved settings** section, click on **Browse / Choose a File** and select the backup configuration file on your computer.
- 📶 Click **Restore** to copy the settings to the new NetComm Wireless NWL-11 router. The router will apply these settings and inform you it will reboot - click on **OK**.

Tip: Don't change the file extension of the backup file as this may cause it to corrupt.



Safety and product care

RF exposure

Your device contains a transmitter and a receiver. When it is on, it receives and transmits RF energy. When you communicate with your device, the system handling your connection controls the power level at which your device transmits.

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. To ensure compliance with RF exposure guidelines the device must be used with a minimum of 20cm separation from the body. Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

External antenna

Any optional external antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operated in conjunction with any other antenna or transmitter. Please consult the health and safety guide of the chosen antenna for specific body separation guidelines as a greater distance of separation may be required for high-gain antennas.

Any external antenna gain must meet RF exposure and maximum radiated output power limits of the applicable rule section. The maximum antenna gain for this device as reported to the FCC is: 9.4 dBi (850MHz) and 8.4 dBi (1900MHz).

FCC statement

FCC compliance

Federal Communications Commission Notice (United States): Before a wireless device model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure.

FCC regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-  Reorientate or relocate the receiving antenna.
-  Increase the separation between the equipment and receiver.
-  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-  Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Electrical safety

Accessories

Only use approved accessories.

Do not connect with incompatible products or accessories.

Connection to a car

Seek professional advice when connecting a device interface to the vehicle electrical system.

Distraction

Operating machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Product handling

You alone are responsible for how you use your device and any consequences of its use.

You must always switch off your device wherever the use of a mobile phone is prohibited. Do not use the device without the clip-on covers attached, and do not remove or change the covers while using the device. Use of your device is subject to safety measures designed to protect users and their environment.

-  Always treat your device and its accessories with care and keep it in a clean and dust-free place.
-  Do not expose your device or its accessories to open flames or lit tobacco products.
-  Do not expose your device or its accessories to liquid, moisture or high humidity.
-  Do not drop, throw or try to bend your device or its accessories.
-  Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
-  Do not paint your device or its accessories.
-  Do not attempt to disassemble your device or its accessories, only authorised personnel must do so.

- ⊞ Do not use or install this product in extremely hot or cold areas. Ensure that the device is installed in an area where the temperature is within the supported operating temperature range (-20°C to 65°C)
- ⊞ Do not use your device in an enclosed environment or where heat dissipation is poor. Prolonged use in such space may cause excessive heat and raise ambient temperature, which will lead to automatic shutdown of your device or the disconnection of the mobile network connection for your safety. To use your device normally again after such shutdown, cool it in a well-ventilated place before turning it on.
- ⊞ Please check local regulations for disposal of electronic products.
- ⊞ Do not operate the device where ventilation is restricted
- ⊞ Installation and configuration should be performed by trained personnel only.
- ⊞ Do not use or install this product near water to avoid fire or shock hazard. Avoid exposing the equipment to rain or damp areas.
- ⊞ Arrange power and Ethernet cables in a manner such that they are not likely to be stepped on or have items placed on them.
- ⊞ Ensure that the voltage and rated current of the power source match the requirements of the device. Do not connect the device to an inappropriate power source.

Children

Do not leave your device and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could accidentally damage the device.

Your device contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.

Emergency situations

This device, like any wireless device, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless device for emergency communications.

Device heating

Your device may become warm during normal use.

Faulty and damaged products

Do not attempt to disassemble the device or its accessories.

Only qualified personnel must service or repair the device or its accessories.

If your device or its accessories have been submerged in water punctured or subjected to a severe fall, do not use until they have been checked at an authorised service centre.

Interference

Care must be taken when using the device in close proximity to personal medical devices, such as pacemakers and hearing aids.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15cm be maintained between a device and a pacemaker to avoid potential interference with the pacemaker.

Hearing aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical devices

Please consult your doctor and the device manufacturer to determine if operation of your device may interfere with the operation of your medical device.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Interference in cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of devices in their vehicles unless an external antenna is included in the installation.

Explosive environments

Petrol stations and explosive atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your device or other radio equipment. Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting caps and areas

Turn off your device or wireless device when in a blasting area or in areas posted turn off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.

Product Warranty

NetComm Wireless products have a standard 12 months warranty from date of purchase.

Technical Support

For firmware updates or if you have any technical difficulties with your product, please refer to the support section of our website.



NetCommWireless

NETCOMM WIRELESS LIMITED ABN 85 002 490 486

Head Office, 18-20 Orion Road
Lane Cove, Sydney, NSW 2066, Australia

p: +61 2 8205 3888 f: +61 2 9424 2010
e: m2msales@netcommwireless.com

www.netcommwireless.com