


Dynalink
RTA230 - RTA770 - RTA770W - RTA1320 - RTA1335 -
RTA1025W - RTA1030W - RTA1046VW
Firmware Upgrade Instructions

1. Using your web browser (Internet Explorer, Mozilla Firefox, etc.), enter the IP address of your NetComm router into the Address Bar.
The default address is <http://192.168.1.1>.
2. Log on using your administrative user name and password.
The default is **admin** and **admin**.
3. Go to **Management > Update Firmware**.



The screenshot shows the Dynalink router's web interface. At the top, there is a navigation bar with icons and labels for 'Quick Start', 'Status', 'Advanced', 'Wireless', 'Diagnostics', and 'Management'. Below this, a sidebar on the left lists various administrative functions: 'Admin Account', 'Remote Access', 'Internet Time', 'System Log', 'SNMP', 'Backup Config', 'Update Firmware', and 'Reset Router'. The main content area is titled 'Update Firmware' and contains the following instructions:

- Step 1:** Obtain an updated firmware image file from your ISP.
- Step 2:** Enter the path to the image file location in the box below or click "Browse" to locate the image file.
- Step 3:** Click "Update Firmware" once to upload the new image file.

A **NOTE:** The update process takes about 2 minutes to complete, and your ADSL router will reboot.

Below the instructions, there is a section for 'Current Firmware Version' (2.14.02.07_a2a013b) and a 'New Firmware File Name' field with a 'Browse...' button. At the bottom of this section is an 'Update Firmware' button.

4. Use the **Browse** button to locate the firmware image file.
5. After selecting the firmware image file, click **Update Firmware**, and wait for the process to complete.
The process may take approximately 1-2 minutes, after which, the modem will reboot.