



---

## **Bridge Mode Setup**

(NB7PLUS4W)

## **Bridge Mode**

This guide will take you through the steps required to set your modem to bridged mode.

1. Open your web browser and go to the address <http://192.168.1.1>, using **admin** as the username and password.
2. Select "**Quick Setup**" from the menu on the lefthandside of the page.
3. Select "**Bridge**" from the "**Protocols**" pulldown menu as per the screenshot below.

The screenshot shows the NetComm Quick Setup web interface. On the left is a navigation menu with the following items: Device Info, Quick Setup, Advanced Setup, Wireless, Diagnostics, and Management. The main content area is titled "Quick Setup" and contains the following sections:

- Service Name:** Quickstart
- Protocols:** Bridge (highlighted with a red box)
- Encapsulation Mode:** LLC/SNAP-BRIDGING
- PVC Settings:** VPI: [0-255] 8, VCI: [32-65535] 35
- LAN Configuration:** IP Address: 192.168.1.1, Subnet Mask: 255.255.255.0
- Wireless Settings:** Enable Wireless . Enter the wireless network name (also known as SSID). SSID: Netcomm 7 Series

At the bottom right, there are two buttons: "Save" and "Save/Reboot". Below the buttons, there is a note: "Save - Only saves configuration data. Save/Reboot - Saves configuration data and reboots the router to make the new configuration effective."

4. Make sure your **VPI** is set to: **8** (**NZ users set your VPI to 0**)
5. Make sure your **VCI** is set to: **35** (**NZ users set your VCI to 100**)
6. Click "**Save/Reboot**" to save these changes.

Your modem will now reboot. When it has finished restarting, it will then be in bridged mode.