

Dynalink RTA1320_Rev2 NZ Firmware Upgrade Instructions

1. Using your web browser (Internet Explorer, Mozilla Firefox, etc.), enter the IP address of your Dynalink router into the Address Bar. The default address is <http://192.168.1.1>.
2. Log on using your administrative user name and password. The default is **admin** and **admin**.
3. Click on **Management** at the top, and then **Update Firmware** on the left.

The screenshot shows a Microsoft Internet Explorer browser window titled "ADSL2+ Router - Microsoft Internet Explorer provided by NetComm". The address bar contains "http://192.168.1.1/main.html". The browser's Favorites bar shows "ADSL2+ Router". The Dynalink web interface has a top navigation bar with "Quick Start", "Status", "Advanced", and "Management" (highlighted with a red box). A language dropdown is set to "English". On the left sidebar, "Update Firmware" is highlighted with a red box. The main content area is titled "Update Firmware" and includes a warning: "Warning: DO NOT turn off your router during firmware updates." Below the warning, the "Current Firmware Version" is "3.65m". The "New Firmware File Name" field contains "cfe-rta1320_rev2_16m_nz-v365p_a2pb025c" and is followed by a "Browse..." button. A red box highlights the "Update Firmware" button. To the right of the button, text states: "The update process takes about 2 minutes to complete, then your DSL router will reboot." At the bottom left, the current firmware version "3.65m" and the ADSL2+ model "A2pB025c.d20h" are displayed.

ADSL2+ Router - Microsoft Internet Explorer provided by NetComm

http://192.168.1.1/main.html

File Edit View Favorites Tools Help

Google 192.168.1.1 Search Share Sidewiki Check Trans

Favorites ADSL2+ Router

Dynalink Quick Start Status Advanced Management

Language: English

Update Firmware

Warning: DO NOT turn off your router during firmware updates.

Current Firmware Version: 3.65m

New Firmware File Name: cfe-rta1320_rev2_16m_nz-v365p_a2pb025c Browse...

Update Firmware

The update process takes about 2 minutes to complete, then your DSL router will reboot.

Firmware: 3.65m
ADSL2+ : A2pB025c.d20h

Use the **Browse** button to locate the firmware image file.

4. After selecting the firmware image file named **cfe-rta1320_rev2_16m_nz-v365p_a2pb025c**, click **Update Firmware**, and wait for the process to complete. The upgrade process may take approximately 1-2 minutes, the modem will automatically reboot after firmware upgrade. You will expected 'Power' and your connected 'Ethernet' port's LED light = **green** after firmware upgrade completed if the modem is not connected to an active ISP service line.

NOTE: DO NOT DISCONNECT YOUR PC FROM THE MODEM or POWER THE RTA1320_REV2 OFF DURING FIRMWARE UPGRADE.

5. Your RTA1320_REV2 firmware upgrade is now completed. The version number is now shown on the button left hand side of the web management interface.

