

Latest Firmware: V85.1.03

NOTE

Please follow the steps below in order to upgrade the firmware on the V85:

1. Log into the V85 Web Configuration page using the V85's IP Address.
2. Click on **System** on the left menu.
3. In **FTP Server IP**, enter the following:

files.netcomm.com.au

In **ImageFile Name**, enter the following:

V85.1.03.bin

The screenshot shows the NetComm V85 web configuration interface. On the left is a navigation menu with the following items: Overview, Network, SIP, Phone, and System. The 'System' menu item is highlighted. The main content area is titled 'System' and contains the following sections:

- Upgrade:**
 1. FTP Server IP:
 2. ImageFile Name:
-
- Change Keypad Password:**
 1. Keypad Password:
 2. Confirm Password:

4. Press the **Set** button, and then press the **Upgrade Now!** button.
The V85 will now be upgrading the firmware. Please do not disconnect any cables or turn off the V85 at this point.
After approximately 2 minutes, the V85 will have finished the upgrade process.

