



Firmware Upgrade Instructions

(NB604n)

Upgrade Notice

Updating your firmware is recommended if you are experiencing problems with your product or have been asked to do so by a NetComm Wireless Technical Support Representative. It is critical to select the correct firmware for your product, before proceeding, please confirm you are on the correct page, by checking the sticker on the base of your NetComm Wireless equipment for the part/product number.

Please take caution while upgrading the firmware. Installation of the incorrect firmware file, disruption to the power source or a break in the connection to your computer during the upgrade process, may render your product unusable and will void the product warranty.

Before Installing the Firmware

Ensure that ALL Anti Virus/Firewall/Security programs are turned OFF before performing the firmware update. Also ensure that you are performing this firmware upgrade when connecting your modem/router with an Ethernet cable.

Do NOT use a wireless connection to upgrade the firmware


File Preparation

If the file's extension is ".img" or ".bin", do not try to open the firmware file on your computer as they can become corrupt. You need to follow the instructions from the Firmware Upgrade Instructions Guide

If the file's extension is ".zip", then you need to unzip the compressed files to a location on your computer to get the actual firmware file using UnZip or WinZip software and then follow the instructions from the guide.

NB304n Firmware Upgrade Procedure


1. Open your web browser and navigate to the site, <http://192.168.1.1>




2. Use "admin" (without the quotes) for the username and "admin" (without the quotes) for the password.




3. Click on Management on the left-hand menu and select Update Software.



4. Click Browse/Choose File, to locate the firmware file and click on Update Software.
The firmware upgrade process will take approximately two (2) minutes. Close the window.



5. Following the firmware upgrade, repeat steps one (1) and two (2)
6. Click on Management from the left-hand menu, select settings from the sub menu then click on Restore Default.



7. Click on Restore Default Settings and click OK to proceed. This process will take approximately two (2) minutes and is the final step of the Firmware Update Procedure.

