

Instructions to upgrade the Firmware for NB504.

- Navigate to <http://192.168.1.1> in a web browser.
- Enter "admin" for both username and password and click Ok. (without quotes)
- Select "System Tools" on left-hand side under "Maintenance".
- Select "Firmware" and then browse the file which you have downloaded from the NetComm Website in the "File:" field.
- Select the "Upgrade" button at the bottom of the page.
- The router firmware will be upgraded and the router will then reboot.
- After the router has rebooted, the firmware upgrade is complete.