


Dynalink
RTA230 - RTA770 - RTA770W - RTA1320 - RTA1335 -
RTA1025W - RTA1030W - RTA1046VW
Firmware Upgrade Instructions

1. Using your web browser (Internet Explorer, Mozilla Firefox, etc.), enter the IP address of your NetComm router into the Address Bar.
The default address is <http://192.168.1.1>.
2. Log on using your administrative user name and password.
The default is **admin** and **admin**.
3. Go to **Management > Update Firmware**.



The screenshot shows the Dynalink web interface. At the top, there is a navigation menu with icons and labels for 'Quick Start', 'Status', 'Advanced', 'Wireless', 'Diagnostics', and 'Management'. The 'Management' menu item is highlighted. Below the navigation menu, there is a language dropdown set to 'English'. On the left side, there is a sidebar menu with the following items: 'Admin Account', 'Remote Access', 'Internet Time', 'System Log', 'SNMP', 'Backup Config', 'Update Firmware', and 'Reset Router'. The 'Update Firmware' item is selected. The main content area is titled 'Update Firmware' and contains the following instructions:

Step 1: Obtain an updated firmware image file from your ISP.
Step 2: Enter the path to the image file location in the box below or click "Browse" to locate the image file.
Step 3: Click "Update Firmware" once to upload the new image file.

NOTE: The update process takes about 2 minutes to complete, and your ADSL router will reboot.

Current Firmware Version: 2.14.02.07_a2a013b

New Firmware File Name:

4. Use the **Browse** button to locate the firmware image file.
5. After selecting the firmware image file, click **Update Firmware**, and wait for the process to complete.
The process may take approximately 1-2 minutes, after which, the modem will reboot.