









C10100P Installation Guide

Mounting inside a Telstra Network Termination Device (NTD)		Mounting on Wall Plate (600 Series)	
	<p>Step 1 Line up the C10100P base with the mounting holes of the NTD as shown. Use 2 self-tap screws (<i>provided in plastic bag</i>) to secure the Splitter base to the NTD.</p>		<p>Step 1 Draw the cables through the wall plate as shown. Clip the base of the C10100P on the wall plate aligning to match the prongs of the wall plate with the holes of the base as shown.</p>
	<p>Step 2 Push to clip and lock the epoxy potted splitter module onto the splitter base and terminate the wires on the IDC terminal block that are clearly identified as 'Line', 'DSL', 'Tel1' and 'Tel2'. [Additional telephones may be connected as shown below using moisture resistant connectors or other joining techniques (not provided by C10). Test the installation before proceeding to Step 3]</p> <div style="text-align: center;">  <p>Line in DSL modem Tel.1 Tel.2 3-wire moisture resistant connectors Phone outlet 3 Phone outlet 2 Phone outlet 1</p> </div>		<p>Step 2 Push to clip and lock the epoxy potted splitter module onto the splitter base and terminate the wires on the IDC terminal block that are clearly identified as 'Line', 'DSL', 'Tel1' and 'Tel2'. (Test the installation before proceeding to Step 3)</p>
	<p>Step 3 Push the small removable cover in place and tighten the self-tap screw (<i>provided with the small removable cover</i>) as shown.</p>		<p>Step 3 Push the small removable cover in place and tighten the self-tap screw (<i>provided with the small removable cover</i>) as shown.</p>
Mounting on Wall Plate (Clipsal 2031 VTO type)			
		<p>For Clipsal type 2031VTO type Wall Plate - Draw the cables through the wall plate as shown. Mount the Splitter base on the Clipsal wall plate, aligning the screw holes as shown (<i>marked in the picture</i>), secure the two screws (<i>not provided by C10 but normally comes with the Clipsal wall plate</i>). Then follow steps 2 and 3 as above.</p>	
<p>Please note that the base of the Central Splitter/Filter is also provided with two wall mounting holes that facilitate mounting the Central Splitter / Filter on the wall.</p>			
<p>www.c10.com.au</p>			