

NetComm

Configuring an RTA1046 with an iiNet VoIP account.

Before proceeding you will need to complete the setup of all required hardware components as per the User Guide that came supplied with your Dynalink RTA1046.

1. Open up web-browser and type in 192.168.1.1 in the address bar and hit enter



2. Now enter in the modem user name password. By default the username is "admin" and the password is "admin" (without quotes).



3. Click on "Voice" on the top menu bar.

Dynalink Quick Start | Status | Advanced | Wireless | Voice | Management

Language: English

SIP Basic
SIP Extension
Audio Codec
PSTN Control
Call Log

SIP Basic Settings

Phone 1: **PSTN mode**
 (Internet connection is not available. You can not make VOIP phone calls through this port now.)

Phone 2: **PSTN mode**
 (Internet connection is not available. You can not make VOIP phone calls through this port now.)

Interface: pppoa_0_100_1

SIP Transport Protocol: UDP Port: 5060

VoIP Service Provider: Others As Given by iiNet

SIP Registrar Address: Port: 5060

SIP Outbound Proxy: Port: 5060

SIP Proxy Server Address: Port: 5060

Registration Information

| Phone | Phone Number | Caller Name | User Name | Password |
|-------|--------------|-------------|-----------|---------------------|
| 1 | | | | iiNet VoIP Password |
| 2 | | | | |

Apply Cancel iiNET VoIP Number

Firmware: 3.63n
 ADSL2+: A2p8023d.d20h
 Wireless: 3.131.35.6

Done Intern

5. Now click on "Apply".

6. The RTA1046VW will now attempt to register to Exetel and you will be presented with the following screen.



 Quick Start

 Status

 Advanced

 Wireless

 Voice

 Management

Language:

SIP Basic
SIP Extension
Audio Codec
PSTN Control
Call Log

Processing...

Firmware: 3.63h
ADSL2+: A2pB023d.d20h

7. You should now be presented with the below screen confirming that your registration details have been successful

- SIP Basic
- SIP Extension
- Audio Codec
- PSTN Control
- Call Log

Firmware: 3.63n
ADSL2+: A2pB023d,d20h

SIP Basic Settings

Phone 1: **VOIP mode**
(You can make VOIP phone calls through this port now.) Register sucessfull

Phone 2: **VOIP mode**
(You can make VOIP phone calls through this port now.)

Interface:

SIP Transport Protocol: Port:

VoIP Service Provider:

SIP Registrar Address: Port:

SIP Outbound Proxy: Port:

SIP Proxy Server Address: Port:

Registration Information

Congratulations, you can now start using a standard telephone handset that is connected to the Dynalink RTA1046VW using iiNet's VoIP service.

Happy chatting!